# Fuel System (G6BA-GSL 2.7)

**GENERAL** 

GASOLINE ENGINE CONTROL SYSTEM ENGINE CONTROL MODULE (ECM)

DTC TROUBLESHOOTING PROCEDURES

**FUEL DELIVERY SYSTEM** 

FUEL INJECTOR FUEL PUMP (FP) FUEL TANK







GENERAL FLB -3

## **GENERAL**

#### SPECIFICATIONS EDC64FCA

#### **FUEL DELIVERY SYSTEM**

Items	Specification		
Fuel Tank	Capacity	55 L	
Fuel Retrun System	Туре	Returnless	
Fuel Filter	Туре	High pressure type (built in Fuel Pump Assembly)	
Fuel Proceure Regulator	Туре	Built in fuel pump assembly	
Fuel Pressure Regulator	Regulated Fuel Pressure	350 kpa (3.5 kg/cm2, 49.8 psi)	
Fuel Pump	Туре	Electrical, in-tank type	

#### **ENGINE MANAGEMENT SYSTEM**

SENSORS	Mass Air Flow Sensor (MAFS)	Туре	I	Hot film type
		Output Voltage	Idle	e: 0.6 ~ 1.0 V
	التالاخو			rpm: 1.3 ~ 1.5 V rpm: 1.7 ~ 1.9 V
	Intake Air Temperature	Туре	Thermistor type (built in MAFS)	
یت محدود)	Sensor (IATS)	Resistance	ů -20 (-4 )	11.72 ~ 19.54 kΩ
			0 (32 )	4.75 ~ 7.11 kΩ
رو در ایران	ديجيتال تعميركاران خود	ولین سامانه	20 (68 )	2.22 ~ 2.82 kΩ
			40 (104 )	1.06 ~ 1.31 kΩ
			60 (140 )	0.55 ~ 0.66 kΩ
			80 (176 )	0.30 ~ 0.36 kΩ
	Engine Coolant Temperature	Type	Thermistor type	
	Sensor (ECTS)	Resistance	-40 (-40°F)	48.14 kΩ
			-20 (-4°F)	14.13 ~ 16.83 kΩ
			0 (32°F)	5.79 kΩ
			20 (68°F)	2.31 ~ 2.59 kΩ
			40 (104°F)	1.15 kΩ
			60 (140°F)	0.59 kΩ
			80 (176°F)	0.32 kΩ

## **FUEL SYSTEM (G6BA-GSL 2.7)**

SENSOR	Throttle Position Sensor (TPS)	Туре	Varia	ble Resistor Type
		Resistance	1.6 ~ 2.4 kΩ	
		Output Voltage	C.T	0.2 ~ 0.8 V
			W.O.T	4.3 ~ 4.8 V
	Heated Oxygen Sensor (HO2S)	Туре	Zirconia Sensor (including Heater)	
		Output Voltage		0 ~ 1V
		Heater Resistance	3.0 ~	4.0 at 23±5
	Knock Sensor	Туре	Pie	zo-electric type
		Capacitance		0.8 ~1.6 nF
	Camshaft Position Sensor	Туре	Hal	I Effect Sensor
	(CMPS)	Output Voltage	0 ~ 5.0V	
	Crankshaft Position Sensor	Туре	Hall Effect Sensor	
	(CKPS)		0 ~ 5.0V	
ACTUATORS	Injector	Туре	Electromagnetic Type	
		Number	6	
		Coil Resistance	13.8	~ 15.2 at 20
	Purge Control Solenoid	Type	Dut	ty Control Type
/	Valve (PCSV)	Coil Resistance	24.5 ~ 27.5 at 20	
ت محدود)	Idle Speed Control Actuator	Туре	Do	uble Coil Type
	(ISCA) پجیتال تعمیرکاران خودر و در ایران	Coil Resistance	CLOSE	17.0 ~ 18.2 (at 20 )
و در ایران		لین سامانه د	OPEN	14.9 ~ 16.1 (at 20 )
	Ignition Coil	Туре	N	fold Coil type
		Primary Coil	0.74±10%	
		Secondary Coil	1	13.3±15% kΩ

GENERAL FLB-5

#### SEALANTS E319AF6A

e Coolant Temperature Sensor (ECTS) assen	LOCTITE 962T or equivalent
---	----------------------------

#### **SERVICE STANDARD**

Basic Idle rpm (After warm up)	A/C OFF	N, P (or Neutral)	700±100 rpm
	A/C OFF	D 700±100 rpm	
	A/C ON	N,P (or Neutral)	870±100 rpm
	A/C ON	D	700±100 rpm
Ignition Timing(After warm up, at idle)	BTDC 12°±5°		

#### TIGHTENING TORQUES E5FDCEF7

#### **ENGINE CONTROL SYSTEM**

Items	N⋅m	kgf∙m	lbf-ft
ECM bracket installation bolt/nut	3.9 ~ 5.9	0.4 ~ 0.6	2.9 ~ 4.3
Mass air flow sensor clamp installation	2.9 ~ 4.9	0.3 ~ 0.5	2.2 ~ 3.6
Crankshaft position sensor installation bolt	3.9 ~ 5.9	0.4 ~ 0.6	2.9 ~ 4.3
Crankshaft position sensor connector bracket installation bolt	19.6 ~ 21.6	2.0 ~ 2.2	14.5 ~ 15.9
Crankshaft position sensor wheel installation screw	4.9 ~ 5.9	0.5 ~ 0.6	3.6 ~ 4.3
Knock sensor installation bolt	16.7 ~ 25.5	1.7 ~ 2.6	12.3 ~ 18.8
Knock sensor connector bracket installation bolt	3.9 ~ 5.9	0.4 ~ 0.6	2.9 ~ 4.3
Engine coolant temperature sensor installation	19.6 ~ 39.2	2.0 ~ 4.0	14.5 ~ 28.9
Heated Oxygen Sensor (Bank 1, Sensor 1)	39.2 ~ 49.1	4.0 ~ 5.0	28.9 ~ 36.2
Heated Oxygen Sensor (Bank 1, Sensor 2)	39.2 ~ 49.1	4.0 ~ 5.0	28.9 ~ 36.2
Heated Oxygen Sensor (Bank 2, Sensor 1)	39.2 ~ 49.1	4.0 ~ 5.0	28.9 ~ 36.2
Heated Oxygen Sensor (Bank 2, Sensor 2)	39.2 ~ 49.1	4.0 ~ 5.0	28.9 ~ 36.2
Camshaft position sensor installation bolt	3.9 ~ 5.9	0.4 ~ 0.6	2.9 ~ 4.3
Oil pressure switch installation	14.7 ~ 21.6	1.5 ~ 2.2	10.9 ~ 15.9
Throttle position sensor installation screws	1.5 ~ 2.5	0.15 ~ 0.25	1.1 ~ 1.8
Idle speed control actuator installation bolts	5.9 ~ 7.8	0.6 ~ 0.8	4.3 ~ 5.8

#### **FUEL DELIVERY SYSTEM**

Items	N-m	kgf⋅m	lbf-ft
Delivery pipe installation bolts	9.8 ~ 14.7	1.0 ~ 1.5	7.2 ~ 10.9
Throttle body installation bolt/nut	14.7 ~ 19.6	1.5 ~ 2.0	10.9 ~ 14.5
Accelerator pedal installation bolt	12.7 ~ 15.7	1.3 ~ 1.6	9.4 ~11.6

## FUEL SYSTEM (G6BA-GSL 2.7)

## SPECIAL SERVICE TOOLS E4BD844F

Tool (Number and name)	Illustration	Application
09353-24100 Fuel Pressure Gauge		Measuring the fuel line pressure
	EFDA003A	
09353-38000 Fuel Pressure Gauge Adapter	BF1A025D	Connection between the delivery pipe and fuel feed line
09353-24000	DI IAUZU	Connection between Fuel Pressure Gauge
Fuel Pressure Gauge Connector		(09353-24100) and Fuel Pressure Gauge Adapter (09353-38000)
ران خودرو در ایران	لین سامانه دیجیتال تعمیرکا EFDA003C	91

GENERAL FLB -7

#### BASIC TROUBLESHOOTING E9DB66B0

#### BASIC TROUBLESHOOTING GUIDE

- 1 Bring Vehicle to Workshop
- 2 Analyze Customer's Problem
- Ask the customer about the conditions and environment relative to the issue (Use CUSTOMER PROBLEM ANALYSIS SHEET).
- 3 Verify Symptom, and then Check DTC and Freeze Frame Data
- Connect Hi-Scan (Pro) to Diagnostic Link Connector (DLC).
- Record the DTC and freeze frame data.
  - **NOTE**

To erase DTC and freeze frame data, refer to Step 5.

- 4 Confirm the Inspection Procedure for the System or Part
- Using the SYMPTOM TROUBLESHOOTING GUIDE CHART, choose the correct inspection procedure for the system
  or part to be checked.
- 5 Erase the DTC and Freeze Frame Data
  - **WARNING**

NEVER erase DTC and freeze frame data before completing Step 2 MIL/DTC in "CUSTOMER PROBLEM ANALYSIS SHEET".

- 6 Inspect Vehicle Visually
- Go to Step 11, if you recognize the problem.
- 7 Recreate (Simulate) Symptoms the DTC
- Try to recreate or simulate the symptoms and conditions of the malfunction as described by customer.
- If DTC(s) is/are displayed, simulate the condition according to troubleshooting procedure for the DTC.
- 8 Confirm Symptoms of Problem
- If DTC(s) is/are not displayed, go to Step 9.
- If DTC(s) is/are displayed, go to Step 11.
- 9 Recreate (Simulate) Symptom
- · Try to recreate or simulate the condition of the malfunction as described by the customer.
- 10 Check the DTC
- If DTC(s) does(do) not occur, refer to INTERMITTENT PROBLEM PROCEDURE in BASIC INSPECTION PROCEDURE.
- If DTC(s) occur(s), go to Step 11.
- 11 Perform troubleshooting procedure for DTC
- 12 Adjust or repair the vehicle
- 13 Confirmation test
- 14 END

LW8F1001

## FUEL SYSTEM (G6BA-GSL 2.7)

## FLB -8

#### **CUSTOMER PROBLEM ANALYSIS SHEET**

#### 1. VEHICLE INFORMATION

(I) VIN:	
(II) Production Date:	
(III) Odometer Reading: (km)	

#### 2. SYMPTOMS

Unable to start	Engine does not turn over	
Difficult to start	Engine turns over slowly Other	
Poor idling	Rough idling Incorrect idling Unstable idling (High: rpm, Low:rpm) Other	
Engine stall	Soon after starting After accelerator pedal depressed After accelerator pedal released During A/C ON Shifting from N to D-range Other	
Others	Poor driving (Surge) Knocking Poor fuel economy  Back fire After fire Other	

## 3. ENVIRONMENT

Problem frequency	Constant Sometimes () Once only Other
Weather	Fine Cloudy Rainy Snowy Other
Outdoor temperature	Approx °C/°F
Place	Highway Suburbs Inner City Uphill Downhill Rough road Other
Engine temperature	Cold Warming up After warming up Any temperature
Engine operation	Starting Just after starting ( min) Idling Racing Driving Constant speed Acceleration Deceleration A/C switch ON/OFF Other

#### 4. MIL/DTC

MIL (Malfunction Indicator Lamp)	Remains ON Sometimes lights up	Does not light
DTC	Normal DTC ( Freeze Frame Data	

GENERAL FLB -9

#### **BASIC INSPECTION PROCEDURE**

## MEASURING CONDITION OF ELECTRONIC PARTS' RESISTANCE

The measured resistance at high temperature after vehicle running may be high or low. So all resistance must be measured at ambient temperature (20  $\,$ , 68  $\,$ ), unless there is any notice.




The measured resistance in except for ambient temperature (20 , 68 ) is reference value.

## INTERMITTENT PROBLEM INSPECTION PROCEDURE

Sometimes the most difficult case in troubleshooting is when a problem symptom occurs but does not occur again during testing. An example would be if a problem appears only when the vehicle is cold but has not appeared when warm. In this case, technician should thoroughly make out a "CUSTOMER PROBLEM ANALYSIS SHEET" and recreate (simulate) the environment and condition which occurred when the vehicle was having the issue.

- Clear Diagnostic Trouble Code (DTC).
- Inspect connector connection, and check terminal for poor connections, loose wires, bent, broken or corroded pins, and then verify that the connectors are always securely fastened.



3. Slightly shake the connector and wiring harness vertically and horizontally.

- 4. Repair or replace the component that has a problem.
- Verify that the problem has disappeared with the road test.

#### SIMULATING VIBRATION

- Sensors and Actuators
  - : Slightly vibrate sensors, actuators or relays with finger.

#### **WARNING**

## Strong vibration may break sensors, actuators or relays

- b. Connectors and Harness
  - : Lightly shake the connector and wiring harness vertically and then horizontally.

#### SIMULATING HEAT

Heat components suspected of causing the malfunction with a hair dryer or other heat sourre.

#### **WARNING**

- DO NOT heat components to the point where they may be damaged.
- DO NOT heat the ECM directly.

#### SIMULATING WATER SPRINKLING

 Sprinkle water onto vehicle to simulate a rainy day or a high humidity condition.

## **WARNING**

DO NOT sprinkle water directly into the engine compartment or electronic components.

#### SIMULATING ELECTRICAL LOAD

 Turn on all electrical systems to simulate excessive electrical loads (Radios, fans, lights, etc.).

BFGE321A


#### **FLB-10**


#### **FUEL SYSTEM (G6BA-GSL 2.7)**

#### **CONNECTOR INSPECTION PROCEDURE**

- 1. Handling of Connector
  - a. Never pull on the wiring harness when disconnecting connectors.

d. When a tester is used to check for continuity, or to measure voltage, always insert tester probe from wire harness side.







BFGE015I

BFGE015F

 When removing the connector with a lock, press or pull locking lever. e. Check waterproof connector terminals from the connector side. Waterproof connectors cannot be accessed from harness side.






BEGE015.I

BFGE015G

 Listen for a click when locking connectors. This sound indicates that they are securely locked.



BFGE015H

### MOTE

- Use a fine wire to prevent damage to the terminal.
- Do not damage the terminal when inserting the tester lead.
- 2. Checking Point for Connector
  - While the connector is connected:
     Hold the connector, check connecting condition and locking efficiency.
  - b. When the connector is disconnected: Check missed terminal, crimped terminal or broken core wire by slightly pulling the wire harness. Visually check for rust, contamination, deformation and bend.
  - Check terminal tightening condition: Insert a spare male terminal into a female terminal, and then check terminal tightening conditions.

BFGE501A

GENERAL FLB -11

 Pull lightly on individual wires to ensure that each wire is secured in the terminal. If an open circuit occurs (as seen in [FIG. 1]), it can be found by performing Step 2 (Continuity Check Method) or Step 3 (Voltage Check Method) as shown below.





FIG 1



BFGE015K

3. Repair Method of Connector Terminal

a. Clean the contact points using air gun and/or shop rag.

**NOTE** 

Never use sand paper when polishing the contact points, otherwise the contact point may be damaged.

b. In case of abnormal contact pressure, replace the female terminal.

Continuity Check Method

NOTE

When measuring for resistance, lightly shake the wire harness above and below or from side to side.

Specification (Resistance)

1 or less Normal Circuit

1MΩ or Higher Open Circuit

#### WIRE HARNESS INSPECTION PROCEDURE


- Before removing the wire harness, check the wire harness position and crimping in order to restore it correctly.
- Check whether the wire harness is twisted, pulled or loosened.
- Check whether the temperature of the wire harness is abnormally high.
- 4. Check whether the wire harness is rotating, moving or vibrating against the sharp edge of a part.
- Check the connection between the wire harness and any installed part.
- If the covering of wire harness is damaged; secure, repair or replace the harness.

# ELECTRICAL CIRCUIT INSPECTION PROCEDURE CHECK OPEN CIRCUIT

- Procedures for Open Circuit
  - Continuity Check
  - Voltage Check

 Disconnect connectors (A), (C) and measure resistance between connector (A) and (C) as shown in [FIG. 2].

In [FIG.2.] the measured resistance of line 1 and 2 is higher than  $1M\Omega$  and below 1 respectively. Specifically the open circuit is line 1 (Line 2 is normal). To find exact break point, check sub line of line 1 as described in next step.




BFGE501B

#### **FLB-12 FUEL SYSTEM (G6BA-GSL 2.7)**

Disconnect connector (B), and measure for resistance between connector (C) and (B1) and between (B2) and (A) as shown in [FIG. 3].

In this case the measured resistance between connector (C) and (B1) is higher than 1MΩ and the open circuit is between terminal 1 of connector (C) and terminal 1 of connector (B1).




BFGE501C

Voltage Check Method

With each connector still connected, measure the voltage between the chassis ground and terminal 1 of each connectors (A), (B) and (C) as shown in [FIG. 4].

The measured voltage of each connector is 5V, 5V and 0V respectively. So the open circuit is between connector (C) and (B).




BFGE501D

#### CHECK SHORT CIRCUIT

- Test Method for Short to Ground Circuit
  - · Continuity Check with Chassis Ground

If short to ground circuit occurs as shown in [FIG. 5], the broken point can be found by performing below Step 2 (Continuity Check Method with Chassis Ground) as shown below.

FIG 5



BEGE501E

Continuity Check Method (with Chassis Ground)



Lightly shake the wire harness above and below, or from side to side when measuring the resistance.


Specification (Resistance)

1 or less Short to Ground Circuit 1M

Normal Circuit or Higher

Disconnect connectors (A), (C) and measure for resistance between connector (A) and Chassis Ground as shown in [FIG. 6].

The measured resistance of line 1 and 2 in this and higher than 1M example is below 1 spectively. Specifically the short to ground circuit is line 1 (Line 2 is normal). To find exact broken point, check the sub line of line 1 as described in the following step.




BFGE501F

GENERAL FLB -13

b. Disconnect connector (B), and measure the resistance between connector (A) and chassis ground, and between (B1) and chassis ground as shown in [FIG. 7].

The measured resistance between connector (B1) and chassis ground is 1 or less. The short to ground circuit is between terminal 1 of connector (C) and terminal 1 of connector (B1).



## FUEL SYSTEM (G6BA-GSL 2.7)

#### SYMPTOM TROUBLESHOOTING GUIDE CHART

MAIN SYMPTOM	DIAGNOSTIC PROCEDURE	ALSO CHECK FOR
Unable to start (Engine does not turn over)	<ol> <li>Test the battery</li> <li>Test the starter</li> <li>Inhibitor switch (A/T) or clutch start switch (M/T)</li> </ol>	
Unable to start (Incomplete combustion)	<ol> <li>Test the battery</li> <li>Check the fuel pressure</li> <li>Check the ignition circuit</li> <li>Troubleshooting the immobilizer system (In case of immobilizer lamp ON)</li> </ol>	<ul> <li>DTC</li> <li>Low compression</li> <li>Intake air leaks</li> <li>Slipped or broken timing belt</li> <li>Contaminated fuel</li> </ul>
Difficult to start	<ol> <li>Test the battery</li> <li>Check the fuel pressure</li> <li>Check the ECT sensor and circuit (Check DTC)</li> <li>Check the ignition circuit</li> </ol>	<ul><li>DTC</li><li>Low compression</li><li>Intake air leaks</li><li>Contaminated fuel</li><li>Weak ignition spark</li></ul>
Poor idling (Rough, unstable or incorrect Idle)	<ol> <li>Check the fuel pressure</li> <li>Check the Injector</li> <li>Check the long term fuel trim and short term fuel trim (Refer to CUSTOMER DATASTREAM)</li> <li>Check the ISCA and ISCA circuit (Check DTC)</li> <li>Inspect and test the Throttle Body</li> <li>Check the ECT sensor and circuit (Check DTC)</li> </ol>	<ul> <li>DTC</li> <li>Low compression</li> <li>Intake air leaks</li> <li>Contaminated fuel</li> <li>Weak ignition spark</li> </ul>
Engine stall	<ol> <li>Test the Battery</li> <li>Check the fuel pressure</li> <li>Check the ISCA and ISCA circuit (Check DTC)</li> <li>Check the ignition circuit</li> <li>Check the CKPS Circuit (Check DTC)</li> </ol>	<ul><li>DTC</li><li>Intake air leaks</li><li>Contaminated fuel</li><li>Weak ignition spark</li></ul>
Poor driving (Surge)	<ol> <li>Check the fuel pressure</li> <li>Inspect and test Throttle Body</li> <li>Check the ignition circuit</li> <li>Check the ECT Sensor and Circuit (Check DTC)</li> <li>Test the exhaust system for a possible restriction</li> <li>Check the long term fuel trim and short term fuel trim (Refer to CUSTOMER DATASTREAM)</li> </ol>	DTC     Low compression     Intake air leaks     Contaminated fuel     Weak ignition spark
Knocking	<ol> <li>Check the fuel pressure</li> <li>Inspect the engine coolant</li> <li>Inspect the radiator and the electric cooling fan</li> <li>Check the spark plugs</li> </ol>	DTC     Contaminated fuel

GENERAL FLB -15

MAIN SYMPTOM	DIAGNOSTIC PROCEDURE	ALSO CHECK FOR
Poor fuel economy	<ol> <li>Check customer's driving habits         <ul> <li>Is A/C on full time or the defroster mode on?</li> <li>Are tires at correct pressure?</li> <li>Is excessively heavy load being carried?</li> <li>Is acceleration too much, too often?</li> </ul> </li> <li>Check the fuel pressure</li> <li>Check the injector</li> <li>Test the exhaust system for a possible restriction</li> <li>Check the ECT sensor and circuit</li> </ol>	<ul> <li>DTC</li> <li>Low compression</li> <li>Intake air leaks</li> <li>Contaminated fuel</li> <li>Weak ignition spark</li> </ul>
Hard to refueling (Overflow during refueling)	<ol> <li>Inspect the fuel filler hose/pipe         <ul> <li>Pinched, kinked or blocked?</li> <li>Filler hose is torn</li> </ul> </li> <li>Inspect the fuel tank vapor vent hose between the EVAP. canister and air filter</li> <li>Check the EVAP. canister</li> </ol>	Malfunctioning gas station filling nozzle (If this problem occurs at a specific gas station during refueling)





#### **DESCRIPTION** E30FF0DE

If the Gasoline Engine Control system components (sensors, ECM, injector, etc.) fail, interruption to the fuel supply or failure to supply the proper amount of fuel for various engine operating conditions will result. The following situations may be encountered.

- Engine is hard to start or does not start at all.
- 2. Unstable idle.
- 3. Poor driveability

If any of the above conditions are noted, first perform a routine diagnosis that includes basic engine checks (ignition system malfunction, incorrect engine adjustment, etc.). Then, inspect the Gasoline Engine Control system components with the HI-SCAN (Pro).



#### **NOTE**

- Before removing or installing any part, read the diagnostic trouble codes and then disconnect the battery negative (-) terminal.
- Before disconnecting the cable from battery terminal, turn the ignition switch to OFF. Removal or connection of the battery cable during engine operation or while the ignition switch is ON could cause damage to the ECM.
- The control harnesses between the ECM and heated oxygen sensor are shielded with the shielded ground wires to the body in order to prevent the influence of ignition noises and radio interference. When the shielded wire is faulty, the control harness must be replaced.
- · When checking the generator for the charging state, do not disconnect the battery '+' terminal to prevent the ECM from damage due to the voltage.
- · When charging the battery with the external charger, disconnect the vehicle side battery terminals to prevent damage to the ECM.

## MALFUNCTION INDICATOR LAMP (MIL)

#### [EOBD]

A malfunction indicator lamp illuminates to notify the driver that there is a problem with the vehicle. However, the MIL will go off automatically after 3 subsequent sequential driving cycles without the same malfunction. Immediately after the ignition switch is turned on (ON position - do not start), the MIL will illuminate continuously to indicate that the MIL operates normally.


Faults with the following items will illuminate the MIL.

- Catalyst
- Fuel system
- Mass Air Flow Sensor (MAFS)
- Intake Air Temperature Sensor (IATS)
- Engine Coolant Temperature Sensor (ECTS)
- Throttle Position Sensor (TPS)
- Upstream Oxygen Sensor
- Upstream Oxygen Sensor Heater
- Downstream Oxygen Sensor
- Downstream Oxygen Sensor Heater
- Injector
- Misfire
- Crankshaft Position Sensor (CKPS)
- Camshaft Position Sensor (CMPS)
- **Evaporative Emission Control System**
- Vehicle Speed Sensor (VSS)
- Idle Speed Control Actuator (ISCA)
- Power Supply
- ECM
- MT/AT Encoding
- Acceleration Sensor
- MIL-on Request Signal
- Power Stage



#### NOTE

Refer to "INSPECTION CHART FOR DIAGNOSTIC TROUBLE CODES (DTC)" for more information.



EFDA015A

FLB -17

#### [NON-EOBD]

A malfunction indicator lamp illuminates to notify the driver that there is a problem with the vehicle. However, the MIL will go off automatically after 3 subsequent sequential driving cycles without the same malfunction. Immediately after the ignition switch is turned on (ON position - do not start), the MIL will illuminate continuously to indicate that the MIL operates normally.

Faults with the following items will illuminate the MIL

- Heated oxygen sensor (HO2S)
- Mass Air Flow sensor (MAFS)
- Throttle position sensor (TPS)
- Engine coolant temperature sensor (ECTS)
- Idle speed control actuator (ISCA)
- Injectors
- **ECM**

## **₩** NOTE

Refer to "INSPECTION CHART FOR DIAGNOSTIC TROUBLE CODES (DTC)" for more information.



[INSPECTION]


- After turning ON the ignition key, ensure that the light illuminates for about 5 seconds and then goes out.
- If the light does not illuminate, check for an open circuit in the harness, a blown fuse or a blown bulb.

#### **SELF-DIAGNOSIS**

The ECM monitors the input/output signals (some signals at all times and the others under specified conditions). When the ECM detects an irregularity, it records the diagnostic trouble code, and outputs the signal to the Data Link connector. The diagnosis results can be read with the MIL or HI-SCAN (Pro). Diagnostic Trouble Codes (DTC) will remain in the ECM as long as battery power is maintained. The diagnostic trouble codes will, however, be erased when the battery terminal or ECM connector is disconnected, or by the HI-SCAN (Pro).




If a sensor connector is disconnected with the ignition switch turned on, the diagnostic trouble code (DTC) is recorded. In this case, disconnect the battery negative terminal (-) for 15 seconds or more, and the diagnosis memory will be erased.



EFDA015A

#### THE RELATION BETWEEN DTC AND DRIVING PATTERN IN EOBD SYSTEM



- When the same malfunction is detected and maintained during two sequential driving cycles, the MIL will automatically illuminate.
- 2. The MIL will go off automatically if no fault is detected after 3 sequential driving cycles.
- A Diagnostic Trouble Code(DTC) is recorded in ECM memory when a malfunction is detected after two sequential driving cycles. The MIL will illuminate when the malfunction is detected on the second driving cycle.

If a misfire is detected, a DTC will be recorded, and the MIL will illuminate, immediately after a fault is first detected.


 A Diagnostic Trouble Code(DTC) will automatically erase from ECM memory if the same malfunction is not detected for 40 driving cycles.



- A "warm-up cycle" means sufficient vehicle operation such that the coolant temperature has risen by at least 40 degrees Fahrenheit from engine starting and reaches a minimum temperature of 160 degress Fahrenheit.
- A "driving cycle" consists of engine startup, vehicle operation beyond the beginning of closed loop operation.


FLB -19


#### **COMPONENTS LOCATION**



- 1. Mass Air Flow Sensor (MAFS)
- 2. Intake Air Temperature Sensor (IATS)
- 3. Engine Coolant Temperature Sensor (ECTS) 10. Idle Speed Control Actuator (ISCA)
- 4. Throttle Position Sensor (TPS)
- 5. Camshaft Position Sensor (CMPS)
- 6. Crankshaft Position Sensor (CKPS)
- 7. Diagnostic Link Connector (DLC)
- 8. Fuel Pump Relay
- 9. Injector
- 11. Vehicle Speed Sensor (VSS)
- 12. Knock Sensor
- 13. Ignition Switch
- 14. Purge Control Solenoid Valve (PCSV)
- 15. Main Relay
- 16. Ignition Coil
- 17. ECM
- 18. Heated Oxygen Sensor (Bank1, Sensor1)
- 19. Heated Oxygen seneor (Bank1, Sensor2)
- 20. Heated Oxygen seneor (Bank2, Sensor1)
- 21. Heated Oxygen seneor (Bank2, Sensor2)

#### **FUEL SYSTEM (G6BA-GSL 2.7)**





## FUEL SYSTEM (G6BA-GSL 2.7)

[18] Heated Oxygen Sensor (Bank 1, Sensor 1) [19] Heated Oxygen Sensor (Bank 1, Sensor 2)	
[EURO-II]	
HO2S (Bank 1, Sensor 1)  HO2S (Bank 1, Sensor 2)	
EZOF015B	






FLB -23

# ENGINE CONTROL MODULE (ECM)

#### ENGINE CONTROL MODULE (ECM) EBB1FBF9

#### 1. ECM HARNESS CONNECTOR



EZOF132A

#### 2. ECM TERMINAL FUNCTION

#### CONNECTOR [C133-1]

Pin No.	Description	Connected to	Remark
1	Ignition switch signal input	Ignition Switch	
2	Not connected	÷ II	
3	Diagnostic Data Line (k-Line)	Data Link Connector (DLC)	
4	ECM ground	Chassis ground	
-5	Power stage ground	Chassis ground	O
6	Power stage ground	Chassis ground	
7	Battery voltage supply	Battery	
8	Battery Voltage Supply after Main Relay	Main Relay	
9	Battery Voltage Supply after Main Relay	Main Relay	

#### **CONNECTOR [C133-2]**

Pin No.	Description	Connected to	Remark
1	Heated Oxygen Sensor Heater (B1/S1) control	Heated Oxygen Sensor (B1/S1)	Except for LEAD
2	Not connected		
3	Not connected		
4	Not connected		
5	Not connected		
6	Not connected		
7	Heated Oxygen Sensor (B1/S2) Heater control	Heated Oxygen Sensor (B1/S2)	- EURO-III/IV - JAPAN
8	Not connected		

## FUEL SYSTEM (G6BA-GSL 2.7)

Pin No.	Description	Connected to	Remark
9	Not connected		
10	Not connected		
11	Not connected		
12	Not connected		
13	Heated Oxygen Sensor (B2/S1) Heater control	Heated Oxygen Sensor (B2/S1)	Except for LEAD
14	Heated Oxygen Sensor (B1/S1) signal input	Heated Oxygen Sensor (B1/S1)	Except for LEAD
15	Heated Oxygen Sensor (B2/S1) signal input	Heated Oxygen Sensor (B2/S1)	Except for LEAD
16	Heated Oxygen Sensor (B1/S2) signal input	Heated Oxygen Sensor (B1/S2)	- EURO-III/IV - JAPAN
17	Fuel Consumption signal output	Trip Computer	
18	Heated Oxygen Sensor (B2/S2) signal input	Heated Oxygen Sensor (B2/S2)	- EURO-III/IV - JAPAN
19	Heated Oxygen Sensor (B2/S2) Heater control	Heated Oxygen Sensor (B2/S2)	- EURO-III/IV - JAPAN
20	Heated Oxygen Sensor (B1/S1) ground	Heated Oxygen Sensor (B1/S1)	Except for LEAD
21	Heated Oxygen Sensor (B2/S1) ground	Heated Oxygen Sensor (B2/S1)	Except for LEAD
22	Heated Oxygen Sensor (B1/S2) ground	Heated Oxygen Sensor (B1/S2)	- EURO-III/IV - JAPAN
23	Main Relay control output	Main Relay	O
24	Heated Oxygen Sensor (B2/S2) ground	Heated Oxygen Sensor (B2/S2)	- EURO-III/IV - JAPAN

#### CONNECTOR [C133-3]

Pin No.	Description	Connected to	Remark
1	Mass Air Flow Sensor signal input	Mass Air Flow Sensor (MAFS)	
2	Not connected		
3	Not connected		
4	Not connected		
5	Not connected		
6	Not connected		
7	Not connected		
8	Crankshaft Position Sensor signal input	Crankshaft Position Sensor (CKPS)	
9	Not connected		
10	Throttle Position Sensor supply	Throttle Position Sensor (TPS)	
11	Not connected		
12	Not connected		

Pin No.	Description	Connected to	Remark
13	Not connected		
14	Not connected		
15	Not connected		
16	Not connected		
17	Mass Air Flow Sensor ground	Mass Air Flow Sensor (MAFS)	
18	Not connected		
19	Throttle Position Sensor signal input	Throttle Position Sensor (TPS)	
20	Throttle Position Sensor ground	Throttle Position Sensor (TPS)	
21	Crankshaft Position Sensor ground	Crankshaft Position Sensor (CKPS)	
22	Intake Air Temperature Sensor signal input	Intake Air Temperature Sensor (IATS)	
23	Intake Air Temperature Sensor ground	Intake Air Temperature Sensor (IATS)	
24	Engine Coolant Temperature Sensor signal input	Engine Coolant Temperature Sensor (ECTS)	
25	Engine Coolant Temperature Sensor ground	Engine Coolant Temperature Sensor (ECTS)	- 0-
26	Power Steering Load input	Power Steering Switch	Q \ \_
27	Not connected	• • •	
28 = 0	Not connected	شرکت دیجیتال	
29	Knock Sensor #1 (Cyl. #1, 3, 5) signal input	Knock Sensor (KS) #1	
30	Knock Sensor #1 (Cyl. #1, 3, 5) ground	Knock Sensor (KS) #1	0
31	Knock Sensor #2 (Cyl. #2, 4, 6) signal input	Knock Sensor (KS) #2	
32	Knock Sensor #2 (Cyl. #2, 4, 6) signal input	Knock Sensor (KS) #2	
33	Injector (Cyl. 1) control output	Injector (Cyl. 1)	
34	Injector (Cyl. 2) control output	Injector (Cyl. 2)	
35	Injector (Cyl. 3) control output	Injector (Cyl. 3)	
36	Injector (Cyl. 4) control output	Injector (Cyl. 4)	
37	Injector (Cyl. 5) control output	Injector (Cyl. 5)	
38	Injector (Cyl. 6) control output	Injector (Cyl. 6)	
39	Not connected		
40	Not connected		
41	Not connected		
42	Purge Control Solenoid Valve PWM output	Purge Control Solenoid Valve (PCSV)	
43	Not connected		
44	Not connected		
45	Not connected		

## FUEL SYSTEM (G6BA-GSL 2.7)

Pin No.	Description	Connected to	Remark
46	Idle Speed Control Actuator PWM output 2 (OPEN)	Idle Speed Control Actuator (ISCA)	
47	Idle Speed Control Actuator PWM output 1 (CLOSE)	Idle Speed Control Actuator (ISCA)	
48	Knock Sensor Shield	Knock Sensor (KS)	
49	Not connected		
50	Not connected		
51	Not connected		
52	Not connected		

#### CONNECTOR [C133-4]

Pin No.	Description	Connected to	Remark
1	Not connected		
2	Not connected		
3	Not connected		
4	Not connected		
5	Not connected		
6	Not connected		
رمورد)	Camshaft Position Sensor signal input	Camshaft Position Sensor (CMPS)	
8	Camshaft Position Sensor ground	Camshaft Position Sensor (CMPS)	
9 اير 9	Not connected	اولین سامانه دی	
10	Fuel Pump Relay control output	Fuel Pump Relay	
11	Not connected		
12	Not connected		
13	Throttle Position PWM output	Other control modules	
14	Not connected		
15	Not connected		
16	Not connected		
17	Engine Speed signal output	Tachometer	
18	Cooling Fan Relay [Low] control output	Cooling Fan Relay	
19	Not connected		
20	Malfunction Indicating Lamp (MIL) output	Malfunction Indicating Lamp (MIL)	
21	Not connected		
22	Vehicle speed signal input	Vehicle Speed Sensor (VSS)	- EURO-II - LEAD
	venicie speed signal input	ABS Control Module	- EURO-III/IV With ABS - JAPAN With ABS

FLB -27

Pin No.	Description	Connected to	Remark
23	Air conditioner switch [Low/High] signal input	Triple Switch	
24	Air conditioner switch signal input	Air Conditioner Switch	
25	Air conditioner switch [Middle] signal input	Triple Switch	
26	Not connected		
27	Not connected		
28	Not connected		
29	Air Conditioner Compressor Relay control output	Air Conditioner Compressor Relay	
30	Not connected		
31	Not connected		
32	Not connected		
33	Not connected		
34	Not connected		
35	Not connected		
36	CAN [HIGH]	Other control modules (TCM, ABS, etc.)	9
37	CAN [LOW]	Other control modules (TCM, ABS, etc.)	
38	Wheel Speed Sensor (WSS) ground	Wheel Speed Sensor (WSS)	- EURO-III/IV without
39	Wheel Speed Sensor (WSS) signal input	Wheel Speed Sensor (WSS)	ABS - JAPAN Witho <mark>ut AB</mark> S
40	Cooling Fan Relay [High] control output	Cooling Fan Relay	

#### CONNECTOR [C133-5]

Pin No.	Description	Connected to	Remark
1	Ignition coil #3 (Cyl. #3,6) control output	Ignition coil #3 (Cyl. #3,6)	
2	Ignition coil #2 (Cyl. #2,5) control output	Ignition coil #2 (Cyl. #2,5)	
3	Ignition coil #1 (Cyl. #1,4) control output	Ignition coil #1 (Cyl. #1,4)	
4	Not connected		
5	Ignition Coil shield	Ignition Coil and Chassis ground	
6	Not connected		
7	Not connected		
8	Not connected		
9	Not connected		

## FUEL SYSTEM (G6BA-GSL 2.7)

## FLB -28

#### 3. ECM TERMINAL INPUT/OUTPUT SIGNAL

#### CONNECTOR [C133-1]

Pin	Description	Type	Vehicle State	Level	Test Result	
1	Ignition switch signal input	DC	IG ON	Vbatt	14.19V	
			IG OFF	0~0.5V	0mV	
2	Not connected					
3	Diagnostic Data Line (k-Line)	Pulse	When communicating	Vbatt 0 ~ 0.5 V BFGE501N	High: 13.69V Low: 307mV Speed:10.365kbps	
4	ECM ground	Static Signal	Always	0~0.5V		
5	Power stage ground	Static Signal	Always	0~0.5V		
6	Power stage ground	Static Signal	Always	0~0.5V		
7	Battery voltage supply	DC	Always	Vbatt	13.37V	
8	Battery Voltage Supply after	DC	IG ON	Vbatt	14.15V	
	Main Relay		IG OFF	0~0.5V	0mV	
9	Battery Voltage Supply after	DC	IG ON	Vbatt	14.17V	
(20	Main Relay		IG OFF	0~0.5V	0V	

## اولین سامانه دیجیتال تعمیرکاران -[CONNECTOR [C133-2]

Pin	Description	Type	Vehicle State	Level	Test Result
1	Heated Oxygen Sensor Heater (B1/S1) control	PWM	Engine Run	Vbatt 0 ~ 0.5 V  BFGE501N  Freq.: 10Hz	14.24V 400mV 10.0Hz
2	Not connected				
3	Not connected				
4	Not connected				
5	Not connected				
6	Not connected				
7	Heated Oxygen Sensor (B1/S2) Heater control	PWM	Engine Run	Whatt  O ~ 0.5 V  BFGE501N  Freq.: 10Hz	14.19V 400mV 10.0Hz
8	Not connected				
9	Not connected				
10	Not connected				
11	Not connected				

Pin	Description	Туре	Vehicle State	Level	Test Result
12	Not connected				
13	Heated Oxygen Sensor (B2/S1) Heater control	PWM	Engine Run	→ Vbatt → 0~0.5 V BFGE501N Freq.: 10Hz	14.24V 400mV 10.0Hz
14	Heated Oxygen Sensor (B1/S1) signal input	Pulse	3000 rpm after warm up	0.8 V 0.1 V BFGE501R Freq. : 1.1 Hz	0.8V 100mV 1.33Hz
15	Heated Oxygen Sensor (B2/S1) signal input	Pulse	3000 rpm after warm up	0.8V 0.1V BFGE501R Freq. : 1.1Hz	0.8V 100mV 1.09Hz
16	Heated Oxygen Sensor (B1/S2) signal input	Pulse	Racing	0.8 V 0.1 V BFGE501R Freq. : 1.1 Hz	0.8V 100mV -Hz
17	Fuel Consumption signal output	ال حودرر	ردت دیجیت	m 0-	
18	Heated Oxygen Sensor (B2/S2) signal input	Pulse Racing		0.8 V 0.1 V BFGE501R Freq. : 1.1 Hz	
19	Heated Oxygen Sensor (B2/S2) Heater control	PWM	Engine Run	Vbatt 0~0.5 V BFGE501N Freq. : 10Hz	14.01V 400mV 10.0Hz
20	Heated Oxygen Sensor (B1/S1) ground	Static Signal	3000 rpm after Warm up	0~0.4V	0V
21	Heated Oxygen Sensor (B2/S1) ground	Static Signal	3000 rpm after Warm up	0~0.4V	0V
22	Heated Oxygen Sensor (B1/S2) ground	Static Signal	3000 rpm after Warm up	0~0.4V	0V
23	Main Relay control output	DC	IG ON	0~1V	903mV
			IG OFF	Vbatt	13.47V
24	Heated Oxygen Sensor (B2/S2) ground	Static Signal	3000 rpm after Warm up	0~0.4V	0V

## FUEL SYSTEM (G6BA-GSL 2.7)

#### CONNECTOR [C133-3]

Pin	Description	Туре	Vehicle State	Level	Test Result
1	Mass Air Flow Sensor signal input	Analog	Idle	0.6~1.0V	663mV
			2000 rpm	1.3~1.5V	1.54V
			3000 rpm	1.7~1.9V	
2	Not connected				
3	Not connected				
4	Not connected				
5	Not connected				
6	Not connected				
7	Not connected				
8	Crankshaft Position Sensor signal input	Pulse			
			Idle	600~900Hz	705.94Hz
-			3000 rpm	2.7~3.3kHz	3,028Hz
9	Not connected				0
10	Throttle Position Sensor supply	DC	After IG ON	Vcc	5.02V
11	Not connected	•••	• ••	. •	
12	Not connected	ن خودرو	کت دیجیتا	ش شا	
13	Not connected				
14	Not connected	يجيتال ن	لین سامانه د	gl	
15	Not connected				
16	Not connected				
17	Mass Air Flow Sensor ground	GND		0~0.5V	6.1mV
18	Not connected				
19	Throttle Position Sensor	Analog	Idle	0.2~0.8V	304mV
	signal input		W.O.T	4.3~4.8V	4.16V
20	Throttle Position Sensor ground	GND		0~0.5V	5.2mV
21	Crankshaft Position Sensor ground	GND		0~0.5V	5.2mV
22	Intake Air Temperature Sensor	Analog	-20°C (-4°F)	4.27~4.54 V	
	signal input		0°C (32°F)	3.54~3.9 V	
			20°C (68°F)	2.63~2.93 V	
			40°C (104°F)	1.73~1.98 V	
			60°C (140°F)	1.08~1.25 V	
			80°C (176°F)	0.65~0.76 V	
23	Intake Air Temperature Sensor ground	GND		0~0.5V	3.4mV

Pin	Description	Туре	Vehicle State	Level	Test Result
24	Engine Coolant Temperature	Analog	COLD(20 )	3.44V	
	Sensor signal input	warm(80 )		1.25V	
25	Engine Coolant Temperature Sensor ground	GND		0~0.5V	4.7mV
26	Power Steering Load input	DC	Active	0~0.5V	-26mV
			Inactive	Vbatt	11.55V
27	Not connected				
28	Not connected				
29	Knock Sensor #1 (Cyl. #1,	Fre-	Knocking	-0.3 ~ 0.3V	224mV
	3, 5) signal input	quency	Normal	0V	0mV
30	Knock Sensor #1 (Cyl. #1, 3, 5) ground				
31	Knock Sensor #2 (Cyl. #2,	Fre-	Knocking	-0.3 ~ 0.3V	247mV
	4, 6) signal input	quency	Normal	0V	0mV
32	Knock Sensor #2 (Cyl. #2, 4, 6) ground				
33	Injector (Cyl. 1) control output				
34	Injector (Cyl. 2) control output	•			Lliab. 14 01V
35	Injector (Cyl. 3) control output		2000	Vbatt	High: 14.01V Low: 185mV
36	Injector (Cyl. 4) control output	DC(PWM)	3000rpm	~	Idle: 5.86Hz
37	Injector (Cyl. 5) control output	: 11"	ا ولين سامانه	BFGE5010 (20 ~ 30Hz)	3000rpm: 25.04Hz
38	Injector (Cyl. 6) control output	، <i>يجيب</i> ال،	اوىين سامانه ا	(20 ~ 30H2)	
39	Not connected				
40	Not connected				
41	Not connected				
42	Purge Control Solenoid Valve PWM output	Pulse PWM	Inactive	Vbatt	
			Active (After warm up & racing)	BFGE501P Freq.: 20Hz	
43	Not connected				
44	Not connected				
45	Not connected				
46	Idle Speed Control Actuator PWM output 2 (OPEN)	PWM	Idle	BFGE501S Freq: 100Hz	High: 15.05V Low: 178mV Freq:100.0Hz

## FUEL SYSTEM (G6BA-GSL 2.7)

Pin	Description	Type	Vehicle State	Level	Test Result
47	Idle Speed Control Actuator PWM output 1 (CLOSE)	PWM	ldle	Below 0.5 V  BFGE501S  Freq: 100Hz	High: 14.82V Low: 151mV Freq:100.0Hz
48	Knock Sensor Shield	GND		0~0.5V	
49	Not connected				
50	Not connected				
51	Not connected				
52	Not connected				

#### CONNECTOR [C133-4]

Pin	Description	Туре	Vehicle State	Level	Test Result
1	Not connected				
2	Not connected				
3	Not connected				
4	Not connected				0
5	Not connected				
6	Not connected	00	• ••		
(7)9	Camshaft Position Sensor signal input	Fre-	کت دیجیتا لین سامانه د	4.5~5.5 V 0 ~ 0.5 V BFGE501T	High: 5.02V Low: 529mV
(	نعمیرکاران خودرو در ایرار	quency	Idle	5.25~7.25Hz	Idle: 5.84Hz
			3000rpm	20~30Hz	3000rpm: 25.14Hz
8	Camshaft Position Sensor ground	GND	0000.p	0~0.5V	
9	Not connected				
10	Fuel Pump Relay control output	DC	IG ON	Vbatt	13.08V
			Idle	0~0.5V	93mV
11	Not connected				
12	Not connected				
13	Throttle Position PWM output	Pulse		BFGE501S  Freq.: 100Hz	High: 12.72V Low: 88mV Freq:100.0Hz
			C.T	5% DUTY	C.T:4.92%
			W.O.T	91% DUTY	WOT:90.92%
14	Not connected				
15	Not connected				
16	Not connected				

Pin	Description	Туре	Vehicle State	Level	Test Result
17	17 Engine Speed signal output			Wellow 0.5 V  BFGE501S	High: 10.35V Low: 13.6mV
			Idle	40Hz	Idle: 35.25Hz
			3000 rpm	150Hz	3000rpm: 151.25Hz
18	Cooling Fan Relay [Low]	DC	FAN ON	0~0.5V	497mV
	control output		FAN OFF	Vbatt	13.95V
19	Not connected				
20	Malfunction Indicating Lamp	DC	MIL ON	0~0.5V	16.4mV
	(MIL) output		MIL OFF	Vbatt	13.54V
21	Not connected				
22	Vehicle speed signal input	Pulse	Vehicle Run(80km/h)	Below 0.5 V	High: 5.02V Low: 0.92mV
		<b>= 00</b>	(	From ABS: 250Hz	252Hz
				From VSS: 25Hz	0
23	Air conditioner switch [Low/High]	DC	S/W OFF	0~0.5V	0.02V
	signal input	••	S/W ON	Vbatt	12.22V
24	Air conditioner switch signal input	ال عودر	S/W OFF	0~0.5V	0mV
			S/W ON	Vbatt	12.45V
25	Air conditioner switch [Middle]	DC	S/W OFF	0~0.5V	0mV
	signal input		S/W ON	Vbatt	12.22V
26	Not connected				
27	Not connected				
28	Not connected				
29	Air Conditioner Compressor	DC	Relay ON	0~0.5V	118mV
	Relay control output		Relay OFF	Vbatt	13.7V
30	Not connected				
31	Not connected				
32	Not connected				
33	Not connected				
34	Not connected				
35	Not connected				
36	CAN [HIGH]	DC	Recessive	2.0~3.0V	2.51V
		(256kbps)	Dominant	2.75~4.5V	3.56V
37	CAN [LOW]	DC	Recessive	2.0~3.0V	2.52V
		(256kbps)	Dominant	0.5~2.25V	1.51V
38	Wheel Speed Sensor (WSS) ground	GND		0V	

## FUEL SYSTEM (G6BA-GSL 2.7)

Pin	Description	Type	Vehicle State	Level	Test Result
39	Wheel Speed Sensor (WSS) signal input		Run Vehicle		
40	Cooling Fan Relay [High]	DC	Relay ON	0V	543mV
	control output		Relay OFF	Vbatt	13.98V

#### CONNECTOR [C133-5]

Pin	Description	Туре	Vehicle State	Level	Test Result
1	Ignition coil #3 (Cyl. #3,6) control output	Pulse	Engine Run	Above 350 V  Vbatt  Below 1.6 V  BFGE501M	High: 14.03V Low: 0.78V~1.13V Peak Voltage: 348V Idle: 11.70Hz 3000rpm: 50.22Hz
2	Ignition coil #2 (Cyl. #2,5) control output	Pulse	Engine Run	Above 350 V  Vbatt  Below 1.6 V  BFGE501M	High: 13.98V Low: 0.77V~1.13V Peak Voltage: 352V Idle: 11.79Hz 3000rpm: 50.54Hz
3	Ignition coil #1 (Cyl. #1,4) control output	Pulse	Engine Run	Above 350 V  Vbatt  Below 1.6 V  BFGE501M	High: 14.07V Low: 0.77V~1.09V Peak Voltage: 352V Idle: 11.88Hz 3000rpm: 49.82Hz
4	Not connected				
5	Ignition Coil shield	GND		0V	-0.2mV
6	Not connected				
7	Not connected				
8	Not connected				
9	Not connected				

**FLB** -35

# PROCEDURE EEBCCADS

 TEST ECM GROUND CIRCUIT: Measure resistance between ECM and chassis ground using the backside of ECM harness connector as ECM side check point. If the problem is found, repair it.

Specification (Resistance): 1 or less

- TEST ECM CONNECTOR: Disconnect the ECM connector and visually check the ground terminals on ECM side and harness side for bent pins or poor contact contact pressure. If the problem is found, repair it.
- If problem is not found in Step 1 and 2, the ECM could be faulty. If so, replace the ECM with a new one, and then check the vehicle again. If the vehicle operates normally then the problem was likely with the ECM.
- 4. RE-TEST THE ORIGINAL ECM: Install the original ECM (may be broken) into a known-good vehicle and check the vehicle. If the problem occurs again, replace the original ECM with a new one. If problem does not occur, this is intermittent problem (Refer to INTERMITTENT PROBLEM PROCEDURE in BASIC INSPECTION PROCEDURE).





# DTC TROUBLESHOOTING PROCEDURES

# INSPECTION CHART FOR DIAGNOSTIC TROUBLE CODES (DTC) ECA1FF81

			M	IL		
DTC	DESCRIPTION	EURO -III/IV	EURO -II	LEADED	JAPAN	PAGE
P0031	HO2S Heater Circuit low (Bank 1 / Sensor 1)					FLB - 40
P0032	HO2S Heater Circuit high (Bank 1 / Sensor 1)					FLB - 44
P0037	HO2S Heater Circuit low (Bank 1 / Sensor 2)					FLB - 47
P0038	HO2S Heater Circuit high (Bank 1 / Sensor 2)					FLB - 51
P0051	HO2S Heater Circuit low (Bank 2 / Sensor 1)					FLB - 54
P0052	HO2S Heater Circuit high (Bank 2 / Sensor 1)					FLB - 58
P0057	HO2S Heater Circuit low (Bank 2 / Sensor 2)					FLB - 61
P0058	HO2S Heater Circuit high (Bank 2 / Sensor 2)				0	FLB - 65
P0101	Mass or Volume Air Flow Circuit Range/Performance		0		J	FLB - 68
P0102	Mass or Volume Air Flow Circuit Low Input	کت دیج	شر	0-	T	FLB - 73
P0103	Mass or Volume Air Flow Circuit high Input					FLB - 76
P0112	Intake Air Temperature Circuit Low Input	لین سام	91	0		FLB - 79
P0113	Intake Air Temperature Circuit High Input					FLB - 83
P0116	Engine Coolant Temperature Circuit Range/Performance					FLB - 86
P0117	Engine Coolant Temperature Circuit Low Input					FLB - 90
P0118	Engine Coolant Temperature Circuit High Input					FLB - 93
P0121	Throttle/Pedal Position Sensor/Switch "A" Circuit Range/Performance					FLB - 96
P0122	Throttle/Pedal Position Sensor/Switch "A" Circuit Low Input					FLB - 100
P0123	Throttle/Pedal Position Sensor/Switch "A" Circuit High Input					FLB - 103
P0130	HO2S Circuit (Bank 1/ Sensor 1)					FLB - 106
P0131	HO2S Circuit Low Voltage (Bank 1 / Sensor 1)					FLB - 109
P0132	HO2S Circuit High Voltage (Bank 1 / Sensor 1)					FLB - 111
P0133	HO2S Circuit Slow Response (Bank 1 / Sensor 1)					FLB - 113
P0136	HO2S Circuit (Bank 1/ Sensor 2)					FLB - 115

FLB -37

		MIL				
DTC	DESCRIPTION	EURO -III/IV	EURO -II	LEADED	JAPAN	PAGE
P0137	HO2S Circuit Low Voltage (Bank 1 / Sensor 2)					FLB - 118
P0138	HO2S Circuit High Voltage (Bank 1 / Sensor 2)					FLB - 120
P0150	HO2S Circuit (Bank 2/ Sensor 1)					FLB - 122
P0151	HO2S Circuit Low Voltage (Bank 2 / Sensor 1)					FLB - 125
P0152	HO2S Circuit High Voltage (Bank 2 / Sensor 1)					FLB - 127
P0153	HO2S Circuit Slow Response (Bank 2 / Sensor 1)					FLB - 129
P0156	HO2S Circuit (Bank 2 / Sensor 2)					FLB - 131
P0157	HO2S Circuit Low Voltage (Bank 2 / Sensor 2)					FLB - 134
P0158	HO2S Circuit High Voltage (Bank 2 / Sensor 2)					FLB - 136
P0171	System Too Lean (Bank 1)					FLB - 138
P0172	System Too Rich (Bank 1)					FLB - 142
P0174	System Too Lean (Bank 2)				0	FLB - 138
P0175	System Too Rich (Bank 2)	<u> </u>	0			FLB - 142
P0230	Fuel Pump Primary Circuit					FLB - 145
P0261	Cylinder 1-Injector Circuit Low			9		FLB - 149
P0262	Cylinder 1-Injector Circuit High	وليرن ساه				FLB - 154
P0264	Cylinder 2-Injector Circuit Low	<u> </u>		0		FLB - 149
P0265	Cylinder 2-Injector Circuit High					FLB - 154
P0267	Cylinder 3-Injector Circuit Low					FLB - 149
P0268	Cylinder 3-Injector Circuit High					FLB - 154
P0270	Cylinder 4-Injector Circuit Low					FLB - 149
P0271	Cylinder 4-Injector Circuit High					FLB - 154
P0273	Cylinder 5-Injector Circuit Low					FLB - 149
P0274	Cylinder 5-Injector Circuit High					FLB - 154
P0276	Cylinder 6-Injector Circuit Low					FLB - 149
P0277	Cylinder 6-Injector Circuit High					FLB - 154
P0300	Random/Multiple Cylinder Misfire Detected					FLB - 157
P0301	Cylinder 1-Misfire detected					FLB - 157
P0302	Cylinder 2-Misfire detected					FLB - 157
P0303	Cylinder 3-Misfire detected					FLB - 157
P0304	Cylinder 4-Misfire detected					FLB - 157
P0305	Cylinder 5-Misfire detected					FLB - 157

# FLB -38 FUEL SYSTEM (G6BA-GSL 2.7)

		MIL				
DTC	DESCRIPTION	EURO -III/IV	EURO -II	LEADED	JAPAN	PAGE
P0306	Cylinder 6-Misfire detected					FLB - 157
P0325	Knock Sensor 1 Circuit					FLB - 163
P0330	Knock Sensor 2 Circuit					FLB - 163
P0335	Crankshaft Position Sensor A Circuit					FLB - 168
P0340	Camshaft Position Sensor A Circuit Malfunction(Single Sensor)					FLB - 174
P0350	Ignition Coil Primary / Secondary Circuit					FLB - 179
P0351	Ignition Coil 'A' Primary / Secondary Circuit					FLB - 179
P0352	Ignition Coil 'B' Primary / Secondary Circuit					FLB - 179
P0353	Ignition Coil 'C' Primary / Secondary Circuit					FLB - 179
P0354	Ignition Coil 'D' Primary / Secondary Circuit					FLB - 179
P0355	Ignition Coil 'E' Primary / Secondary Circuit					FLB - 179
P0356	Ignition Coil 'F' Primary / Secondary Circuit				0	FLB - 179
P0420	Catalyst System Efficiency below Threshold (Bank 1)	7:-	0		J	FLB - 185
P0430	Catalyst System Efficiency below Threshold (Bank 2)	کت دیج	شر	0-		FLB - 185
P0444	Evap. Emission System-Purge Ctrl. Valve Circuit Open	لين سام	او			FLB - 188
P0445	Evap. Emission System-Purge Ctrl. Valve Circuit Shorted					FLB - 192
P0501	Vehicle Speed Sensor A Range/Performance					FLB - 195
P0506	Idle Air Control System-RPM lower than expected					FLB - 203
P0507	Idle Air Control System-RPM higher than expected					FLB - 208
P0551	Power Steering Pressure Sensor/Switch Circuit Range/Performance					FLB - 212
P0560	System Voltage					FLB - 215
P0605	Internal Control Module Read Only Memory(ROM) Error					FLB - 219
P0650	Malfunction Indicator Lamp(MIL) Control Circuit					FLB - 220
P1166	HO2S System - Lambda Controller at the Limit (Bank 1)					FLB - 223
P1167	HO2S System - Lambda Controller at the Limit (Bank 2)					FLB - 223
P1372	Segment Time Acquisition Incorrect					FLB - 226
P1505	Idle Charge Actuator Signal Low of Coil #1					FLB - 228

FLB -39

			N	IIL		
DTC	DESCRIPTION	EURO -III/IV	EURO -II	I FADED		PAGE
P1506	Idle Charge Actuator Signal High of Coil #1					FLB - 233
P1507	Idle Charge Actuator Signal Low of Coil #2					FLB - 236
P1508	Idle Charge Actuator Signal High of Coil #2					FLB - 239
P1529	TCM Request for MIL ON/Freeze Frame To ECM via CAN					FLB - 242
P1602	CAN Communication BUS with TCM (Timeout)					FLB - 243
P1642	Non-Immobilizer-EMS connected to an Immobilizer					-

# **NOTE**

: MIL ON & FAULT CODE MEMORY

: MIL OFF & FAULT CODE MEMORY



اولین رسامانه دیچیتال تعمیرکاران خودرو در ایران




# **FUEL SYSTEM (G6BA-GSL 2.7)**

# TROUBLESHOOTING FOR DTC EDS

DTC	P0031	HO2S Heater Circuit Low (Bank 1 / Sensor 1)
-----	-------	---

#### **COMPONENT LOCATION**



EZOF505E

# **DESCRIPTION**

In order to control the emission of the CO, HC and NOx components of the exhaust gas, a heated oxygen sensor (HO2S), mounted on the front side and rear side of the catalytic converter, detects the oxygen content in the exhaust gas. The front HO2S signal is used to control air/fuel ratio (closed loop fuel control) and the rear HO2S signal is used to monitor front HO2S and catalyst for proper operation. The HO2S requires a minimum temperature to operate properly and provide a closed loop fuel control system. So the HO2S contains a heater element to reduce warm-up time and ensure proper performance during all driving conditions, which allows for closed loop fuel control or catalyst monitoring immediately upon engine start-up. The ECM controls this heater element by duty cycle. The main relay supplies voltage to the heater and the ECM provides a ground circuit for activating the heater.

# DTC DETECTING CONDITION

1. DTC Description

ECM sets DTC P0031 if the ECM detects that the HO2S(B1/S1) heater control line is short to ground or broken.

2. Conditions for Setting the DTC


DTC	Detecting Condition & Limp Home	Possible Cause
P0031	Detecting Condition  • DTC Strategy  - Driver Stage Check  • Enable condition  - Battery Voltage > 10V  - 1% < HO2S heater duty < 99%	<ul> <li>Open or short to ground in HO2S(B1/S1) heater circuit</li> <li>HO2S(B1/S1) heater</li> <li>ECM</li> </ul>

# **SPECIFICATION**

• HO2S Heater Resistance: 3.0~4.0 at 23±5°C


**FLB-41** 

#### **SCHEMATIC DIAGRAM**



EZOF401D

# ولین سامانه دیجیتال تعمیرکاران SIGNAL WAVE FORM



The HO2S requires a minimum temperature to provide a closed loop fuel control system. So HO2S contains a heater element to reduce its warming-up time and to ensure its performance during all driving conditions. The HO2S heater should be always ON after cold engine start. The ECM controls this heater element by duty cycle. The main relay supplies voltage to the heater and the ECM provides a ground circuit for activating the heater. The left illustration is the signal waveform of HO2S Heater and the right is the one of HO2 sensor.

# **INSPECTION PROCEDURE**

#### 1. PROBLEM VERIFICATION

- 1. Connect a Hi-Scan (Pro) to the data link connector.
- 2. Start engine and warm up the vehicle until the cooling operates.

# Does scan tool display DTC P0031?




No

Problem is intermittent or was repaired and ECM memory was not cleared. Refer to "INTERMITTENT PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

#### 2. CHECK HEATER RESISTANCE

- 1. Turn ignition switch to OFF position and disconnect HO2S connector.
- 2. Measure resistance between terminals 3 and 4 of the HO2S connector.
  - Specification (HO2S resistance): 3.0 ~ 4.0  $\Omega$  at 23  $\pm$  5  $^{\circ}$ C



Is resistance within specification?




No

Replace HO2S.

# 3. CHECK POWER TO HO2S HEATER TO HO2S HEATER

- 1. Turn ignition switch to OFF position and disconnect HO2S connector.
- 2. Turn ignition switch to ON position.
- 3. Measure voltage between terminal 3 of the HO2S harness connector and chassis ground.
  - Specification (Voltage): approximately B+



Is voltage within specification?



No


Repair open or short to chassis ground in harness.

EZOF601F

FLB -43

# 4. CHECK FOR OPEN IN HARNESS

- Turn ignition to OFF position, and then disconnect HO2S and ECM connector.
- 2. Measure resistance between terminal 4 of the HO2S harness connector and 1 of the ECM harness connector(C133-2).
  - Specification (Resistance): below  $1\Omega$




Does the resistance indicate continuity?



No Repair open in harness.

# 5. CHECK FOR SHORT TO GROUND IN HARNESS

- 1. Turn ignition switch to OFF position, and then disconnect HO2S and ECM connector.
- 2. Measure resistance between terminal 4 of the HO2S harness connector and chassis ground.
  - Specification (Resistance): infinite



Does the resistance indicate open?



No Po

Repair short or short to chassis ground in harness.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

EZOF601G

# FLB -44

# **FUEL SYSTEM (G6BA-GSL 2.7)**

# TROUBLESHOOTING FOR DTC EEAF7DAC

DTC	P0032	HO2S Heater Circuit High (Bank 1 / Sensor 1)
-----	-------	--

# **DESCRIPTION**

Refer to DTC P0031

#### DTC DETECTING CONDITION

1. DTC Description

ECM sets DTC P0032 if the ECM detects that the HO2S (B1/S1) heater control line is short to battery line.

2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause
P0032	Detecting Condition  • DTC Strategy  - Driver stage Check  • Enable condition  - Battery Voltage > 10V  - 1 % < HO2S heater duty < 99 %	<ul> <li>Short to battery line in HO2S (B1/S1) heater circuit</li> <li>HO2S (B1/S1) heater</li> <li>ECM</li> </ul>

# **SPECIFICATION**

Refer to DTC P0031

# SCHEMATIC DIAGRAM

Refer to DTC P0031

# SIGNAL WAVE FORM

Refer to DTC P0031

FLB -45

# **INSPECTION PROCEDURE**

#### 1. PROBLEM VERIFICATION

- 1. Connect a Hi-Scan (Pro) to the data link connector.
- 2. Start engine and warm up the vehicle until the cooling operates.

Does scan tool display DTC P0032?




No

Problem is intermittent or was repaired and ECM memory was not cleared. Refer to "INTERMITTENT PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

# 2. CHECK HEATER RESISTANCE

- 1. Turn ignition switch to OFF position and disconnect HO2S connector.
- 2. Measure resistance between terminals 3 and 4 of the HO2S connector.
  - Specification (HO2S resistance): 3.0 ~ 4.0  $\Omega$  at 23  $\pm$  5  $^{\circ}$ C



Is resistance within specification?




No

Replace HO2S.

# 3. CHECK POWER TO HO2S HEATER

- 1. Turn ignition switch to OFF position and disconnect HO2S connector.
- 2. Turn ignition switch to ON position.
- 3. Measure voltage between terminal 3 of the HO2S harness connector and chassis ground.
  - Specification (Voltage): approximately B+



Is voltage within specification?



No

Repair open or short to chassis ground in harness.


EZOF601H

# **FUEL SYSTEM (G6BA-GSL 2.7)**

# **FLB** -46

#### 4. CHECK FOR SHORT TO POWER IN HARNESS

- 1. Turn ignition switch to OFF position, and then disconnect HO2S and ECM connector.
- 2. Measure resistance between terminal 4 of the HO2S harness connector and chassis ground.
  - Specification (Voltage): below 0.5V



Is viltage within specification?



No

Repair short to power in harness.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

EZOF601I



شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




FLB -47

# TROUBLESHOOTING FOR DTC EFBCECEE

DTC	P0037	HO2S Heater Circuit Low (Bank 1 / Sensor 2)
-----	-------	---

#### **COMPONENT LOCATION**



EZOF5050

# **DESCRIPTION**

In order to control the emission of the CO, HC and NOx components of the exhaust gas, a heated oxygen sensor (HO2S), mounted on the front side and rear side of the catalytic converter, detects the oxygen content in the exhaust gas. The front HO2S signal is used to control air/fuel ratio (closed loop fuel control) and the rear HO2S signal is used to monitor front HO2S and catalyst for proper operation. The HO2S requires a minimum temperature to operate properly and provide a closed loop fuel control system. So the HO2S contains a heater element to reduce warm-up time and ensure proper performance during all driving conditions, which allows for closed loop fuel control or catalyst monitoring immediately upon engine start-up. The ECM controls this heater element by duty cycle. The main relay supplies voltage to the heater and the ECM provides a ground circuit for activating the heater.

# DTC DETECTING CONDITION

1. DTC Description

ECM sets DTC P0037 if the ECM detects that the HO2S(B1/S2) heater control line is short to ground or broken.

2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause
P0037	Detecting Condition  • DTC Strategy  - Driver stage check  • Enable condition  - Battery Voltage > 10V  - 1% < HO2S heater duty < 99%	<ul> <li>Open or short to ground in HO2S (B1/S2)</li> <li>HO2S (B1/S2) heater</li> <li>ECM</li> </ul>

# **SPECIFICATION**

HO2S Heater Resistance: 3.0~4.0 at 23±5°C

# **FUEL SYSTEM (G6BA-GSL 2.7)**

# **FLB** -48

# **SCHEMATIC DIAGRAM**

# [CIRCUIT DIAGRAM] HO2S (B1/S2) 3(4) 7 - HEATER CONTROL 1(2) 16 - HO2S SIGNAL 2(1) 22 - GND \*( ): EURO-II

# [CONNECTION INFORMATION]

#### EURO-III/IV (C147)

Terminal	Connected to	Function
1	ECM C133-2 (16)	HO2S(B1/S2) Signal
2	ECM C133-2 (22)	Ground
3	Main Relay	Battery Voltage
4	ECM C133-2 (7)	HO2S Heater (B1/S2)

#### EURO-II (C122)

Terminal	Connected to	Function
1	ECM C133-2 (22)	Ground
2	ECM C133-2 (16)	HO2S(B1/S2) Signal
3	ECM C133-2 (17)	HO2S Heater (B1/S2)
4	Main Relay	Battery Voltage

# [HARNESS CONNECTORS]

Main Relay



24 23 21 20 19 18 17 15 14 13 12 11 10 9 8 6 6 5 4 3 2 1


**C133-2** ECM

ولین سامانه دیجیتال تعمیرکاران خودرو در ایران

HO2S (B1/S2)

EZOF4010

#### SIGNAL WAVE FORM



The HO2S requires a minimum temperature to provide a closed loop fuel control system. So HO2S contains a heater element to reduce its warming-up time and ensure its performance during all driving conditions. The HO2S heater should be always ON after engine start. The ECM controls this heater element by duty cycle. The main relay supplies voltage to the heater and the ECM provides a ground circuit for activating the heater. The illustration is the signal waveform at idle.

EFOE0014

FLB -49

# **INSPECTION PROCEDURE**

#### 1. PROBLEM VERIFICATION

- 1. Connect a Hi-Scan (Pro) to the data link connector.
- 2. Start engine and warm up the vehicle until the cooling operates.

Does scan tool display DTC P0037?




No

Problem is intermittent or was repaired and ECM memory was not cleared. Refer to "INTERMITTENT PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

#### 2. CHECK HEATER RESISTANCE

- 1. Turn ignition switch to OFF position and disconnect HO2S connector.
- Measure resistance between terminals 3(4) and 4(3) of the HO2S connector.
  - Specification (HO2S resistance): 3.0 ~ 4.0  $\Omega$  at 23  $\pm$  5°C



Is resistance within specification?



No


Replace HO2S.

# 3. CHECK POWER TO HO2S HEATER

- 1. Turn ignition switch to OFF position and disconnect HO2S connector.
- 2. Turn ignition switch to ON position.

Is voltage within specification?

- 3. Measure voltage between terminal 3(4) of the HO2S harness connector and chassis ground.
  - Specification (Voltage): approximately B+



Yes

No


Repair open or short to chassis ground in harness.

EZOF601K

# **FUEL SYSTEM (G6BA-GSL 2.7)**

# 4. CHECK FOR OPEN IN HARNESS

- 1. Turn ignition to OFF position, and then disconnect HO2S and ECM connector.
- 2. Measure resistance between terminal 4(3) of the HO2S harness connector and 7 of the ECM harness connector (C133-2).
  - Specification (Resistance): below 1 $\Omega$



Does the resistance indicate continuity?



No Repair open in harness.

# 5. CHECK FOR SHORT TO GROUND IN HARNESS

- 1. Turn ignition switch to OFF position, and then disconnect HO2S and ECM connector.
- 2. Measure resistance between terminal 4(3) of the HO2S harness connector and chassis ground.
  - Specification (Resistance): infinite

PF HO2S

2(1) 1(2) 4(3) 3(4) B+ Ω

ECM

( ): EURO-II

Does the resistance indicate open?



No

Repair short or short to chassis ground in harness.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

EZOF601L

FLB -51

# TROUBLESHOOTING FOR DTC E6A8679F

DTC	P0038	HO2S Heater Circuit High (Bank 1 / Sensor 2)
-----	-------	--

# **DESCRIPTION**

Refer to DTC P0037

#### DTC DETECTING CONDITION

1. DTC Description

ECM sets DTC P0038 if the ECM detects that the HO2S (B1/S2) heater control line is short to battery line.

2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause
P0038	Detecting Condition  • DTC Strategy  - Driver stage check  • Enable condition  - Battery Voltage > 10V  - 1 % < HO2S heater duty < 99 %	<ul> <li>Short to battery line in HO2S (B1/S2) heater circuit</li> <li>HO2S (B1/S2) heater</li> <li>ECM</li> </ul>

# **SPECIFICATION**

Refer to DTC P0037

# **SCHEMATIC DIAGRAM**

Refer to DTC P0037

# SIGNAL WAVE FORM

Refer to DTC P0037

# **INSPECTION PROCEDURE**

#### 1. PROBLEM VERIFICATION

- 1. Connect a Hi-Scan (Pro) to the data link connector.
- 2. Start engine and warm up the vehicle until the cooling operates.

Does scan tool display DTC P0038?




No

Problem is intermittent or was repaired and ECM memory was not cleared. Refer to "INTERMITTENT PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

# 2. CHECK HEATER RESISTANCE

- 1. Turn ignition switch to OFF position and disconnect HO2S connector.
- 2. Measure resistance between terminals 3(4) and 4(3) of the HO2S connector.
  - Specification (HO2S resistance): 3.0 ~ 4.0  $\Omega$  at 23  $\pm$  5  $^{\circ}$ C



Is resistance within specification?

Yes

No


Replace HO2S.

# 3. CHECK POWER TO HO2S HEATER TO HO2S HEATER

- 1. Turn ignition switch to OFF position and disconnect HO2S connector.
- 2. Turn ignition switch to ON position.

Is voltage within specification?

- 3. Measure voltage between terminal 3(4) of the HO2S harness connector and chassis ground.
  - Specification (Voltage): approximately B+



Yes

No


Repair open or short to chassis ground in harness.

EZOF601M

FLB -53

# 4. CHECK FOR OPEN IN HARNESS

- 1. Turn ignition switch to OFF position, and then disconnect HO2S and ECM connector.
- 2. Measure resistance between terminal 4(3) of the HO2S harness connector and 7 of the ECM harness connector (C133-2).
  - Specification (Resistance): below 1Ω




Does the resistance indicate continuity?



No Repair open in harness.

# 5. CHECK FOR SHORT TO POWER IN HARNESS

- 1. Turn ignition switch to OFF position, and then disconnect HO2S and ECM connector.
- 2. Measure resistance between terminal 4(3) of the HO2S harness connector and chassis ground.
  - Specification (Voltage): below 0.5V



Is viltage within specification?



Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

EZOF601N


# FLB -54

# **FUEL SYSTEM (G6BA-GSL 2.7)**

# TROUBLESHOOTING FOR DTC E7

DTC	P0051	HO2S Heater Circuit Low (Bank 2 / Sensor 1)
-----	-------	---

#### **COMPONENT LOCATION**



EZOF6030

#### **DESCRIPTION**

In order to control the emission of the CO, HC and NOx components of the exhaust gas, a heated oxygen sensor (HO2S), mounted on the front side and rear side of the catalytic converter, detects the oxygen content in the exhaust gas. The front HO2S signal is used to control air/fuel ratio (closed loop fuel control) and the rear HO2S signal is used to monitor front HO2S and catalyst for proper operation. The HO2S requires a minimum temperature to operate properly and provide a closed loop fuel control system. So the HO2S contains a heater element to reduce warm-up time and ensure proper performance during all driving conditions, which allows for closed loop fuel control or catalyst monitoring immediately upon engine start-up. The ECM controls this heater element by duty cycle. The main relay supplies voltage to the heater and the ECM provides a ground circuit for activating the heater.

# DTC DETECTING CONDITION

1. DTC Description

ECM sets DTC P0051 if the ECM detects that the HO2S(B2/S1) heater control line is short to ground or broken.

2. Conditions for Setting the DTC


DTC	Detecting Condition & Limp Home	Possible Cause
P0051	Detecting Condition  • DTC Strategy  - Driver Stage Check  • Enable condition  - Battery Voltage > 10V  - 1% < HO2S heater duty < 99%	<ul> <li>Open or short to ground in HO2S(B2/S1) heater circuit</li> <li>HO2S(B2/S1) heater</li> <li>ECM</li> </ul>

# **SPECIFICATION**


• HO2S Heater Resistance: 3.0~4.0 at 23±5°C

**FLB** -55

# **SCHEMATIC DIAGRAM**



# ولین سامانه دیجیتال تعمیرکاران SIGNAL WAVE FORM



The HO2S requires a minimum temperature to provide a closed loop fuel control system. So HO2S contains a heater element to reduce its warming-up time and to ensure its performance during all driving conditions. The HO2S heater should be always ON after cold engine start. The ECM controls this heater element by duty cycle. The main relay supplies voltage to the heater and the ECM provides a ground circuit for activating the heater. The left illustration is the signal waveform of HO2S Heater and the right is the one of HO2 sensor.

# **INSPECTION PROCEDURE**

#### 1. PROBLEM VERIFICATION

- 1. Connect a Hi-Scan (Pro) to the data link connector.
- 2. Start engine and warm up the vehicle until the cooling operates.

Does scan tool display DTC P0051?




No

Problem is intermittent or was repaired and ECM memory was not cleared. Refer to "INTERMITTENT PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

#### 2. CHECK HEATER RESISTANCE

- 1. Turn ignition switch to OFF position and disconnect HO2S connector.
- 2. Measure resistance between terminals 3 and 4 of the HO2S connector.
  - Specification (HO2S resistance): 3.0 ~ 4.0  $\Omega$  at 23  $\pm$  5  $^{\circ}$ C



Is resistance within specification?




No

Replace HO2S.

# 3. CHECK POWER TO HO2S HEATER TO HO2S HEATER

- 1. Turn ignition switch to OFF position and disconnect HO2S connector.
- 2. Turn ignition switch to ON position.
- 3. Measure voltage between terminal 3 of the HO2S harness connector and chassis ground.
  - Specification (Voltage): approximately B+



Is voltage within specification?




No

Repair open or short to chassis ground in harness.

FLB -57

# 4. CHECK FOR OPEN IN HARNESS

- Turn ignition to OFF position, and then disconnect HO2S and ECM connector.
- 2. Measure resistance between terminal 4 of the HO2S harness connector and 13 of the ECM harness connector(C133-2).
  - Specification (Resistance): below  $1\Omega$




Does the resistance indicate continuity?



No Repair open in harness.

# 5. CHECK FOR SHORT TO GROUND IN HARNESS

- 1. Turn ignition switch to OFF position, and then disconnect HO2S and ECM connector.
- 2. Measure resistance between terminal 4 of the HO2S harness connector and chassis ground.
  - Specification (Resistance): infinite



Does the resistance indicate open?



No خودر

Repair short or short to chassis ground in harness.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

# FLB -58

# **FUEL SYSTEM (G6BA-GSL 2.7)**

# TROUBLESHOOTING FOR DTC EEF05CE3

DTC	P0052	HO2S Heater Circuit High (Bank 2 / Sensor 1)
-----	-------	--

# **DESCRIPTION**

Refer to DTC P0051

#### DTC DETECTING CONDITION

1. DTC Description

ECM sets DTC P0052 if the ECM detects that the HO2S (B2/S1) heater control line is short to battery line.

2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause
P0052	Detecting Condition  • DTC Strategy  - Driver stage Check  • Enable condition  - Battery Voltage > 10V  - 1 % < HO2S heater duty < 99 %	<ul> <li>Short to battery line in HO2S (B2/S1) heater circuit</li> <li>HO2S (B2/S1) heater</li> <li>ECM</li> </ul>

# **SPECIFICATION**

Refer to DTC P0051

# **SCHEMATIC DIAGRAM**

Refer to DTC P0051

# SIGNAL WAVE FORM

Refer to DTC P0051

FLB -59

# **INSPECTION PROCEDURE**

#### 1. PROBLEM VERIFICATION

- 1. Connect a Hi-Scan (Pro) to the data link connector.
- 2. Start engine and warm up the vehicle until the cooling operates.

Does scan tool display DTC P0052?




No

Problem is intermittent or was repaired and ECM memory was not cleared. Refer to "INTERMITTENT PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

# 2. CHECK HEATER RESISTANCE

- 1. Turn ignition switch to OFF position and disconnect HO2S connector.
- 2. Measure resistance between terminals 3 and 4 of the HO2S connector.
  - Specification (HO2S resistance): 3.0 ~ 4.0  $\Omega$  at 23  $\pm$  5  $^{\circ}$ C



Is resistance within specification?




No

Replace HO2S.

# 3. CHECK POWER TO HO2S HEATER

- 1. Turn ignition switch to OFF position and disconnect HO2S connector.
- 2. Turn ignition switch to ON position.
- 3. Measure voltage between terminal 3 of the HO2S harness connector and chassis ground.
  - Specification (Voltage): approximately B+



Is voltage within specification?



No


Repair open or short to chassis ground in harness.

# **FUEL SYSTEM (G6BA-GSL 2.7)**

# FLB -60

#### 4. CHECK FOR SHORT TO POWER IN HARNESS

- 1. Turn ignition switch to OFF position, and then disconnect HO2S and ECM connector.
- 2. Measure resistance between terminal 4 of the HO2S harness connector and chassis ground.
  - Specification (Voltage): below 0.5V



Is viltage within specification?



No

Repair short to power in harness.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

EZOF6034



شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




**FLB-61** 

#### TROUBLESHOOTING FOR DTC E48A3153

DTC
-----

#### **COMPONENT LOCATION**



EZOF6035

# **DESCRIPTION**

In order to control the emission of the CO, HC and NOx components of the exhaust gas, a heated oxygen sensor (HO2S), mounted on the front side and rear side of the catalytic converter, detects the oxygen content in the exhaust gas. The front HO2S signal is used to control air/fuel ratio (closed loop fuel control) and the rear HO2S signal is used to monitor front HO2S and catalyst for proper operation. The HO2S requires a minimum temperature to operate properly and provide a closed loop fuel control system. So the HO2S contains a heater element to reduce warm-up time and ensure proper performance during all driving conditions, which allows for closed loop fuel control or catalyst monitoring immediately upon engine start-up. The ECM controls this heater element by duty cycle. The main relay supplies voltage to the heater and the ECM provides a ground circuit for activating the heater.

# DTC DETECTING CONDITION

1. DTC Description

ECM sets DTC P0057 if the ECM detects that the HO2S(B2/S2) heater control line is short to ground or broken.


2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause
P0057	Detecting Condition  • DTC Strategy  - Driver stage check  • Enable condition  - Battery Voltage > 10V  - 1% < HO2S heater duty < 99%	<ul> <li>Open or short to ground in HO2S (B2/S2)</li> <li>HO2S (B2/S2) heater</li> <li>ECM</li> </ul>

# **SPECIFICATION**

• HO2S Heater Resistance: 3.0~4.0 at 23±5°C

# **SCHEMATIC DIAGRAM**



# [CONNECTION INFORMATION]

Terminal	Connected to	ected to Function	
1	ECM C133-2 (18)	HO2S(B2/S2) Signal	
2	ECM C133-2 (24)	Ground	
3	Main Relay	Battery Voltage	
4	ECM C133-2 (19)	HO2S Heater (B2/S2)	

[HARNESS CONNECTORS]






ECM

EZOF4410

#### SIGNAL WAVE FORM



The HO2S requires a minimum temperature to provide a closed loop fuel control system. So HO2S contains a heater element to reduce its warming-up time and ensure its performance during all driving conditions. The HO2S heater should be always ON after engine start. The ECM controls this heater element by duty cycle. The main relay supplies voltage to the heater and the ECM provides a ground circuit for activating the heater. The illustration is the signal waveform at idle.

EFOE0014

**FLB-63** 

# **INSPECTION PROCEDURE**

#### 1. PROBLEM VERIFICATION

- 1. Connect a Hi-Scan (Pro) to the data link connector.
- 2. Start engine and warm up the vehicle until the cooling operates.

Does scan tool display DTC P0057?




No

Problem is intermittent or was repaired and ECM memory was not cleared. Refer to "INTERMITTENT PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

#### 2. CHECK HEATER RESISTANCE

- 1. Turn ignition switch to OFF position and disconnect HO2S connector.
- 2. Measure resistance between terminals 3 and 4 of the HO2S connector.
  - Specification (HO2S resistance): 3.0 ~ 4.0  $\Omega$  at 23  $\pm$  5°C



Is resistance within specification?




No

Replace HO2S.

# 3. CHECK POWER TO HO2S HEATER AND A JUNE 1997

- 1. Turn ignition switch to OFF position and disconnect HO2S connector.
- 2. Turn ignition switch to ON position.
- 3. Measure voltage between terminal 3 of the HO2S harness connector and chassis ground.
  - Specification (Voltage): approximately B+



#### Is voltage within specification?



No


Repair open or short to chassis ground in harness.

# **FUEL SYSTEM (G6BA-GSL 2.7)**

# **FLB-64**

# 4. CHECK FOR OPEN IN HARNESS

- 1. Turn ignition to OFF position, and then disconnect HO2S and ECM connector.
- 2. Measure resistance between terminal 4 of the HO2S harness connector and 19 of the ECM harness connector (C133-2).
  - Specification (Resistance): below 1 $\Omega$



Does the resistance indicate continuity?



No Repair open in harness.

# 5. CHECK FOR SHORT TO GROUND IN HARNESS

- 1. Turn ignition switch to OFF position, and then disconnect HO2S and ECM connector.
- 2. Measure resistance between terminal 4 of the HO2S harness connector and chassis ground.
  - Specification (Resistance): infinite

PF HO2S

2 1 4 3 B+ Ω

24 18 19

ECM

( ): EURO-II

Does the resistance indicate open?



No

Repair short or short to chassis ground in harness.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

FLB -65

# TROUBLESHOOTING FOR DTC E45EB5D5

DTC	P0058	HO2S Heater Circuit High (Bank 2 / Sensor 2)
-----	-------	--

# **DESCRIPTION**

Refer to DTC P0057

#### DTC DETECTING CONDITION

1. DTC Description

ECM sets DTC P0058 if the ECM detects that the HO2S (B2/S2) heater control line is short to battery line.

2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause
P0058	Detecting Condition  • DTC Strategy  - Driver stage check  • Enable condition  - Battery Voltage > 10V  - 1 % < HO2S heater duty < 99 %	<ul> <li>Short to battery line in HO2S (B2/S2) heater circuit</li> <li>HO2S (B2/S2) heater</li> <li>ECM</li> </ul>

# **SPECIFICATION**

Refer to DTC P0057

# **SCHEMATIC DIAGRAM**

Refer to DTC P0057

# SIGNAL WAVE FORM

Refer to DTC P0057

# **INSPECTION PROCEDURE**

#### 1. PROBLEM VERIFICATION

- 1. Connect a Hi-Scan (Pro) to the data link connector.
- 2. Start engine and warm up the vehicle until the cooling operates.

Does scan tool display DTC P0058?




No

Problem is intermittent or was repaired and ECM memory was not cleared. Refer to "INTERMITTENT PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

# 2. CHECK HEATER RESISTANCE

- 1. Turn ignition switch to OFF position and disconnect HO2S connector.
- 2. Measure resistance between terminals 3 and 4 of the HO2S connector.
  - Specification (HO2S resistance): 3.0 ~ 4.0  $\Omega$  at 23  $\pm$  5°C



Is resistance within specification?




No

Replace HO2S.

# 3. CHECK POWER TO HO2S HEATER TO A SIGNAL OF THE SECOND SE

- 1. Turn ignition switch to OFF position and disconnect HO2S connector.
- 2. Turn ignition switch to ON position.
- 3. Measure voltage between terminal 3 of the HO2S harness connector and chassis ground.
  - Specification (Voltage): approximately B+



Is voltage within specification?

Yes


No

Repair open or short to chassis ground in harness.

**FLB-67** 

# 4. CHECK FOR OPEN IN HARNESS

- 1. Turn ignition switch to OFF position, and then disconnect HO2S and ECM connector.
- 2. Measure resistance between terminal 4 of the HO2S harness connector and 19 of the ECM harness connector (C133-2).
  - Specification (Resistance): below 1Ω




Does the resistance indicate continuity?



No Repair open in harness.

# 5. CHECK FOR SHORT TO POWER IN HARNESS

- 1. Turn ignition switch to OFF position, and then disconnect HO2S and ECM connector.
- 2. Measure resistance between terminal 4 of the HO2S harness connector and chassis ground.
  - Specification (Voltage): below 0.5V



Is viltage within specification?



No

Repair short to power in harness.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.


# **FUEL SYSTEM (G6BA-GSL 2.7)**

# **FLB** -68

# TROUBLESHOOTING FOR DTC

DTC	P0101	Mass or Volume Air Flow Circuit Range/Performance
-----	-------	---


#### **COMPONENT LOCATION**



EZOF505G

#### **DESCRIPTION**

The Mass Air Flow Sensor (MAFS) is located between the air cleaner assembly and the throttle body. The MAFS uses a hot film type sensing element to measure the mass of intake air entering the engine. This hot film type air flow sensor consists of a hot film sensor, housing and metering ducts. Mass air flow rate is measured by detection of heat transfer from a hot film probe. The change in air flow rate causes change in the amount of heat being transferred from the hot film probe surface to the air. A large amount of intake air represents acceleration or high load conditions while a small amount of intake air represents deceleration or idle. The mass of intake air should increase at acceleration and be stable during constant engine speed. The ECM uses this information to determine the injection duration and ignition timing for the desired air/fuel ratio.



BFGE505H

**FLB-69** 

# DTC DETECTING CONDITION

# 1. DTC Description

The ECM compares the actual measured Mass Air Flow signal to the modeled Mass Air Flow value and sets the DTC P0101 when the difference between these two value is too high or too low with lambda deviation in opposite direction. The ECM illuminates the MIL on the second consecutive driving cycle that the diagnostic runs and fails. The modeled Mass Air Flow value is determined by engine speed, throttle angle and ISCA duty.


# 2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause
	Detecting Condition  • DTC Strategy  - Compare calculated MAF with MAFS signal	
P0101	<ul> <li>Enable condition</li> <li>1,500 &lt; Engine speed &lt; 3,500 rpm</li> <li>150 &lt; Measured mass air flow &lt; 350 mg/stroke</li> <li>Engine coolant temperature &gt; 60°C(140°F)</li> </ul>	<ul><li>MAFS</li><li>TPS</li><li>Air cleaner</li><li>ECM</li></ul>
	<ul> <li>Threshold Value</li> <li>(Measured MAF) / (Calculated MAF) &gt; 1.3 or &lt; 0.5</li> <li>and lambda controller limit for 110 seconds</li> </ul>	0


#### **SPECIFICATION**

Test Condition	MAFS DATA	
	Output Voltage (V)	Mass Air Flow (kg/h)
تعمیرکاران خ <sub>افا</sub> ه رو در ایران	وليــــــــــــــــــــــــــــــــــــ	11.66 ~ 15.38
2000 rpm	1.3 ~ 1.5	28.41 ~ 35.58
3000 rpm	1.7 ~ 1.9	43.84 ~ 53.38

# SCHEMATIC DIAGRAM



#### SIGNAL WAVE FORM



As much as possible, MAFS signal should be compared with the TPS signal. And check whether MAFS and TPS signals are increased at the same time when accelerating. During acceleration, the MAFS output voltage increases; during deceleration, the MAFS output voltage decreases. The left illustration is signal waveform at idle and the right illustration during acceleration and deceleration.

**FLB-71** 

#### INSPECTION PROCEDURE

#### 1. CHECK DTC RELATING TO MAFS/TPS

- 1. Connect a Hi-Scan (Pro) to the data link connector.
- 2. Turn ignition switch to ON position and monitor other DTCs.

Is any DTC relating to MAFS or TPS set?



Yes

Do all repairs associated with those codes before proceeding with this procedure.

#### 2. PROBLEM VERIFICATION

- 1. Warm up engine to normal operating temperature.
- 2. Using Hi-Scan (Pro), monitor MAFS signals while changing throttle position.
  - Specification (MAFS signal voltage):

0.6 ~ 1.0 V at idle

1.3 ~ 1.5 V at 2000 rpm

1.7 ~ 1.9 V at 3000 rpm

Does signal change normally according to TPS signal?

No

Yes

Problem is intermittent or was repaired and ECM memory was not cleared.

Refer to "INTERMITTENT PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

# 3. CHECK TPS RESISTANCE


- 1. Turn ignition switch to OFF and disconnect TPS connector.
- 2. Measure resistance between the terminals 3 and 2 of TPS connector.
  - Specification (TPS resistance)

0.71 ~ 1.38 k $\Omega$  at idle position

2.2 ~ 3.4 k $\Omega$  at W.O.T

- 3. Measure resistance between the terminals 2 and 3 of TPS connector.
  - Specification (TPS resistance): 1.6 ~ 2.4 k $\Omega$  at all throttle position

Is resistance within specification?





No

Replace TPS.

# 4. CHECK MAFS, TPS, AND ECM CONNECTORS

- 1. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
  - Refer to "CONNECTOR INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

Are all connectors good?

EZOF601R

# FLB -72 FUEL SYSTEM (G6BA-GSL 2.7)

Yes

No

Repair or replace it.

# 5. CHECK AIR CLEANER

1. Check air cleaner for dirt, blockage, or damage.

Is air cleaner good?

Yes

No

Clean or replace it.

#### 6. CHECK INTAKE SYSTEM FOR LEAKAGE

- 1. Check entire air intake system for leaks or blockages such as:
  - Throttle body
  - PCV valve
  - · Intake manifold
  - Gasket between intake manifold and surge tank
  - Seals between intake manifold and fuel injectors
  - Seal between surge tank and PCV pipe

Is entire air intake system good?

Yes

No

Repair or replace it.

# 7. CHECK MAFS SIGNAL AGAIN

- 1. Reconnect the ECM and MAFS connectors.
- 2. Connect a Hi-Scan (Pro) to the data link connector.
- 3. Start the engine and monitor the MAFS signals.
  - Specification (MAFS signal voltage):

0.6 ~ 1.0 V at idle

1.3 ~ 1.5 V at 2000 rpm

1.7 ~ 1.9 V at 3000 rpm

Is signal within specification?

Yes

No

Replace MAFS.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

EZOF601S

FLB -73

## TROUBLESHOOTING FOR DTC EA5BE623

DTC	P0102	Mass Air Flow Circuit Low Input
-----	-------	---------------------------------

### **DESCRIPTION**

Refer to DTC P0101

#### DTC DETECTING CONDITION

1. DTC Description

ECM sets DTC P0102 if the ECM detects signal voltage lower than the possible range of a properly operating MAF sensor.

2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause
P0102	Detecting Condition  • DTC Strategy  - Voltage range check  • Threshold Value  - Mass air flow < 6 kg/h for 200 msec	<ul> <li>Open or short to ground in MAFS circuit</li> <li>MAFS</li> <li>ECM</li> </ul>

## **SPECIFICATION**

Refer to DTC P0101

## SCHEMATIC DIAGRAM

Refer to DTC P0101

## SIGNAL WAVE FORM

Refer to DTC P0101

## **FLB** -74

### **INSPECTION PROCEDURE**

#### 1. PROBLEM VERIFICATION

- 1. Connect a Hi-Scan (Pro) to the data link connector.
- 2. Start the engine and monitor the MAFS signals.
  - Specification (MAFS signal voltage):

0.6 ~ 1.0 V at idle

1.3 ~ 1.5 V at 2000 rpm

1.7 ~ 1.9 V at 3000 rpm

Is signal within specification?



Yes

Problem is intermittent or was repaired and ECM memory was not cleared. Refer to "INTERMITTENT PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

### 2. CHECK MAFS AND ECM CONNECTORS

- 1. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
  - Refer to "CONNECTOR INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

Are both connectors good?

Yes


No

Repair or replace it.

## 3. CHECK POWER TO MAFS

Is voltage within specification?

- 1. Turn ignition switch to OFF position and disconnect MAFS connector.
- 2. Turn ignition switch to ON position.
- 3. Measure voltage between terminal 3 of the MAFS harness connector and chassis ground.
  - Specification : approximately B+



Yes

No

Repair open or short to chassis ground in harness.


EZOF6010

FLB -75

#### 4. CHECK FOR OPEN IN HARNESS

- Turn ignition switch to OFF position, and then disconnect MAFS and ECM connector.
- 2. Measure resistance between terminal 2 of the MAFS harness connector and 1 of the ECM harness connector (C133-3).
- 3. Measure resistance between terminal 1 of the MAFS harness connector and 17 of the ECM harness connector (C133-3).
  - Specification (Resistance) : below  $1\Omega$

## Does resistance indicate continuity?






No Repair open in harness.

## 5. CHECK FOR SHORT TO GROUND IN HARNESS

- 1. Turn ignition switch to OFF position, and then disconnect MAFS and ECM connector.
- 2. Measure resistance between terminal 2 of the MAFS harness connector and chassis ground.
- 3. Measure resistance between terminals 2 and 1 of the MAFS harness connector.
  - Specification (Resistance): infinite

Does the resistance indicate open?





No

Repair short or short to chassis ground in harness.

#### 6. CHECK MAFS SIGNAL

- 1. Connect the ECM and MAFS connectors.
- 2. Connect a Hi-Scan (Pro) to the data link connector.
- 3. Start the engine and monitor the MAFS signals.
  - Specification (MAFS signal voltage):

0.6 ~ 1.0 V at idle

1.3 ~ 1.5 V at 2000 rpm

1.7 ~ 1.9 V at 3000 rpm

Is signal within specification?



No

Replace MAFS.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

EZOF601U

## FLB -76

## **FUEL SYSTEM (G6BA-GSL 2.7)**

## TROUBLESHOOTING FOR DTC E7D8AFC8

DTC
-----

### **DESCRIPTION**

Refer to DTC P0101

#### DTC DETECTING CONDITION

1. DTC Description

ECM sets DTC P0103 if the ECM detects signal voltage higher than the possible range of a properly operating MAF sensor.

2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause
P0103	Detecting Condition  • DTC Strategy  - Voltage range check  • Threshold Value  - Mass air flow > 700 kg/h for 200 msec	<ul> <li>Short to battery line in MAFS circuit</li> <li>MAFS</li> <li>ECM</li> </ul>

## **SPECIFICATION**

Refer to DTC P0101

## SCHEMATIC DIAGRAM

Refer to DTC P0101

## SIGNAL WAVE FORM

Refer to DTC P0101

**FLB** -77

#### **INSPECTION PROCEDURE**

#### 1. PROBLEM VERIFICATION

- 1. Connect a Hi-Scan (Pro) to the data link connector.
- 2. Start the engine and monitor the MAFS signals.
  - Specification (MAFS signal voltage):

0.6 ~ 1.0 V at idle

1.3 ~ 1.5 V at 2000 rpm

1.7 ~ 1.9 V at 3000 rpm

Is signal within specification?



Yes

Problem is intermittent or was repaired and ECM memory was not cleared. Refer to "INTERMITTENT PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

#### 2. CHECK MAFS AND ECM CONNECTORS

- 1. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
  - Refer to "CONNECTOR INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

Are both connectors good?




No

Repair or replace it.

## 3. CHECK FOR SHORT TO POWER IN HARNESS

- Turn ignition switch to OFF position and disconnect MAFS and ECM connectors.
- 2. Turn ignition switch to ON position.
- 3. Measure voltage between terminal 2 of the MAFS harness connector and chassis ground.
  - Specification (Voltage): below 0.5 V



Is voltage within specification?



No Repair short to power in harness.

EZOF6011

## FLB -78

#### 4. CHECK MAFS SIGNAL

- 1. Reconnect the ECM and MAFS connectors.
- 2. Connect a Hi-Scan (Pro) to the data link connector.
- 3. Start the engine and monitor the MAFS signals.
  - Specification (MAFS signal voltage):

0.6 ~ 1.0 V at idle

1.3 ~ 1.5 V at 2000 rpm

1.7 ~ 1.9 V at 3000 rpm

Is signal within specification?



No

Replace MAFS.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

EZOF601W



شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




**FLB-79** 

## TROUBLESHOOTING FOR DTC E7DD7384

DTC	P0112	Intake Air Temperature Circuit Low Input
-----	-------	--

#### **COMPONENT LOCATION**



EZOF505I

#### **DESCRIPTION**

The Intake Air Temperature Sensor (IATS) is installed on surge tank. The IATS uses a thermistor whose resistance changes with the temperature. The electrical resistance of the IATS decreases as the temperature increases, and increases as the temperature decreases. The 5V power source in the ECM is supplied to the IATS via a resistor in the ECM. That is, the resistor in the ECM and the thermistor in the IATS are connected in series. When the resistance value of the thermistor in IATS changes according to the intake air temperature, the signal voltage also changes. Using this signal, the information of the intake air temperature, the ECM corrects basic fuel injection duration and ignition timing.

#### DTC DETECTING CONDITION

1. DTC Description

ECM sets DTC P0112 if the ECM detects signal voltage lower than the possible range of a properly operating IATS.

2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause
P0111	Detecting Condition  • DTC Strategy  - Voltage range check  • Threshold Value  - Intake air Temperature > 117.75°C (243.95°F) for 50 seconds	<ul><li>Short to ground in IATS circuit</li><li>IATS</li><li>ECM</li></ul>

## FLB -80

### **SPECIFICATION**


Temperature			Temperature		
( )	( )	IATS Resistance(k )	( )	( )	IATS Resistance(k )
-20	-4	11.72~19.54	40	104	1.06~1.31
0	32	4.75~7.11	60	140	0.55~0.66
20	68	2.22~2.82	80	176	0.30~0.36

#### **SCHEMATIC DIAGRAM**



EZOF401T

## SIGNAL WAVE FORM



IATS and ECTS signals should be smooth and continuous without any sudden changes. When the engine is cold, IATS and ECTS signals should look similar, depending on the ambient air temperature. After warmed-up the IATS signal should not have changed significantly while ECTS signal should have dropped. This indicates the normal increase of the engine coolant temperature is larger than the normal increase of the intake air temperature as the engine warms up.

EZOF6043

**FLB-81** 

### **INSPECTION PROCEDURE**

## 1. CHECK IATS AND ECM CONNECTORS

- 1. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
  - Refer to "CONNECTOR INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

## Are all connectors good?




No Repair or replace it.

### 2. CHECK IATS RESISTANCE

- 1. Turn ignition switch to OFF position and disconnect IATS connector.
- 2. Measure resistance between terminals 1 and 2 of the IATS connector.
  - Specification (IATS resistance):

Temperature		Resistance	Temperature		Resistance
(°C)	(°F)	(Ω)	(°C)	(°F)	(Ω)
-20	-4	11.72 ~ 19.54	40	104	1.06 ~ 1.31
0	32	4.75 ~ 7.11	60	140	0.55 ~ 0.66
20	68	2.22 ~ 2.82	80	176	0.30 ~ 0.36



## Is resistance within specification?




No

Replace IATS.

## 3. CHECK REFERENCE VOLTAGE TO IATS

- 1. Turn ignition switch to OFF position and disconnect IATS connector.
- 2. Turn ignition switch to ON position.
- 3. Measure voltage between terminal 1 of the IATS harness connector and chassis ground.
  - Specification (Voltage): approximately 5V

No



Is voltage within specification?



Repair open or short to chassis ground in harness.

EZOF6012


## FLB -82

## **FUEL SYSTEM (G6BA-GSL 2.7)**

### 4. CHECK FOR SHORT TO GROUND IN HARNESS

- 1. Turn ignition switch to OFF position, and then disconnect IATS and ECM connector.
- 2. Measure resistance between terminal 1 of the IATS harness connector and chassis ground.
- 3. Measure resistance between terminal 1 and 2 of the IATS harness connector.
  - Specification (Resistance): infinite

Does each resistance indicate open?





No

Repair short or short to chassis ground in harness.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

EZOF601Y



شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



FLB -83

## TROUBLESHOOTING FOR DTC ED124B40

DTC	P0113	Intake Air Temperature Sensor Circuit High Input
-----	-------	--

### **DESCRIPTION**

Refer to DTC P0112

#### DTC DETECTING CONDITION

1. DTC Description

ECM sets DTC P0113 if the ECM detects signal voltage higher than the possible range of a properly operating IATS.

2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause
P0113	Detecting Condition  • DTC Strategy  - Voltage range check  • Enable condition  - Time after engine start > 300sec  • Threshold Value  - Intake air temperature < - 38.25°C (-36.85°C) for 50 seconds	<ul> <li>Open or short to battery line in IATS circuit</li> <li>IATS</li> <li>ECM</li> </ul>

# شركت ديجيتال خودرو سامانه (مسئول SPECIFICATION)

Refer to DTC P0112

## SCHEMATIC DIAGRAM

Refer to DTC P0112

#### SIGNAL WAVE FORM

Refer to DTC P0112

## **FLB-84**

### **INSPECTION PROCEDURE**

## 1. CHECK IATS AND ECM CONNECTORS

- 1. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
  - Refer to "CONNECTOR INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

### Are all connectors good?




No Repair or replace it.

### 2. CHECK IATS RESISTANCE

- 1. Turn ignition switch to OFF position and disconnect IATS connector.
- 2. Measure resistance between terminals 1 and 2 of the IATS connector.
  - Specification (IATS resistance):

rature	Resistance	Temperature		Resistance
(°F)	(Ω)	(°C)	(°F)	(Ω)
-4	11.72 ~ 19.54	40	104	1.06 ~ 1.31
32	4.75 ~ 7.11	60	140	0.55 ~ 0.66
68	2.22 ~ 2.82	80	176	0.30 ~ 0.36
	(°F) -4 32	(°F) (Ω) -4 11.72 ~ 19.54 32 4.75 ~ 7.11	(°F) (Ω) (°C) -4 11.72 ~ 19.54 40 32 4.75 ~ 7.11 60	(°F) (Ω) (°C) (°F) -4 11.72 ~ 19.54 40 104 32 4.75 ~ 7.11 60 140



## Is resistance within specification?




No

Replace IATS.

## 3. CHECK REFERENCE VOLTAGE TO IATS

- 1. Turn ignition switch to OFF position and disconnect IATS connector.
- 2. Turn ignition switch to ON position.
- 3. Measure voltage between terminal 1 of the IATS harness connector and chassis ground.
  - Specification (Voltage): approximately 5V



Is voltage within specification?



No Repair open or short to chassis ground in harness.


EZOF6012

**FLB-85** 

## 4. CHECK FOR OPEN IN HARNESS

- Turn ignition to OFF position, and then disconnect IATS and ECM connector.
- 2. Measure resistance between terminal 1 of the IATS harness connector and 22 of the ECM harness connector (C133-3).
- 3. Measure resistance between terminal 2 of the IATS harness connector and 23 of the ECM harness connector (C133-3).
  - Specification (Resistance): below 1 $\Omega$

Does the resistance indicate continuity?




Yes

No Repair open in harness.

## 5. CHECK FOR SHORT TO POWER IN HARNESS

- Turn ignition switch to OFF position and disconnect IATS and ECM connectors.
- 2. Turn ignition switch to ON position.
- 3. Measure voltage between terminal 1 of the IATS harness connector and chassis ground.
  - Specification (Voltage): below 0.5V

Is voltage within specification?



Yes

No

Repair short to power in harness.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.


EZOF601Z

## **FLB** -86

## TROUBLESHOOTING FOR DTC

DTC P0116 Engine Coolant Temperature Circuit Range/Performance


#### **COMPONENT LOCATION**



EZOF505J

#### **DESCRIPTION**

The Engine Coolant Temperature Sensor (ECTS) is located in the engine coolant passage of the cylinder head for detecting the engine coolant temperature. The ECTS uses a thermistor whose resistance changes with the temperature. The electrical resistance of the ECTS decreases as the temperature increases, and increases as the temperature decreases. The reference 5 V in the ECM is supplied to the ECTS via a resistor in the ECM. That is, the resistor in the ECM and the thermistor in the ECTS are connected in series. When the resistance value of the thermistor in the ECTS changes according to the engine coolant temperature, the output voltage also changes. During cold engine operation the ECM increases the fuel injection duration and controls the ignition timing using the information of engine coolant temperature to avoid engine stalling and improve drivability.



BFGE505K

FLB -87

### DTC DETECTING CONDITION

### 1. DTC Description

The purpose of this diagnosis is to detect a stuck coolant temperature signal. The diagnostic function checks whether after a variation of the calculated coolant temperature also a variation of the measured coolant temperature is detected. ECM sets DTC P0116 when the variation of measured engine coolant temperature from engine start is smaller than threshold while variation of calculated coolant temperature by ECM is greater than threshold. If this error code is set in the next driving cycle again, ECM illuminates the MIL. The diagnosis is performed only once per driving cycle.

## 2. Conditions for Setting the DTC


DTC	Detecting Condition & Limp Home	Possible Cause
P0116	Detecting Condition  • DTC Strategy  - Signal stuck  • Threshold Value  - The calculated ECT is higher than the threshlod value but the measured ECT is lower than the threshlod value for 5 seconds.  (The threshold value deands on the ECT at start.)	• ECTS • ECM

#### **SPECIFICATION**


Tempe	erature	•• •	Tempe	erature	
ت مرحدود)	ه (مرسځولي	ECTS Resistance(k )	شرکت دیا	( )	ECTS Resistance(k )
-20	-4	14.13 ~ 16.83	40	104	1.15
ه در اروان	کاران32و در	انه در ح 5.79 تعمیر	60	140	0.59
20	68	2.31 ~ 2.59	80	176	0.32

### **FLB-88**

### **SCHEMATIC DIAGRAM**



#### SIGNAL WAVE FORM



ECTS and IATS signals should be smooth and continuous without any sudden changes. When the engine is cold, ECTS and IATS signals should look similar, depending on the ambient air temperature. After warmed-up the IATS signal should not have changed significantly while ECTS signal should have dropped. This indicates the normal increase of the engine coolant temperature is larger than the normal increase of the intake air temperature as the engine warms up.

EZOF6044

**FLB-89** 

### **INSPECTION PROCEDURE**

### 1. CHECK DTC RELATING TO ECTS

- 1. Connect a Hi-Scan (Pro) to the data link connector.
- 2. Turn ignition switch to ON position and monitor other DTCs.

### Is any DTC relating to ECTS set?



Yes

Do all repairs associated with those codes before proceeding with this procedure.

#### 2. CHECK ECTS AND ECM CONNECTORS

- Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
  - Refer to "CONNECTOR INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

## Are all connectors good?

Yes


No

Repair or replace it.

## 3. CHECK ECTS RESISTANCE

- 1. Turn ignition switch to OFF and disconnect ECTS connector.
- 2. Measure resistance between the terminals 1 and 3 of ECTS connector.
  - Specification (ECTS resistance):

 Tempe	erature	ECTS	Temp	erature	ECTS
(°C)	(°F)	Resistance (kΩ)	(°C)	(°F)	Resistance (kΩ)
-20	-4	14.13 ~ 16.83	40	104	1.15
0	32	5.79	60	140	0.59
20	68	2.31 ~ 2.59	80	176	0.32



## Is resistance within specification?



No Replace ECTS.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

EZOF602A

## FLB -90

## **FUEL SYSTEM (G6BA-GSL 2.7)**

## TROUBLESHOOTING FOR DTC

DTC	P0117	Engine Coolant Temperature Circuit Low
-----	-------	--

### **DESCRIPTION**

Refer to DTC P0116

#### DTC DETECTING CONDITION

1. DTC Description

ECM sets DTC P0117 if the ECM detects signal voltage lower than the possible range of a properly operating ECTS.

2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause
P0117	Detecting Condition  • DTC Strategy  - Voltage range check  • Threshold Value  - Engine coolant temperature > 138°C(280.4°F) for 5 seconds	<ul> <li>Short to ground in ECTS circuit</li> <li>ECTS</li> <li>ECM</li> </ul>

### **SPECIFICATION**

Refer to DTC P0116

SCHEMATIC DIAGRAM

Refer to DTC P0116

SIGNAL WAVE FORM

Refer to DTC P0116

**FLB-91** 

### **INSPECTION PROCEDURE**

### 1. PROBLEM VERIFICATION

- 1. Connect a Hi-Scan (Pro) to the data link connector.
- 2. Start the engine and monitor the ECTS signals while warming up engine to normal operating temperature.

Scanned temperature on the Hi-Scan (Pro) should be close to actual engine coolant temperature, shouldn't it?



Yes

Problem is intermittent or was repaired and ECM memory was not cleared. Refer to "INTERMITTENT PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

#### 2. CHECK ECTS AND ECM CONNECTORS

- 1. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
  - Refer to "CONNECTOR INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

#### Are all connectors good?

Yes

No


Repair or replace it.

## 3. CHECK ECTS RESISTANCE

- 1. Turn ignition switch to OFF and disconnect ECTS connector.
- 2. Measure resistance between the terminals 1 and 3 of ECTS connector.
  - Specification (ECTS resistance):

No

(°C)         (°F)         Resistance (κΩ)         (°C)         (°F)         Resistance (κΩ)           -20         -4         14.13 ~ 16.83         40         104         1.15           0         32         5.79         60         140         0.59	Tempe	erature	ECTS	Temp	erature	ECTS
	(°C)	(°F)	Resistance (kΩ)	(°C)	(°F)	Resistance (kΩ)
0 32 5.79 60 140 0.59	-20	-4	14.13 ~ 16.83	40	104	1.15
	0	32	5.79	60	140	0.59
20 68 2.31 ~ 2.59 80 176 0.32	20	68	2.31 ~ 2.59	80	176	0.32



### Is resistance within specification?

Yes

Replace ECTS.


EZOF602B

### **FLB-92**

## **FUEL SYSTEM (G6BA-GSL 2.7)**

#### 4. CHECK REFERENCE VOLTAGE TO ECTS

- 1. Turn ignition switch to OFF position and disconnect ECTS connector.
- 2. Turn ignition switch to ON position.
- 3. Measure voltage between terminal 1 of the ECTS harness connector and chassis ground.
  - Specification (Voltage): approximately 5V



Is voltage within specification?




No Repair open or short to chassis ground in harness.

## 5. CHECK FOR SHORT TO GROUND IN HARNESS

- 1. Turn ignition switch to OFF position, and then disconnect ECTS and ECM connectors.
- 2. Measure resistance between terminal 1 of the ECTS harness connector and chassis ground.
- 3. Measure resistance between terminal 1 and 3 of the ECTS harness connector.
  - Specification (Resistance): infinite

Does the resistance indicate open?





Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

EZOF602C

FLB -93

## TROUBLESHOOTING FOR DTC E74CA4FF

DTC	P0118	Engine Coolant Temperature Sensor Circuit High
-----	-------	--

### **DESCRIPTION**

Refer to DTC P0116

#### DTC DETECTING CONDITION

1. DTC Description

ECM sets DTC P0118 if the ECM detects signal voltage higher than the possible range of a properly operating ECTS.

2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause
	Detecting Condition  • DTC Strategy  - Voltage range check	
P0118	<ul> <li>Enable condition <ul> <li>a) When intake air temperature &lt; 30°C (86°F)</li> <li>Time after start &gt; 60 seconds</li> <li>b) When in take air temperature &gt; 30°C (86°F)</li> <li>Immediately after start</li> </ul> </li> <li>Threshold Value <ul> <li>Engine coolant temperature &lt; -38°C (-36.4°F) for 5 seconds</li> </ul> </li> </ul>	<ul> <li>Open or short to battery line in ECTS circuit</li> <li>ECTS</li> <li>ECM</li> </ul>

### **SPECIFICATION**

Refer to DTC P0116

**SCHEMATIC DIAGRAM** 

Refer to DTC P0116

SIGNAL WAVE FORM

Refer to DTC P0116

### **FLB-94**

### **INSPECTION PROCEDURE**

#### 1. PROBLEM VERIFICATION

- 1. Connect a Hi-Scan (Pro) to the data link connector.
- 2. Start the engine and monitor the ECTS signals while warming up engine to normal operating temperature.

Scanned temperature on the Hi-Scan (Pro) should be close to actual engine coolant temperature, shouldn't it?



Yes

Problem is intermittent or was repaired and ECM memory was not cleared. Refer to "INTERMITTENT PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

#### 2. CHECK ECTS AND ECM CONNECTORS

- 1. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
  - Refer to "CONNECTOR INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

#### Are all connectors good?


Yes

No Repair or replace it.

### 3. CHECK ECTS RESISTANCE

- 1. Turn ignition switch to OFF and disconnect ECTS connector.
- 2. Measure resistance between the terminals 1 and 3 of ECTS connector.
  - Specification (ECTS resistance):

Tempe	erature	ECTS	Temp	erature	ECTS
(°C)	(°F)	Resistance (kΩ)	(°C)	(°F)	Resistance (kΩ)
-20	-4	14.13 ~ 16.83	40	104	1.15
0	32	5.79	60	140	0.59
20	68	2.31 ~ 2.59	80	176	0.32



Is resistance within specification?

Yes


No Replace ECTS.

EZOF602B

FLB -95

## 4. CHECK REFERENCE VOLTAGE TO ECTS

- 1. Turn ignition switch to OFF position and disconnect ECTS connector.
- 2. Turn ignition switch to ON position.
- 3. Measure voltage between terminal 1 of the ECTS harness connector and chassis ground.
  - Specification (Voltage): approximately 5V



Is voltage within specification?





No

Repair open or short to chassis ground in harness.

#### 5. CHECK FOR OPEN IN HARNESS

- 1. Turn ignition to OFF position, and then disconnect ECTS and ECM connector.
- 2. Measure resistance between terminal 1 of the ECTS harness connector and 24 of the ECM harness connector (C133-3).
- 3. Measure resistance between terminal 3 of the ECTS harness connector and 25 of the ECM harness connector (C133-3).
  - Specification (Resistance): below 1Ω








No

Repair open in harness.

## 6. CHECK FOR SHORT TO POWER IN HARNESS

- 1. Turn ignition switch to OFF position, and then disconnect ECTS and ECM connectors.
- 2. Turn ignition switch to ON position.
- 3. Measure voltage between terminal 1 of the ECTS harness connector and chassis ground.
  - Specification (Voltage): below 0.5V



Is voltage within specification?

Yes

No

Repair short to power in harness.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.


EZOF602D

### **FLB-96**

## TROUBLESHOOTING FOR DTC

DTC	P0121	Throttle Position Sensor Circuit Range / Performance Problem
-----	-------	--

## **COMPONENT LOCATION**



EZOF505M

#### **DESCRIPTION**

The Throttle Position Sensor (TPS) is mounted on the throttle body and detects the opening angle of the throttle plate. The TPS has a variable resistor (potentiometer) whose characteristic is the resistance changing according to the throttle angle. During acceleration, the TPS resistance between the reference 5V and the signal terminal decreases and output voltage increases; during deceleration, the TPS resistance increases and TPS output voltage decreases. The ECM supplies a reference 5V to the TPS and the output voltage increases directly with the opening of the throttle valve. The TPS output voltage will vary from 0.2~0.8V at closed throttle to 4.3~4.8V at wide-open throttle. The ECM determines operating conditions such as idle (closed throttle), part load, acceleration/deceleration, and wide-open throttle from the TPS. Also The ECM uses the Mass Air Flow Sensor (MAFS) signal along with the TPS signal to adjust fuel injection duration and ignition timing.

#### DTC DETECTING CONDITION

#### 1. DTC Description

The ECM compares the actual measured Mass Air Flow signal with the modeled Mass Air Flow value to detect implausibile TPS signal. Because throttle position is one of key parameters in determining the modeled Mass Air Flow value. The DTC P0121 is set when the difference between these two value is too high or too low with lambda deviation in same dirrection for a certain time.

The ECM illuminates the MIL on the second consecutive driving cycle that the diagnostic runs and fails. The modeled Mass Air Flow value is determined by engine speed, throttle angle and ISCA duty.

FLB -97


## 2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home Possible Cause			
P0121	Detecting Condition  DTC Strategy  Compare calculated MAF with MAFS signal  Enable condition  1,500 < Engine speed < 3,500 rpm  Meqsured mass air flow < 350mg/stroke  Engine coolant temperature > 60°C(140°F)  Threshold Value  (Measured MAF) / (Calculated MAF) > 1.3 of < 0.5	<ul><li>TPS</li><li>Intake system</li><li>ECM</li></ul>		

## **SPECIFICATION**

	PS	Normal Parameter		
11	-5	C.T (Idle)	W.O.T	
Throttle Angle (°)		0 ~ 0.5 °	90°~100°	
Signal Voltage (V)		0.2 ~ 0.8 V	4.3 ~ 4.8 V	
Resistance (kΩ)	Terminal 1 and 2	0.71 ~ 1.38 kΩ at all temperature	2.2~3.4 kΩ at all temperature	
/	Terminal 2 and 3	1.6 ~ 2.4 kΩ at all throttle position		
(مسئولیت محدود)	شرکت دیجیتال خودر و سامانه (مسئولیت محدود)			


## **SCHEMATIC DIAGRAM**




EZOF401N

## **FLB** -98

### SIGNAL WAVE FORM






During acceleration, the TPS output voltage increases; during deceleration, the TPS output voltage decreases. As much as possible, TPS signal should be compared with the MAFS signal. And check whether TPS and MAFS signals are increased at the same time when accelerated.



شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



**FLB-99** 

### **INSPECTION PROCEDURE**

#### 1. CHECK DTC RELATING TO TPS

- 1. Connect a Hi-Scan (Pro) to the data link connector.
- 2. Turn ignition to ON position and monitor other DTCs.

Is any DTC relating to TPS set?



Yes

Do all repairs associated with those codes before proceeding with this procedure.

#### 2. CHECK INTAKE SYSTEM

- 1. Inspect the intake system for the following items:
  - Air leakage
  - · Connection of each components

Are the items okay?

Yes


No

Repair or replace it.

## 3. CHECK TPS RESISTANCE

- 1. Turn ignition switch to OFF and disconnect TPS connector.
- 2. Measure resistance between the terminal 3 and 2 of TPS connector.
- 3. Measure resistance between the terminal 2 and 1 of TPS connector.
  - Specification (TPS resistance at any temperature):
    - Terminal 1 and 2: 0.71 ~ 1.38 k $\Omega$  at Closed Throttle 2.2 ~ 3.4 k $\Omega$  at Wide Open Throttle
    - Terminal 2 and 3: 1.6 ~ 2.4 k $\Omega$  at all throttle position

Is each resistance within specification?



2

**TPS** 

Yes

No

Replace TPS.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

EZOF602E

## FLB -100

## **FUEL SYSTEM (G6BA-GSL 2.7)**

## TROUBLESHOOTING FOR DTC EF417C60

DTC	P0122	Throttle Position Sensor Circuit Low Input
-----	-------	--

### **DESCRIPTION**

Refer to DTC P0121

### **DTC DETECTING CONDITION**

1. DTC Description

ECM sets DTC P0122 if the ECM detects signal voltage lower than the possible range of a properly operating TPS.

2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause
P0122	Detecting Condition  • DTC Strategy  - Voltage range check  • Threshold Value	Short to ground in TPS circuit     TPS     ECM
	- TPS signal < 0.14V for 1 second	

## **SPECIFICATION**

Refer to DTC P0121

SCHEMATIC DIAGRAM

Refer to DTC P0121

SIGNAL WAVE FORM

Refer to DTC P0121

FLB -101

### **INSPECTION PROCEDURE**

#### 1. PROBLEM VERIFICATION

- 1. Turn ignition switch to ON position.
- 2. Using a Hi-Scan (Pro), monitor the TPS signals while slowly opening the throttle.
  - · Specification (TPS signal):
    - 0.2 ~ 0.8 V at Closed Throttle
    - 4.3 ~ 4.8 V at Wide Open Throttle
  - Refer to CHARACTERISTIC CURVE in P0121 about any other throttle angle.

Is signal within specification and consistent with the normal curve?



Yes

Problem is intermittent or was repaired and ECM memory was not cleared. Refer to "INTERMITTENT PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

## 2. CHECK TPS AND ECM CONNECTORS

- 1. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
  - Refer to "CONNECTOR INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

Are all connectors good?




No

Repair or replace it.

## 3. CHECK TPS RESISTANCE

- 1. Turn ignition switch to OFF and disconnect TPS connector.
- 2. Measure resistance between the terminal 3 and 2 of TPS connector.
- 3. Measure resistance between the terminal 2 and 1 of TPS connector.
  - Specification (TPS resistance at any temperature):
    - Terminal 1 and 2: 0.71 ~ 1.38 k $\Omega$  at Closed Throttle 2.2 ~ 3.4 k $\Omega$  at Wide Open Throttle
    - Terminal 2 and 3: 1.6 ~ 2.4 kΩ at all throttle position

Is each resistance within specification?



Yes

No

Replace TPS.


EZOF602F

## **FLB** -102

## **FUEL SYSTEM (G6BA-GSL 2.7)**

#### 4. CHECK REFERENCE VOLTAGE TO TPS

- 1. Turn ignition switch to OFF position and disconnect TPS connector.
- 2. Turn ignition switch to ON position.
- 3. Measure voltage between terminal 3 of the TPS harness connector and chassis ground.
  - Specification (Voltage): approximately 5V



Is voltage within specification?





No Repair open or short to chassis ground in harness.

### 5. CHECK FOR SHORT TO GROUND IN HARNESS

- 1. Turn ignition switch to OFF position, and then disconnect TPS and ECM connectors.
- 2. Measure resistance between terminal 3 and 2 of the TPS harness connector.
- 3. Measure resistance between terminal 3 of the TPS harness connector and chassis ground.
  - Specification (Resistance): infinite

Does each resistance indicate open?





Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

EZOF602G

FLB -103

## TROUBLESHOOTING FOR DTC E3E7B98B

DTC	P0123	Throttle Position Sensor Circuit High Input
-----	-------	---

### **DESCRIPTION**

Refer to DTC P0121

#### DTC DETECTING CONDITION

1. DTC Description

ECM sets DTC P0123 if the ECM detects signal voltage higher than the possible range of a properly operating TPS.

2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause
P0123	Detecting Condition  • DTC Strategy  - Voltage range check  • Threshold Value  - TPS signal > 4.86V for 1 seconds	<ul> <li>Open or short to battery line in TPS circuit</li> <li>TPS</li> <li>ECM</li> </ul>

## **SPECIFICATION**

Refer to DTC P0121

SCHEMATIC DIAGRAM

Refer to DTC P0121

SIGNAL WAVE FORM

Refer to DTC P0121

WWW.DIGITALKHODRO.COM

## FLB -104

### **INSPECTION PROCEDURE**

#### 1. PROBLEM VERIFICATION

- 1. Turn ignition switch to ON position.
- 2. Using a Hi-Scan (Pro), monitor the TPS signals while slowly opening the throttle.
  - Specification (TPS signal):
    - 0.2 ~ 0.8 V at Closed Throttle
    - 4.3 ~ 4.8 V at Wide Open Throttle
  - Refer to CHARACTERISTIC CURVE in P0121 about any other throttle angle.

Is signal within specification and consistent with the normal curve?



Yes

Problem is intermittent or was repaired and ECM memory was not cleared. Refer to "INTERMITTENT PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

## 2. CHECK TPS AND ECM CONNECTORS

- 1. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
  - Refer to "CONNECTOR INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

Are all connectors good?

Yes

No

Repair or replace it.


## 3. CHECK TPS RESISTANCE

- 1. Turn ignition switch to OFF and disconnect TPS connector.
- 2. Measure resistance between the terminal 3 and 2 of TPS connector.
- 3. Measure resistance between the terminal 2 and 1 of TPS connector.
  - Specification (TPS resistance at any temperature):
    - Terminal 1 and 2: 0.71 ~ 1.38 k $\Omega$  at Closed Throttle

2.2 ~ 3.4 k $\Omega$  at Wide Open Throttle

- Terminal 2 and 3: 1.6 ~ 2.4 k $\Omega$  at all throttle position

Is each resistance within specification?



Yes

No


Replace TPS.

EZOF602F

FLB -105

### 4. CHECK REFERENCE VOLTAGE TO TPS

- 1. Turn ignition switch to OFF position and disconnect TPS connector.
- 2. Turn ignition switch to ON position.
- 3. Measure voltage between terminal 1 of the TPS harness connector and chassis ground.
  - Specification (Voltage): approximately 5V



**TPS** 

## Is voltage within specification?




No

Repair open or short to chassis ground in harness.

## 5. CHECK FOR OPEN IN HARNESS

- Turn ignition switch to OFF position, and then disconnect TPS and ECM connector.
- 2. Measure resistance between terminal 2 of the TPS harness connector and 20 of the ECM harness connector (C133-3).
- Measure resistance between terminal 3 of the TPS harness connector and 19 of the ECM harness connector (C133-3).
  - Specification (Resistance): below 1Ω



Does each resistance indicate continuity?




No

Repair open in harness.

## 6. CHECK FOR SHORT TO POWER IN HARNESS

- 1. Turn ignition switch to OFF position, and then disconnect TPS and ECM connectors.
- 2. Turn ignition switch to ON position.
- 3. Measure voltage between terminal 3 of the TPS harness connector and chassis ground.
  - Specification (Voltage): below 0.5V



Is voltage within specification?



No

Repair short to power in harness.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.


EZOF602H

## FLB -106

## TROUBLESHOOTING FOR DTC EA75A8A0

DTC	P0130	HO2S Circuit Low Voltage (Bank 1/Sensor 1)	
-----	-------	--	--

#### **COMPONENT LOCATION**



#### EZOF505E

## **DESCRIPTION**

The heated oxygen sensor is mounted on the front side of Catalytic Converter (warm-up catalytic converter) or in the front exhaust pipe, which detects the oxygen concentration in the exhaust gas. The heated oxygen sensor (HO2S) produces a voltage that varies between 0V and 1V. When the air/fuel ratio is lean, the oxygen concentration in the exhaust gas increases and the front HO2S outputs a low voltage (approximately 0 ~ 0.1V). When the air/fuel ratio is rich, the oxygen concentration in the exhaust gas decreases and the front HO2S outputs a high voltage (approximately 0.8 ~ 1V). The ECM constantly monitors the HO2S and increases or decreases the fuel injection duration by using the HO2S signal, which is called closed-loop fuel control operation.

## DTC DETECTING CONDITION

1. DTC Description


ECM sets DTC P0130 if the ECM detects that the front HO2S signal line is open.

2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause
P0130	Detecting Condition  DTC Strategy Check open circuit on HO2S (B1/S1)  Enable condition Sensor pre-heating and full heating phases finished Lambda control active No relevant failure Battery voltage > 10V  Threshold Value	<ul><li>Open in HO2S(B1/S1) circuit</li><li>HO2S (B1/S1)</li><li>ECM</li></ul>
	- 0.37 < HO2S signal < 0.49V for 1 seconds	


FLB -107

### **SCHEMATIC DIAGRAM**



EZOF401D

## ولین سامانه دیجیتال تعمیرکاران SIGNAL WAVE FORM



If you release the accelerator pedal suddenly after engine running about 4000 rpm, fuel supply will stop for short period and the O2 sensor service data in the Hi-Scan (Pro) will display values 200 mV or lower. When you suddenly press on the accelerator pedal down, the voltage will reach  $0.6 \sim 1.0 \text{ V}$ . When you let the engine idle again, the voltage will fluctuate between 200 mV or lower and  $0.6 \sim 1.0 \text{ V}$ . In this case, the O2sensor can be determined as good.

EFAE0098

## FLB -108

#### INSPECTION PROCEDURE

#### 1. PROBLEM VERIFICATION

- 1. Connect a Hi-Scan (Pro) to the data link connector.
- 2. Warm up engine to normal operating temperature and monitor HO2S signal.

Does the HO2S signal switch from lean to rich or from rich to lean?

No

Yes

Problem is intermittent or was repaired and ECM memory was not cleared. Refer to "INTERMITTENT PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

## 2. CHECK HO2S AND ECM CONNECTORS

- Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
  - Refer to "CONNECTOR INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

Are all connectors good?

Yes


No

Repair or replace it.

#### 3. CHECK FOR OPEN IN HARNESS

- Turn ignition switch to OFF position, and then disconnect HO2S and ECM connector.
- 2. Measure resistance between terminal 2 of the HO2S harness connector and terminal 20 of the ECM harness connector (C133-2).
- 3. Measure resistance between terminal 1 of the HO2S harness connector and terminal 14 of the ECM harness connector (C133-2).
  - Specification (HO2S resistance): below 1Ω

Does each resistance indicate continuity?



HO2S

3

Yes

No

Repair open in harness.

#### 4. CHECK HO2S SIGNAL WAVEFORM

- 1. Reconnect the HO2S and ECM connectors.
- 2. Warm up the engine to normal operating temperature.
- 3. Using a Hi-Scan (Pro), monitor the HO2S signal waveform.
  - Refer to "SIGNAL WAVEFORM" for more information.

Do the front HO2S signals fluctuate between 0V and 1V?

Yes

No

Replace HO2S.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

EZOF602R

FLB -109

### TROUBLESHOOTING FOR DTC EA134453

DTC	P0131	HO2S Circuit Low Voltage (Bank 1 / Sensor 1)
-----	-------	--

#### **DESCRIPTION**

Refer to DTC P0130

#### DTC DETECTING CONDITION

1. DTC Description

ECM sets DTC P0131 if the ECM detects signal voltage lower than the possible range of a properly operating HO2S (B1/S1).

2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause
P0131	Detecting Condition  • DTC Strategy  - Sensor voltage low  • Enable condition  - Sensor pre-heating and full heating phases finished  - Battery voltage > 10V	<ul> <li>Short to ground in HO2S (B1/S1) circuit</li> <li>Front HO2S (B1/S1)</li> <li>ECM</li> </ul>
محدود)	Threshold Value     HO2S signal < 0.02V for 2 seconds	

#### **SPECIFICATION**

Refer to DTC P0130

**SCHEMATIC DIAGRAM** 

Refer to DTC P0130

SIGNAL WAVE FORM

#### FLB -110

### **INSPECTION PROCEDURE**

#### 1. PROBLEM VERIFICATION

- 1. Connect a Hi-Scan (Pro) to the data link connector.
- 2. Warm up engine to normal operating temperature and monitor HO2S signal.

Does the HO2S signal switch from lean to rich or from rich to lean?



Yes

Problem is intermittent or was repaired and ECM memory was not cleared. Refer to "INTERMITTENT PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

#### 2. CHECK HO2S AND ECM CONNECTORS

- Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
  - Refer to "CONNECTOR INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

Are all connectors good?

Yes

No

Repair or replace it.

### 3. CHECK FOR SHORT TO GROUND IN HARNESS

- Turn ignition switch to OFF position, and then disconnect HO2S and ECM connector.
- Measure resistance between terminal 1 and 2 of the HO2S harness connector.
- 3. Measure resistance between terminal 1 of the HO2S harness connector and chassis ground.
  - Specification (Resistance): infinite

Does each resistance indicate open?



No

Repair short in harness or short to chassis ground.

### 4. CHECK HO2S SIGNAL WAVEFORM

- 1. Reconnect the HO2S and ECM connectors.
- 2. Warm up the engine to normal operating temperature.
- 3. Using a Hi-Scan (Pro), monitor the HO2S signal waveform.
  - Refer to "SIGNAL WAVEFORM" for more information.

Do the rear HO2S signals fluctuate between 0V and 1V?




No

Replace HO2S.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

EZOF602S



FLB -111

### TROUBLESHOOTING FOR DTC E6B5DA73

DTC	P0132	HO2S Circuit High Input (Bank 1 / Sensor 1)
-----	-------	---

#### **DESCRIPTION**

Refer to DTC P0130

#### DTC DETECTING CONDITION

1. DTC Description

ECM sets DTC P0132 if the ECM detects signal voltage higher than the possible range of a properly operating HO2S (B1/S1).

2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause
P0132	Detecting Condition  • DTC Strategy  - Sensor voltage high  • Enable condition  - Sensor pre-heating and full heating phases finished  - Battery voltage > 10V	<ul> <li>Short to battery line in HO2S (B1/S1) circuit</li> <li>HO2S (B1/S1)</li> <li>ECM</li> </ul>
محدود)	Threshold Value     HO2S signal > 1.3V for 2 seconds	

#### **SPECIFICATION**

Refer to DTC P0130

**SCHEMATIC DIAGRAM** 

Refer to DTC P0130

SIGNAL WAVE FORM

### FLB -112

#### INSPECTION PROCEDURE

#### 1. PROBLEM VERIFICATION

- 1. Connect a Hi-Scan (Pro) to the data link connector.
- 2. Warm up engine to normal operating temperature and monitor HO2S signal.

Does the HO2S signal switch from lean to rich or from rich to lean?

Yes

No

Problem is intermittent or was repaired and ECM memory was not cleared. Refer to "INTERMITTENT PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

#### 2. CHECK HO2S AND ECM CONNECTORS

- 1. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
  - Refer to "CONNECTOR INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

Are all connectors good?

Yes


No

Repair or replace it.

#### 3. CHECK FOR SHORT TO POWER IN HARNESS

- Turn ignition switch to OFF position, and then disconnect HO2S and ECM connectors.
- 2. Turn ignition switch to ON position.
- Measure voltage between terminal 1 of the HO2S harness connector and chassis ground.
  - Specification (Voltage): below 0.5V

Is voltage within specification?





No

Repair short to power in harness.

### 4. CHECK HO2S SIGNAL WAVEFORM

- 1. Reconnect the HO2S and ECM connectors.
- 2. Warm up the engine to normal operating temperature.
- 3. Using a Hi-Scan (Pro), monitor the HO2S signal waveform.
  - Refer to "SIGNAL WAVEFORM" for more information.

Do the rear HO2S signals fluctuate between 0V and 1V?



No

Replace HO2S.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

EZOF602T

FLB -113

### TROUBLESHOOTING FOR DTC E134FDE3

DTC	P0133	HO2S Circuit Slow Response (Bank 1/ Sensor 1)
-----	-------	---

#### **DESCRIPTION**

Refer to DTC P0130

#### **DTC DETECTING CONDITION**

1. DTC Description

DTC P0133 is set when the switching time is bigger than the limit value.

2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause
	Detecting Condition  • DTC Strategy  - Comparison of HO2S lean/rich period with calculated period	
P0133	<ul> <li>Enable condition</li> <li>Catalyst temperature (Model): 340~600°C(644~1,112°F)</li> <li>Engine coolant temperature &gt; 70°C(158°F)</li> <li>800 &lt; Engine speed &lt; 2500 rpm</li> </ul>	<ul> <li>Open or short in HO2S (B1/S1) heater circuit</li> <li>HO2S (B1/S1)</li> <li>Intake system</li> <li>Improper fuel pressure</li> </ul>
محدود)	Threshold Value     Sum of HO2S Lean/Rich period > Calculated limit for 80 lambda controller cycles	• ECM

# schematic diagram اولین سامانه دیجیتال تعمیرکاران

Refer to DTC P0130

SIGNAL WAVE FORM

### FLB -114

#### **INSPECTION PROCEDURE**

#### 1. CHECK OTHER DTC

- 1. Connect Hi-Scan (Pro) to data link connector.
- Turn ignition switch to ON and monitor other DTCs.

Are any other DTCs also set?

No

Yes

Do all repairs associated with those codes before proceeding with this procedure.

#### 2. CHECK FRONT HO2S

- 1. Check the front HO2S for the following items:
  - HO2S error
  - Open or short in HO2S circuit
  - Refer to "DTC P0131 and P0132 (O2 Sensor Circuit High/Low Input)" for a detailed inspection procedure.

Is the front HO2S okay?

Yes

No Replace it.

### 3. CHECK INTAKE SYSTEM FOR VACUUM LEAKGE

1. Visually check intake system for vacuum leakage.

Is any leakage present?



No Repair it.

### 4. CHECK FUEL LINE PRESSURE

- 1. Reduce the fuel pressure to install the fuel pressure gauge.
- 2. After installing tightly the fuel pressure gauge to fuel delivery pipe, start the engine and let it idle.
- 3. Check fuel line pressure.
  - Refer to " FUEL PRESSURE TEST " of FUEL DELIVERY SYSTEM for more information.

Is fuel line pressure normal?

Yes

No

Repair it.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.


LGGE0050

FLB -115

### TROUBLESHOOTING FOR DTC EA4C3E1C

DTC	P0136	HO2S Circuit (Bank 1 / Sensor 2)
-----	-------	----------------------------------

#### **COMPONENT LOCATION**



EZOF5050

#### **DESCRIPTION**

The rear heated oxygen sensor is mounted on the rear side of the Catalytic Converter (warm-up catalytic converter) or in the rear exhaust pipe, which detects the catalyst efficiency. The rear heated oxygen sensor (HO2S) produces a voltage between 0V and 1V. This rear heated oxygen sensor is used to estimate the oxygen storage capability. If a catalyst has good conversion properties, the oxygen fluctuations are smoothed by the oxygen storage capacity of the catalyst. If the conversion provided by the catalyst is low due to aging, poisoning or misfiring, then the oxygen fluctuations are similar to signals from the front oxygen sensor.

### DTC DETECTING CONDITION

1. DTC Description


ECM sets DTC P0136 if the ECM detects that the HO2S (B1/S2) signal line is open.

2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause
P0136	Detecting Condition  Detecting Condition  Check open circuit on rear HO2S  Enable condition  Sensor pre-heating and full heating phases finished  No relevant failure  10 < Battery voltage < 16V  Threshold Value  0.37 < HO2S signal < 0.49V for 2 seconds	<ul><li>Open in HO2S (B1/S2) circuit</li><li>HO2S (B1/S2)</li><li>ECM</li></ul>

### FLB -116

#### **SCHEMATIC DIAGRAM**



#### [CONNECTION INFORMATION]

#### EURO-III/IV (C147)

Terminal	erminal Connected to Function				
1	ECM C133-2 (16) HO2S(B1/S2) Sig				
2	ECM C133-2 (22)	Ground			
3	Main Relay Battery Voltage				
4	ECM C133-2 (7)	HO2S Heater (B1/S2)			

#### EURO-II (C122)

Terminal	Connected to	Function
1	ECM C133-2 (22)	Ground
2	ECM C133-2 (16)	HO2S(B1/S2) Signal
3	ECM C133-2 (17)	HO2S Heater (B1/S2)
4	Main Relay	Battery Voltage

### [HARNESS CONNECTORS]



HO2S (B1/S2)

24	23		21	20	19
18	17		15	14	13
12	11	10	9	8	
6	5	4	3	2	1
$\mathbf{I}$					

**C133-2** ECM

ولین سامانه دیجیتال تعمیرکاران خودرو در ایرا

EZOF4010

### SIGNAL WAVE FORM

02 SNSR(Zr)						0.2 V					1.0 S					
MIN:	7	35.	0m	V							X:	945.0ml		0mV		
1.6																
1.2																
pr9				~~	~~~		~~	•••	~~~	<b>-~</b> -	,	,		سير		
								٠	٠	٠						
0.4																
D																
	0L		ZO	ΛМ	<u></u>	URS	1 [	R-8	\m	МТ	ENU	1 .	IEL	<u> </u>		

The amplitude of signal output of rear HO2S has small value compared to front HO2S because rear HO2S detects emission gas purified by catalytic converter. This illustration is the normal signal waveform of rear HO2S at idle.

EFAE0113

FLB -117

#### **INSPECTION PROCEDURE**

#### 1. PROBLEM VERIFICATION

- 1. Connect a Hi-Scan (Pro) to the data link connector.
- 2. Start engine and hold the engine at 3000 rpm with no load (in P or N) until the cooling fan comes on.

#### Does scan tool display DTC P0136?





No

Problem is intermittent or was repaired and ECM memory was not cleared. Refer to "INTERMITTENT PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

#### 2. CHECK FOR OPEN IN HARNESS

- Turn ignition switch to OFF position, and then disconnect HO2S and ECM connector.
- 2. Measure resistance between terminal 2(1) of the HO2S harness connector and terminal 22 of the ECM harness connector (C133-2).
- 3. Measure resistance between terminal 1(2) of the HO2S harness connector and terminal 16 of the ECM harness connector(C133-2).
  - Specification (HO2S resistance): below  $1\Omega$





Yes

No

Repair open in harness.

### 3. CHECK HO2S SIGNAL WAVEFORM

- 1. Reconnect the HO2S and ECM connectors.
- 2. Warm up the engine to normal operating temperature.
- 3. Using a Hi-Scan (Pro), monitor the HO2S signal waveform.



- 0.0V at Fuel-Cut state after racing with no load
- 0.1 ~ 0.8V at idle.

### Do the rear HO2S signals fluctuate between 0V and 1V?



No

Rep-lace HO2S.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

### FLB -118

### **FUEL SYSTEM (G6BA-GSL 2.7)**

### TROUBLESHOOTING FOR DTC ED5BBF78

DTC	P0137	O2 Sensor Circuit Low Input (Bank1, Sensor2)
-----	-------	--

#### **DESCRIPTION**

Refer to DTC P0136

#### DTC DETECTING CONDITION

1. DTC Description

ECM sets DTC P0137 if the ECM detects signal voltage lower than the possible range of a properly operating HO2S (B1/S2).

2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause
P0137	Detecting Condition  • DTC Strategy  - Sensor voltate low  • Enable condition  - Sensor pre-heating and full heating phases finished  - Battery voltage > 10V	<ul> <li>Short to ground in HO2S (B1/S2) circuit</li> <li>HO2S (B1/S2)</li> <li>ECM</li> </ul>
ىحدود)	Threshold Value     HO2S signal < 0.02V for 2 seconds	

#### **SPECIFICATION**

Refer to DTC P0136

**SCHEMATIC DIAGRAM** 

Refer to DTC P0136

SIGNAL WAVE FORM

FLB -119

#### **INSPECTION PROCEDURE**

#### 1. PROBLEM VERIFICATION

- 1. Connect a Hi-Scan (Pro) to the data link connector.
- 2. Start engine and wait 1 minute.

#### Does scan tool display DTC P0137?




No

Problem is intermittent or was repaired and ECM memory was not cleared. Refer to "INTERMITTENT PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

#### 2. CHECK FOR SHORT TO GROUND IN HARNESS

- Turn ignition switch to OFF position, and then disconnect HO2S and ECM connector.
- Measure resistance between terminal 2(1) and 1(2) of the HO2S harness connector.
- 3. Measure resistance between terminal 1(2) of the HO2S harness connector and chassis ground.
  - Specification (Resistance): infinite

Does each resistance indicate open?



Yes

No

Repair short in harness or short to chassis ground.

#### 3. CHECK HO2S SIGNAL WAVEFORM

- 1. Reconnect the HO2S and ECM connectors.
- 2. Warm up the engine to normal operating temperature.
- 3. Using a Hi-Scan (Pro), monitor the HO2S signal waveform.



• 0.0V when signal line is short to chassis ground

Do the rear HO2S signals fluctuate between 0V and 1V?



No

Replace HO2S.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

### FLB -120

### **FUEL SYSTEM (G6BA-GSL 2.7)**

### TROUBLESHOOTING FOR DTC EFF9712D

DTC	HO2S Circuit High Voltage (Bank 1 / Sensor 2)	
-----	---	--

#### **DESCRIPTION**

Refer to DTC P0136

#### DTC DETECTING CONDITION

1. DTC Description

ECM sets DTC P0138 if the ECM detects signal voltage higher than the possible range of a properly operating HO2S (B1/S2).

2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause
P0138	Detecting Condition  • DTC Strategy  - Sensor voltage high  • Enable condition  - Sensor pre-heating and fullheating phases finished  - Battery voltage > 10V	<ul> <li>Short to battery line in HO2S (B1/S2) circuit</li> <li>HO2S (B1/S2)</li> <li>ECM</li> </ul>
بحدود)	Threshold Value     HO2S signal > 1.3V for 2 seconds	

#### **SPECIFICATION**

Refer to DTC P0136

**SCHEMATIC DIAGRAM** 

Refer to DTC P0136

SIGNAL WAVE FORM

FLB -121

#### **INSPECTION PROCEDURE**

#### 1. PROBLEM VERIFICATION

- 1. Connect a Hi-Scan (Pro) to the data link connector.
- 2. Start engine and wait 1 minute.

Does scan tool display DTC P0138?




No

Problem is intermittent or was repaired and ECM memory was not cleared. Refer to "INTERMITTENT PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

### 2. CHECK FOR SHORT TO POWER IN HARNESS

- Turn ignition switch to OFF position, and then disconnect HO2S and ECM connectors.
- 2. Turn ignition switch to ON position.
- 3. Measure voltage between terminal 1(2) of the HO2S harness connector and chassis ground.
  - Specification (Voltage): below 0.5V



Is voltage within specification?



No

Repair short to power in harness.

### 3. CHECK HO2S SIGNAL WAVEFORM

- 1. Reconnect the HO2S and ECM connectors.
- 2. Warm up the engine to normal operating temperature.
- 3. Using a Hi-Scan (Pro), monitor the HO2S signal waveform.



1.3V when signal line is short to battery line.

Do the rear HO2S signals fluctuate between 0V and 1V?



No

Replace HO2S.


Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

### FLB -122

### TROUBLESHOOTING FOR DTC EB2

DTC	P0150	HO2S Circuit Low Voltage (Bank 2/Sensor 1)
-----	-------	--

#### **COMPONENT LOCATION**



FZOF6030

#### DESCRIPTION

The heated oxygen sensor is mounted on the front side of Catalytic Converter (warm-up catalytic converter) or in the front exhaust pipe, which detects the oxygen concentration in the exhaust gas. The heated oxygen sensor (HO2S) produces a voltage that varies between 0V and 1V. When the air/fuel ratio is lean, the oxygen concentration in the exhaust gas increases and the front HO2S outputs a low voltage (approximately 0 ~ 0.1V). When the air/fuel ratio is rich, the oxygen concentration in the exhaust gas decreases and the front HO2S outputs a high voltage (approximately 0.8 ~ 1V). The ECM constantly monitors the HO2S and increases or decreases the fuel injection duration by using the HO2S signal, which is called closed-loop fuel control operation.

### DTC DETECTING CONDITION

1. DTC Description


ECM sets DTC P0150 if the ECM detects that the front HO2S signal line is open.


2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause
P0150	Detecting Condition	<ul><li>Open in HO2S(B2/S1) circuit</li><li>HO2S (B2/S1)</li><li>ECM</li></ul>
	- 0.37 < HO2S signal < 0.49V for 1 seconds	

FLB -123

#### **SCHEMATIC DIAGRAM**





If you release the accelerator pedal suddenly after engine running about 4000 rpm, fuel supply will stop for short period and the O2 sensor service data in the Hi-Scan (Pro) will display values 200mV or lower. When you suddenly press on the accelerator pedal down, the voltage will reach  $0.6 \sim 1.0 \text{ V}$ . When you let the engine idle again, the voltage will fluctuate between 200 mV or lower and  $0.6 \sim 1.0 \text{ V}$ . In this case, the O2sensor can be determined as good.

EFAE0098

#### FLB -124

#### INSPECTION PROCEDURE

#### 1. PROBLEM VERIFICATION

- 1. Connect a Hi-Scan (Pro) to the data link connector.
- 2. Warm up engine to normal operating temperature and monitor HO2S signal.

Does the HO2S signal switch from lean to rich or from rich to lean?

No

Yes

Problem is intermittent or was repaired and ECM memory was not cleared. Refer to "INTERMITTENT PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

#### 2. CHECK HO2S AND ECM CONNECTORS

- Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
  - Refer to "CONNECTOR INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

Are all connectors good?

Yes


No

Repair or replace it.

#### 3. CHECK FOR OPEN IN HARNESS

- Turn ignition switch to OFF position, and then disconnect HO2S and ECM connector.
- 2. Measure resistance between terminal 2 of the HO2S harness connector and terminal 21 of the ECM harness connector (C133-2).
- 3. Measure resistance between terminal 1 of the HO2S harness connector and terminal 15 of the ECM harness connector (C133-2).
  - Specification (HO2S resistance): below 1Ω

Does each resistance indicate continuity?





No

Repair open in harness.

#### 4. CHECK HO2S SIGNAL WAVEFORM

- 1. Reconnect the HO2S and ECM connectors.
- 2. Warm up the engine to normal operating temperature.
- 3. Using a Hi-Scan (Pro), monitor the HO2S signal waveform.
  - Refer to "SIGNAL WAVEFORM" for more information.

Do the front HO2S signals fluctuate between 0V and 1V?

Yes

No

Replace HO2S.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

FLB -125

### TROUBLESHOOTING FOR DTC E8EA6FD8

DTC P01	HO2S Circuit Lov	w Voltage (Bank 2 / Sensor 1)
---------	------------------	-------------------------------

#### **DESCRIPTION**

Refer to DTC P0150

#### DTC DETECTING CONDITION

1. DTC Description

ECM sets DTC P0151 if the ECM detects signal voltage lower than the possible range of a properly operating HO2S (B2/S1).

2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause
P0151	Detecting Condition  • DTC Strategy  - Sensor voltage low  • Enable condition  - Sensor pre-heating and full heating phases finished  - Battery voltage > 10V	<ul> <li>Short to ground in HO2S (B2/S1) circuit</li> <li>Front HO2S (B2/S1)</li> <li>ECM</li> </ul>
محدود)	Threshold Value HO2S signal < 0.02V for 2 seconds	

#### **SPECIFICATION**

Refer to DTC P0150

**SCHEMATIC DIAGRAM** 

Refer to DTC P0150

SIGNAL WAVE FORM

#### FLB -126

#### **INSPECTION PROCEDURE**

#### 1. PROBLEM VERIFICATION

- 1. Connect a Hi-Scan (Pro) to the data link connector.
- 2. Warm up engine to normal operating temperature and monitor HO2S signal.

Does the HO2S signal switch from lean to rich or from rich to lean?



Yes

Problem is intermittent or was repaired and ECM memory was not cleared. Refer to "INTERMITTENT PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

#### 2. CHECK HO2S AND ECM CONNECTORS

- 1. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
  - Refer to "CONNECTOR INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

Are all connectors good?

Yes


Nο


Repair or replace it.

### 3. CHECK FOR SHORT TO GROUND IN HARNESS

- 1. Turn ignition switch to OFF position, and then disconnect HO2S and ECM connector.
- Measure resistance between terminal 1 and 2 of the HO2S harness connector.
- 3. Measure resistance between terminal 1 of the HO2S harness connector and chassis ground.
  - Specification (Resistance): infinite

Does each resistance indicate open?





## 4. CHECK HO2S SIGNAL WAVEFORM

- Reconnect the HO2S and ECM connectors.
- 2. Warm up the engine to normal operating temperature.
- 3. Using a Hi-Scan (Pro), monitor the HO2S signal waveform.
  - Refer to "SIGNAL WAVEFORM" for more information.

Do the rear HO2S signals fluctuate between 0V and 1V?



No

Replace HO2S.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

FLB -127

### TROUBLESHOOTING FOR DTC E3E204AF

DTC	P0152	HO2S Circuit High Input (Bank 2 / Sensor 1)
-----	-------	---

#### **DESCRIPTION**

Refer to DTC P0150

#### DTC DETECTING CONDITION

1. DTC Description

ECM sets DTC P0152 if the ECM detects signal voltage higher than the possible range of a properly operating HO2S (B2/S1).

2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause
P0152	Detecting Condition  • DTC Strategy  - Sensor voltage high  • Enable condition  - Sensor pre-heating and full heating phases finished  - Battery voltage > 10V	<ul> <li>Short to battery line in HO2S (B2/S1) circuit</li> <li>HO2S (B2/S1)</li> <li>ECM</li> </ul>
محدود)	Threshold Value     HO2S signal > 1.3V for 2 seconds	

#### **SPECIFICATION**

Refer to DTC P0150

**SCHEMATIC DIAGRAM** 

Refer to DTC P0150

SIGNAL WAVE FORM

#### FLB -128

#### **INSPECTION PROCEDURE**

#### 1. PROBLEM VERIFICATION

- 1. Connect a Hi-Scan (Pro) to the data link connector.
- 2. Warm up engine to normal operating temperature and monitor HO2S signal.

Does the HO2S signal switch from lean to rich or from rich to lean?

Yes

No

Problem is intermittent or was repaired and ECM memory was not cleared. Refer to "INTERMITTENT PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

#### 2. CHECK HO2S AND ECM CONNECTORS

- 1. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
  - Refer to "CONNECTOR INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

Are all connectors good?

Yes


No

Repair or replace it.

#### 3. CHECK FOR SHORT TO POWER IN HARNESS

- Turn ignition switch to OFF position, and then disconnect HO2S and ECM connectors.
- 2. Turn ignition switch to ON position.
- Measure voltage between terminal 1 of the HO2S harness connector and chassis ground.
  - Specification (Voltage): below 0.5V

Is voltage within specification?



HO2S

ON



No

Repair short to power in harness.

### 4. CHECK HO2S SIGNAL WAVEFORM

- 1. Reconnect the HO2S and ECM connectors.
- 2. Warm up the engine to normal operating temperature.
- 3. Using a Hi-Scan (Pro), monitor the HO2S signal waveform.
  - Refer to "SIGNAL WAVEFORM" for more information.

Do the rear HO2S signals fluctuate between 0V and 1V?



No

Replace HO2S.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

FLB -129

### TROUBLESHOOTING FOR DTC E1E21C4C

DTC	P0153	HO2S Circuit Slow Response (Bank 2/ Sensor 1)
-----	-------	---

#### **DESCRIPTION**

Refer to DTC P0150

#### **DTC DETECTING CONDITION**

1. DTC Description

DTC P0153 is set when the switching time is bigger than the limit value.

2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause
P0153	Detecting Condition  • DTC Strategy  - Comparison of HO2S lean/rich period with calculated period  • Enable condition  - Catalyst temperature (Model): 340~600°C(644~1,112°F)  - Engine coolant temperature > 70°C(158°F)	<ul> <li>Open or short in HO2S (B2/S1) heater circuit</li> <li>HO2S (B2/S1)</li> <li>Intake system</li> </ul>
محدود)	- 800 < Engine speed < 2500 rpm      Threshold Value     - Sum of HO2S Lean/Rich period > Calculated limit for 80 lambda controller cycles	<ul><li>Improper fuel pressure</li><li>ECM</li></ul>

## ولین سامانه دیجیتال تعمیرکاران SCHEMATIC DIAGRAM

Refer to DTC P0150

### SIGNAL WAVE FORM

### FLB -130

#### **INSPECTION PROCEDURE**

#### 1. CHECK OTHER DTC

- 1. Connect Hi-Scan (Pro) to data link connector.
- Turn ignition switch to ON and monitor other DTCs.

Are any other DTCs also set?

No

Yes

Do all repairs associated with those codes before proceeding with this procedure.

#### 2. CHECK FRONT HO2S

- 1. Check the front HO2S for the following items:
  - HO2S error
  - Open or short in HO2S circuit
  - Refer to "DTC P0151 and P0152 (O2 Sensor Circuit High/Low Input)" for a detailed inspection procedure.

Is the front HO2S okay?

Yes

No Replace it.

### 3. CHECK INTAKE SYSTEM FOR VACUUM LEAKGE

1. Visually check intake system for vacuum leakage.

Is any leakage present?



No Repair it.

### 4. CHECK FUEL LINE PRESSURE

- 1. Reduce the fuel pressure to install the fuel pressure gauge.
- 2. After installing tightly the fuel pressure gauge to fuel delivery pipe, start the engine and let it idle.
- 3. Check fuel line pressure.
  - Refer to " FUEL PRESSURE TEST " of FUEL DELIVERY SYSTEM for more information.

Is fuel line pressure normal?

Yes

No

Repair it.


Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

FLB -131

### TROUBLESHOOTING FOR DTC EBA239FB

DTC	P0156	HO2S Circuit (Bank 2 / Sensor 2)
-----	-------	----------------------------------

#### **COMPONENT LOCATION**



EZOF6035

#### **DESCRIPTION**

The rear heated oxygen sensor is mounted on the rear side of the Catalytic Converter (warm-up catalytic converter) or in the rear exhaust pipe, which detects the catalyst efficiency. The rear heated oxygen sensor (HO2S) produces a voltage between 0V and 1V. This rear heated oxygen sensor is used to estimate the oxygen storage capability. If a catalyst has good conversion properties, the oxygen fluctuations are smoothed by the oxygen storage capacity of the catalyst. If the conversion provided by the catalyst is low due to aging, poisoning or misfiring, then the oxygen fluctuations are similar to signals from the front oxygen sensor.

#### DTC DETECTING CONDITION

1. DTC Description


ECM sets DTC P0156 if the ECM detects that the HO2S (B2/S2) signal line is open.

2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause	
	Detecting Condition  • DTC Strategy  - Check open circuit on rear HO2S  • Enable condition	Open in HO2S (B2/S2) circuit	
P0156	<ul> <li>Sensor pre-heating and full heating phases finished</li> <li>No relevant failure</li> <li>10 &lt; Battery voltage &lt; 16V</li> </ul>	• HO2S (B2/S2) • ECM	
	Threshold Value - 0.37 < HO2S signal < 0.49V for 2 seconds		

### FLB -132

#### **SCHEMATIC DIAGRAM**




#### [CONNECTION INFORMATION]

Terminal	Connected to	Function
1	ECM C133-2 (18)	HO2S(B2/S2) Signal
2	ECM C133-2 (24)	Ground
3	Main Relay	Battery Voltage
4	ECM C133-2 (19)	HO2S Heater (B2/S2)

[HARNESS CONNECTORS]





ECM

EZOF4410

#### SIGNAL WAVE FORM

The amplitude of signal output of rear HO2S has small value compared to front HO2S because rear HO2S detects emission gas purified by catalytic converter. This illustration is the normal signal waveform of rear HO2S at idle.

EFAE0113

FLB -133

#### **INSPECTION PROCEDURE**

#### 1. PROBLEM VERIFICATION

- 1. Connect a Hi-Scan (Pro) to the data link connector.
- 2. Start engine and hold the engine at 3000 rpm with no load (in P or N) until the cooling fan comes on.

### Does scan tool display DTC P0156?




No

Problem is intermittent or was repaired and ECM memory was not cleared. Refer to "INTERMITTENT PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

#### 2. CHECK FOR OPEN IN HARNESS

- Turn ignition switch to OFF position, and then disconnect HO2S and ECM connector.
- 2. Measure resistance between terminal 2 of the HO2S harness connector and terminal 24 of the ECM harness connector (C133-2).
- 3. Measure resistance between terminal 1 of the HO2S harness connector and terminal 18 of the ECM harness connector(C133-2).
  - Specification (HO2S resistance): below  $1\Omega$



Does each resistance indicate continuity?



No

Repair open in harness.

### 3. CHECK HO2S SIGNAL WAVEFORM

- 1. Reconnect the HO2S and ECM connectors.
- 2. Warm up the engine to normal operating temperature.
- 3. Using a Hi-Scan (Pro), monitor the HO2S signal waveform.



- 0.0V at Fuel-Cut state after racing with no load
- 0.1 ~ 0.8V at idle.

Do the rear HO2S signals fluctuate between 0V and 1V?



No

Rep-lace HO2S.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

### FLB -134

### **FUEL SYSTEM (G6BA-GSL 2.7)**

### TROUBLESHOOTING FOR DTC E2AB58EC

DTC	O2 Sensor Circuit Low Input (Bank2, Sensor2)
-----	--

#### **DESCRIPTION**

Refer to DTC P0156

#### DTC DETECTING CONDITION

1. DTC Description

ECM sets DTC P0137 if the ECM detects signal voltage lower than the possible range of a properly operating HO2S (B2/S2).

2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause
P0157	Detecting Condition  • DTC Strategy  - Sensor voltate low  • Enable condition  - Sensor pre-heating and full heating phases finished  - Battery voltage > 10V	<ul> <li>Short to ground in HO2S (B2/S2) circuit</li> <li>HO2S (B2/S2)</li> <li>ECM</li> </ul>
بحدود)	Threshold Value     HO2S signal < 0.02V for 2 seconds	

#### **SPECIFICATION**

Refer to DTC P0156

**SCHEMATIC DIAGRAM** 

Refer to DTC P0156

SIGNAL WAVE FORM

FLB -135

#### **INSPECTION PROCEDURE**

#### 1. PROBLEM VERIFICATION

- 1. Connect a Hi-Scan (Pro) to the data link connector.
- 2. Start engine and wait 1 minute.

### Does scan tool display DTC P0157?




No

Problem is intermittent or was repaired and ECM memory was not cleared. Refer to "INTERMITTENT PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

#### 2. CHECK FOR SHORT TO GROUND IN HARNESS

- Turn ignition switch to OFF position, and then disconnect HO2S and ECM connector.
- 2. Measure resistance between terminal 2 and 1 of the HO2S harness connector.
- 3. Measure resistance between terminal 1 of the HO2S harness connector and chassis ground.
  - Specification (Resistance): infinite





Yes

No

Repair short in harness or short to chassis ground.

#### 3. CHECK HO2S SIGNAL WAVEFORM

- 1. Reconnect the HO2S and ECM connectors.
- 2. Warm up the engine to normal operating temperature.
- 3. Using a Hi-Scan (Pro), monitor the HO2S signal waveform.



• 0.0V when signal line is short to chassis ground

Do the rear HO2S signals fluctuate between 0V and 1V?



No

Replace HO2S.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

### FLB -136

### **FUEL SYSTEM (G6BA-GSL 2.7)**

### TROUBLESHOOTING FOR DTC E45C4773

DTC	P0158	HO2S Circuit High Voltage (Bank 2 / Sensor 2)
-----	-------	---

#### **DESCRIPTION**

Refer to DTC P0156

#### DTC DETECTING CONDITION

1. DTC Description

ECM sets DTC P0158 if the ECM detects signal voltage higher than the possible range of a properly operating HO2S (B2/S2).

2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause
P0158	Detecting Condition  • DTC Strategy  - Sensor voltage high  • Enable condition  - Sensor pre-heating and fullheating phases finished  - Battery voltage > 10V	<ul> <li>Short to battery line in HO2S (B2/S2) circuit</li> <li>HO2S (B2/S2)</li> <li>ECM</li> </ul>
ىحدود)	Threshold Value     HO2S signal > 1.3V for 2 seconds	

#### **SPECIFICATION**

Refer to DTC P0156

**SCHEMATIC DIAGRAM** 

Refer to DTC P0156

SIGNAL WAVE FORM

FLB -137

#### **INSPECTION PROCEDURE**

#### 1. PROBLEM VERIFICATION

- 1. Connect a Hi-Scan (Pro) to the data link connector.
- 2. Start engine and wait 1 minute.

Does scan tool display DTC P0158?




No

Problem is intermittent or was repaired and ECM memory was not cleared. Refer to "INTERMITTENT PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

### 2. CHECK FOR SHORT TO POWER IN HARNESS

- 1. Turn ignition switch to OFF position, and then disconnect HO2S and ECM connectors.
- 2. Turn ignition switch to ON position.
- 3. Measure voltage between terminal 1 of the HO2S harness connector and chassis ground.
  - Specification (Voltage): below 0.5V



Is voltage within specification?

Yes

No

Repair short to power in harness.

### 3. CHECK HO2S SIGNAL WAVEFORM

- 1. Reconnect the HO2S and ECM connectors.
- 2. Warm up the engine to normal operating temperature.
- 3. Using a Hi-Scan (Pro), monitor the HO2S signal waveform.



1.3V when signal line is short to battery line.

Do the rear HO2S signals fluctuate between 0V and 1V?



No

Replace HO2S.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

#### FLB -138

### TROUBLESHOOTING FOR DTC EEDS

DTC
-----

#### **DESCRIPTION**

In order to provide the best possible combination of drivability, fuel economy and emission control, the ECM uses a closed loop air/fuel metering system. The ECM monitors the HO2S signal voltage and adjusts fuel delivery based it in closed loop fuel control. Changes in fuel delivery will be indicated by the long-term and the short-term fuel trim values. The ideal fuel trim value is around 0%. The ECM will add fuel when the HO2S signal is indicating a lean condition. Additional fuel is indicated by fuel trim values that are above 0%. The ECM will reduce fuel when the HO2S signal is indicating a rich condition. Reduction in fuel is indicated by fuel trim values that are below 0%. The DTC relevant to fuel trim will be set when the amount reaches excessive levels because of a lean or rich condition.

#### DTC DETECTING CONDITION

### 1. DTC Description

Breaking the lambda adaptation and lambda controller limits for a long time, which may have been caused by failures in the fuel or intake system will involve emission rise and therefore shall be diagnosed by fuel system monitoring. The lambda controller deviation including adaptive terms are used for fuel system monitoring. The time counter is increased if lambda controller exceeds the threshold and the ECM sets DTC P0171/P0174 or P0172/P0175 respectively depending on direction of lambda controller deviation. P0171/P0174 is set with positive deviation and P0172/P0175 is set with negative deviation.

If same error code is set in the next driving cycle, the ECM illuminates the MIL.

## 2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause
P0171 P0174	Detecting Condition  DTC Strategy  Monitoring deviation of fueling control  Enable condition  Estimated canister loading > -11%  Estimated altitude < 2,440m(8,000ft)  Engine coolant temperature > 60°C(140°F)  Fueling adaptation > 23%  Threshold Value  (Lambda controller + Trim) > 2.2% (Lean A/F ratio) for 800 seconds  [Lean A/F ratio: 300 sec]	<ul> <li>PCSV</li> <li>Intake system</li> <li>Exhaust system</li> <li>Fuel delivery system</li> <li>Ignition system</li> <li>MAFS</li> <li>Front HO2S</li> <li>TPS</li> <li>ECM</li> </ul>

FLB -139

#### **INSPECTION PROCEDURE**

### 1. CHECK DTC RELATING TO INJECTOR, HO2S, ECTS, OR MAFS

- 1. Connect a Hi-Scan (Pro) to the data link connector.
- 2. Turn ignition to ON position and monitor other DTCs.

Are DTCs relating to injector, HO2S, ECTS, or MAFS also set?

No

Yes

Do all repairs associated with those codes before proceeding with this procedure.

#### 2. CHECK FUEL/SEALS/GASKETS FOR CONTAMINATION AND/OR LEAK

- 1. Visually/physically inspect the following items:
  - · Throttle body gasket
  - Gasket between intake manifold and surge tank
  - · Seals between intake manifold and fuel injectors
  - · Seals between surge tank and PCV valves
  - Crankcase ventilation valve and/or system for leaks
  - Contaminated fuel

#### Are all items okay?

Yes

No

Repair or replace it.

#### 3. CHECK AIR CLEANER/MAFS/EXHAUST SYSTEM

- 1. Visually/physically inspect the following items:
  - Air cleaner element for being restricted.
  - Inspect Mass Air Flow Sensor (MAFS)
  - Check for exhaust gas leakage

#### Are all items okay?

Yes

No

Repair or replace it.

#### 4. CHECK CONNECTIONS

Check vacuum hoses for splits and proper connections.
 (Especially PCSV, ISCA hose, throttle body, intake manifold, and brake booster).

### Are all connections okay?

Yes

No

Repair or replace it.

EZOF602X

#### FLB -140

#### 5. CHECK VACUUM AT PCSV

- 1. Disconnect PCSV connector and EVAP. hose (PCSV side) between PCSV and canister.
- 2. Start engine and check vacuum at PCSV at idle.



In 40 seconds after starting the engine (the engine is already warmed up), PCSV operates. So this test must be terminated for 40 seconds.

#### Is vacuum present?

No

Yes

PCSV circuit failure.

Repair according to DTC P0444 and P0445 repair procedures.

#### 6. CHECK FUEL LINE PRESSURE

- 1. Reconnect the ignition coils and spark plug connectors.
- 2. Release the fuel pressure and attach the fuel pressure gauge.
- 3. Start the engine and warm it up to operating temperature.
- 4. Check fuel line pressure at idle.
  - Refer to "FUEL PREESURE TEST" in FUEL DELIVERY SYSTEM.

Is fuel line pressure correct with ignition switch ON?

Yes

No

Check fuel delivery system.

(Refer to "FUEL PREESURE TEST" in FUEL DELIVERY SYSTEM)

#### 7. CHECK INJECTOR FOR NORMAL OPERATION

- 1. Start engine and check engine RPM decrease when disconnecting each injector connector in sequence.
- 2. Measure the decreasing engine RPM of all cylinders.

Is there any cylinder with no change in RPM or only a small change in RPM?

No

Yes

Repair or replace it.

### 8. CHECK INJECTOR FOR NORMAL OPERATION

- 1. Remove spark plugs and inspect spark plug tips.
- 2. Check abnormal color of spark plug tips compared to other cylinders.

Is any spark plug with abnormal color compared to others?

No

Yes

Check engine for mechanical failure. If it is okay, replace spark plugs.

EZOF602Y

FLB -141

### 9. CHECK ECM INPUT SIGNALS

1. Check for ECM input signal from MAFS, HO2S, TPS and other input signals.

Are input signals within specification?



No

Replace all failed parts.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.





### FLB -142

### **FUEL SYSTEM (G6BA-GSL 2.7)**

### TROUBLESHOOTING FOR DTC ECD8D02E

DTC	P0172 P0175	System Too Rich (Bank 1) System Too Rich (Bank 2)
		System reserved (Barin 2)

#### **DESCRIPTION**

Refer to DTC P0171/P0174

#### DTC DETECTING CONDITION

1. DTC Description

Breaking the lambda adaptation and lambda controller limits for a long time, which may have been caused by failures in the fuel or intake system will involve emission rise and therefore shall be diagnosed by fuel system monitoring. The lambda controller deviation including adaptive terms are used for fuel system monitoring. The time counter is increased if lambda controller exceeds the threshold and the ECM sets DTC P0171/P0174 or P0172/P0175 respectively depending on direction of lambda controller deviation. P0171/P0174 is set with positive deviation and P0172/P0175 is set with negative deviation.

If same error code is set in the next driving cycle, the ECM illuminates the MIL.

### 2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause
P0172 P0175	Detecting Condition  DTC Strategy  Monitoring deviation of fueling control  Enable condition  Estimated canister loading > -11%  Estimated altitude < 2,440m(8,000ft)  Engine coolant temperature > 60°C(140°F)  Fueling adaptation > 23%  Threshold Value  (Lambda controller + Trim) < -27% (Rich A/F ratio) for 800 seconds  [Rich A/F ratio : 400 sec]	<ul> <li>PCSV</li> <li>Intake system</li> <li>Exhaust system</li> <li>Fuel delivery system</li> <li>MAFS</li> <li>Front HO2S</li> <li>TPS</li> <li>ECM</li> </ul>

FLB -143

#### **INSPECTION PROCEDURE**

### 1. CHECK DTC RELATING TO INJECTOR, HO2S, ECTS, OR MAFS

- 1. Connect a Hi-Scan (Pro) to the data link connector.
- 2. Turn ignition switch to ON position and monitor other DTCs.

Are DTCs relating to injector, HO2S, ECTS, or MAFS also set?



Yes

Do all repairs associated with those codes before proceeding with this procedure.

#### 2. CHECK AIR CLEANER/MAFS

- 1. Visually/physically inspect the following items:
  - · Air cleaner element for restrictions.
  - MAFS for proper installation and foreign objects

Are all items okay?

Yes

No

Repair or replace it.

#### 3. CHECK FUEL LINE PRESSURE

- 1. Reconnect the ignition coils and spark plug connectors.
- 2. Release the fuel pressure and attach the fuel pressure gauge to the service port on the fuel rail.
- 3. Start the engine and warm it up to operating temperature.
- 4. Check fuel line pressure at idle.
  - Refer to "FUEL PREESURE TEST" in FUEL DELIVERY SYSTEM.

Is fuel line pressure correct with ignition switch ON?

Yes

No

Check fuel delivery system.

(Refer to "FUEL PREESURE TEST" in FUEL DELIVERY SYSTEM)

#### 4. CHECK INJECTOR FOR NORMAL OPERATION

- 1. Start engine and check engine RPM decrease when disconnecting each injector connector in sequence.
- 2. Measure the decreasing engine RPM of all cylinders.

Is there any cylinder with no change in RPM or only a small change in RPM?

No

Yes

Repair or replace it.

BFGE602Z

### FLB -144

## **FUEL SYSTEM (G6BA-GSL 2.7)**

### 5. CHECK ECM INPUT SIGNALS

1. Check for ECM input signal from MAFS, HO2S, TPS and other input signals.

Are input signals within specification?



No Replace all failed parts.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

BFGE603A






FLB -145

#### TROUBLESHOOTING FOR DTC EC924D46

DTC	P0230	Fuel Pump Circuit Malfunction
-----	-------	-------------------------------

#### **COMPONET LOCATION**



EZOF6053

#### **DESCRIPTION**

The ECM provides ground to one side of the coil in the fuel pump relay to control the fuel pump relay. The other side of the fuel pump relay coil is connected to fuel pump relay, which activates when the ignition switch is ON. The ECM monitors the control circuit between the fuel pump relay and the ECM. When the ignition switch is turned ON, the ECM energizes the fuel pump relay, which sends power to the fuel pump.

## DTC DETECTING CONDITION

1. DTC Description

ECM sets DTC P0230 if the ECM detects that fuel pump relay control line is open or short to ground or battery line.


#### 2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause
P0230	Detecting Condition  • DTC Strategy  - Driver stage check  • Enable condition  - Battery Voltage > 10V  • Threshold Value  - Fuel pump relay control line is open or short to ground for 1.5 seconds	<ul> <li>Open or short in fuel pump relay circuit</li> <li>Fuel pump relay</li> <li>ECM</li> </ul>

# **FUEL SYSTEM (G6BA-GSL 2.7)**

# FLB -146

#### **SPECIFICATION**



FLB -147

#### **INSPECTION PROCEDURE**

#### 1. CHECK FUEL PUMP RELAY AND ECM CONNECTORS

- 1. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
  - Refer to "CONNECTOR INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

#### Are all connectors good?



No Repair or replace it.

# 2. CHECK FUEL PUMP RELAY

- 1. Remove the fuel pump relay.
- 2. Apply power to the fuel pump relay terminal 5 and ground terminal 3.
- 3. Check if the fuel pump relay works well when it is energized. (If the fuel pump relay works normally, a clicking sound can be heard.)

## Does the fuel pump relay operate normally?

Yes


No

Replace fuel pump relay.

#### 3. CHECK POWER TO FUEL PUMP RELAY

- 1. Remove the fuel pump relay.
- 2. Turn ignition switch to ON position.
- 3. Measure the voltage between terminal 5 of the fuel pump relay harness connector and chassis ground.
- 4. Measure the voltage between terminal 1 of the fuel pump relay harness connector and chassis ground.
  - · Specification : approximately B+

#### Is voltage within specification?





No


Repair open or short to chassis ground in harness.

EZOF603F

# **FUEL SYSTEM (G6BA-GSL 2.7)**

#### 4. CHECK FOR SHORT TO GROUND IN HARNESS

- 1. Turn ignition switch to OFF position, and then disconnect fuel pump relay and ECM connectors.
- 2. Measure resistance between terminal 3 of the fuel pump relay harness connector and chassis ground.
  - · Specification (Resistance): infinite



Does the resistance indicate open?




No

Repair short or short to chassis ground in harness.

#### 5. CHECK FOR SHORT TO POWER IN HARNESS

- 1. Turn ignition switch to OFF position, and then disconnect fuel pump relay and ECM connectors.
- 2. Turn ignition switch to ON position.
- 3. Measure voltage between terminal 3 of the fuel pump relay harness connector and chassis ground.
  - Specification (Voltage): below 0.5V



Is voltage within specification?




No

Repair short to power in harness.

#### 6. CHECK FOR OPEN IN HARNESS

- 1. Turn ignition switch to OFF position, and then disconnect fuel pump relay and ECM connectors.
- 2. Measure resistance between terminal 3 of the injector harness connector and terminal 10 of ECM harness connector (C133-4).
  - Specification (Resistance): below  $1\Omega$



Does resistance indicate continuity?

Yes

No

Repair open in harness.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.


EZOF603G

FLB -149

#### TROUBLESHOOTING FOR DTC EF99CD44

DTC	P0261 P0264 P0267 P0270 P0273	Cylinder 1 - Injector Circuit Low Input Cylinder 2 - Injector Circuit Low Input Cylinder 3 - Injector Circuit Low Input Cylinder 4 - Injector Circuit Low Input Cylinder 5 - Injector Circuit Low Input
	P0273	Cylinder 5 - Injector Circuit Low Input
	P0276	Cylinder 6 - Injector Circuit Low Input

#### **COMPONENT LOCATION**



EZOF505R

#### **DESCRIPTION**

Based on information from various sensors, the ECM measures the fuel injection amount. The fuel injector is a solenoid-operated valve and the fuel injection amount is controlled by length of time the fuel injector is held open. The ECM controls each injector by grounding the control circuit. When the ECM energizes the injector by grounding the control circuit, the circuit voltage should be low (theoretically 0V) and the fuel is injected. When the ECM de-energizes the injector by opening control circuit, the fuel injector is closed and circuit voltage should be peak for a moment.

#### DTC DETECTING CONDITION

1. DTC Description

ECM sets DTC P0261, P0264, P0267, P0270, P0273 or P0276 respectively if the ECM detects that injector (Cylinder #1, 2, 3, 4, 5 or 6) control line is short to ground.


2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause	
P0261 P0264 P0267 P0270 P0273 P0276	Detecting Condition  • DTC Strategy  - Driver stage check  • Enable condition  - Engine speed > 30 rpm  - Battery voltage > 10V  • Threshold Value	<ul><li>Short to ground in injector circuit</li><li>Injector</li><li>ECM</li></ul>	
	Injector control line is short to ground for 1.5 seconds		

#### **SPECIFICATION**

Injector Resistance: 13.8~15.2 at 20°C(68°F)


#### **SCHEMATIC DIAGRAM**



EZOF401V

FLB -151

#### SIGNAL WAVE FROM



When the ECM energizes the injector by grounding control circuit, the circuit voltage should be low (theoretically 0V) and the fuel is injected. When the ECM de-energizes the injector by opening control circuit, the fuel injector is closed and circuit voltage should be peak at a moment. Peak voltage and injection duration (injector opening time) is equal to the individual cylinder without acceleration.



#### **INSPECTION PROCEDURE**

#### 1. PROBLEM VERIFICATION

- 1. Connect a Hi-scan (Pro) to the data link connector.
- 2. Start the engine.
- 3. Using the Hi-Scan (Pro), monitor the signal waveform of the injector.

#### Is the signal waveform normal?



Yes

Problem is intermittent or was repaired and ECM memory was not cleared. Refer to "INTERMITTENT PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

#### 2. CHECK INJECTOR AND ECM CONNECTORS

- 1. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
  - Refer to "CONNECTOR INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

#### Are all connectors good?


Yes

No

Repair or replace it.

#### 3. CHECK INJECTOR RESISTANCE

- 1. Turn ignition switch to OFF and disconnect injector connector.
- 2. Measure resistance between the terminal 1 and 2 of injector connector.
  - Specification (injector resistance): 13.8 ~ 15.2 Ω at 20°C (68°F)



Is resistance within specification?

Yes

No

Replace Injector.

#### 4. CHECK POWER TO INJECTOR

- 1. Turn ignition switch to OFF position and disconnect injector connector.
- 2. Turn ignition switch to ON position.
- 3. Measure voltage between terminal 1 of the injector harness connector and chassis ground.
  - Specification (Voltage): approximately B+

ON INJECTOR

2 1 B+

33/34/35/36/37/38 =

ECM

Is voltage within specification?

EZOF603H

FLB -153




No

Repair open or short to chassis ground in harness.

#### 5. CHECK FOR SHORT TO GROUND IN HARNESS

- 1. Turn ignition switch to OFF position, and then disconnect injector and ECM connectors.
- 2. Measure resistance between terminal 2 of the injector harness connector and chassis ground.
  - · Specification (Resistance): infinite



Does the resistance indicate open?



No

Repair short or short to chassis ground in harness.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

FZOF6031

# **FUEL SYSTEM (G6BA-GSL 2.7)**

#### TROUBLESHOOTING FOR DTC EE27EEAA

D.	тс	P0262 P0265 P0268 P0271 P0274	Cylinder 1 - Injector Circuit High Input Cylinder 2 - Injector Circuit High Input Cylinder 3 - Injector Circuit High Input Cylinder 4 - Injector Circuit High Input Cylinder 5 - Injector Circuit High Input
			, , , , , , , , , , , , , , , , , , , ,
		P0277	Cylinder 6 - Injector Circuit High Input

#### **DESCRIPTION**

Refer to DTC P0261

#### **DTC DETECTING CONDITION**

1. DTC Description

ECM sets DTC P0262, P0265, P0268, P0271, P0274 or P0277 respectively if the ECM detects that injector (Cylinder #1, 2, 3, 4, 5 or 6) control line is open or short to battery line.

2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause
P0262 P0265 P0268 P0271 P0274 P0277	Detecting Condition	Open or short to battery line in injector circuit     Injector     ECM

#### **SPECIFICATION**

Refer to DTC P0261

**SCHEMATIC DIAGRAM** 

Refer to DTC P0261

SIGNAL WAVE FORM

Refer to DTC P0261

FLB -155

#### **INSPECTION PROCEDURE**

#### 1. PROBLEM VERIFICATION

- 1. Connect a Hi-scan (Pro) to the data link connector.
- 2. Start the engine.
- 3. Using the Hi-Scan (Pro), monitor the signal waveform of the injector.

#### Is the signal waveform normal?



Yes

Problem is intermittent or was repaired and ECM memory was not cleared. Refer to "INTERMITTENT PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

#### 2. CHECK INJECTOR AND ECM CONNECTORS

- 1. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
  - Refer to "CONNECTOR INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

#### Are all connectors good?


Yes

No 🌑

Repair or replace it.

#### 3. CHECK INJECTOR RESISTANCE

- 1. Turn ignition switch to OFF and disconnect injector connector.
- 2. Measure resistance between the terminal 1 and 2 of injector connector.
  - Specification (injector resistance): 13.8 ~ 15.2 Ω at 20°C (68°F)



#### Is resistance within specification?



No

Replace Injector.

#### 4. CHECK POWER TO INJECTOR

- 1. Turn ignition switch to OFF position and disconnect injector connector.
- 2. Turn ignition switch to ON position.
- 3. Measure voltage between terminal 1 of the injector harness connector and chassis ground.
  - Specification (Voltage): approximately B+

ON INJECTOR

2 1 B+

33/34/35/36/37/38 =

ECM

Is voltage within specification?

EZOF603H

# **FUEL SYSTEM (G6BA-GSL 2.7)**

Yes


No

Repair open or short to chassis ground in harness.

#### 5. CHECK FOR SHORT TO POWER IN HARNESS

- Turn ignition switch to OFF position, and then disconnect injector and ECM connectors.
- 2. Turn ignition switch to ON position.
- 3. Measure voltage between terminal 2 of the injector harness connector and chassis ground.
  - Specification (Voltage): below 0.5V

Is voltage within specification?



Yes


No

Repair short to power in harness.

#### 6. CHECK FOR OPEN IN HARNESS

- 1. Turn ignition switch to OFF position, and then disconnect injector and ECM connectors.
- Measure resistance between terminal 2 of the injector harness connector and terminal 33, 34, 35, 36, 37 or 38 (for cylinder #1, 2, 3, 4, 5 or 6 respectively) of ECM harness connector.
  - Specification (Resistance): below  $1\Omega$

Does resistance indicate continuity?



Yes

No

Repair open in harness.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

EZOF603J

FLB -157

#### TROUBLESHOOTING FOR DTC E8446E6D

DTC	P0300 P0301 P0302 P0303	Random/Mutiple Cylinder Misfire Detected Cylinder 1 - Misfire Detected Cylinder 2 - Misfire Detected Cylinder 3 - Misfire Detected
	P0304 P0305	Cylinder 4 - Misfire Detected Cylinder 5 - Misfire Detected
	P0306	Cylinder 6 - Misfire Detected

#### **DESCRIPTION**

Misfires can be caused by lack of combustion in a cylinder due to absence of spark, poor fuel metering, poor compression, or many other causes. Even a small number of misfires may result in excessive exhaust emissions due to the unburned mixture. Increased misfire rates cause damage to the catalytic converter. The ECM monitors the crankshaft speed variation to determine if any misfiring generated. The ECM identifies the specific cylinder in which the misfire has occurred and counts individual misfire events by monitoring changes in the crankshaft rotation for each cylinder. A random misfire indicates two or more cylinders are misfiring.

#### DTC DETECTING CONDITION

#### 1. DTC Description

The ECM must monitor the engine for misfiring possibly caused by ignition coil defects or injector fails. If misfiring is detected, the ECM identify the cylinder(s) that has(have) misfired and calculate misfiring rate for a given duration. The DTC for Misfire (P0301 to 0306) is set as soon as misfiring rate exceed the limit which result in damage to the catalyst or increase emissions. The ECM stores individual DTC for the cylinder which has more than 10% of total misfire rate. With more than two cylinders misfire detection, the ECM sets P0300. If the misfire rate is not extremely high, the MIL will be illuminated in the next driving cycle that diagnostic runs and fails. With extremely high misfire rate which has a danger of burning up the catalyst, the MIL blinks immediately.

# FUEL SYSTEM (G6BA-GSL 2.7)

# 2. Conditions for Setting the DTC

FLB -158

DTC	Detecting Condition & Limp Home	Possible Cause
P0300	Detecting Condition  • DTC Strategy  - Calculation of engine roughness  • Threshold Value	
P0301 P0302 P0303 P0304 P0305 P0306	- Misfire detected on 2 or more cylinders  Detecting Condition (I)  • DTC Strategy  - Calculation of engine roughness  • Enable Condition  - Catalyst temperature > 1,050 (1,922 )  - Mass air flow > zero load  - 500 < Engine speed < 6,500 rpm  - Intake air mass gradient > threshold value calculated by MAF gradient  - Throttle angle gradient > threshold value calculated by TP gradient  - Time after start = 0 sec  • Threshold Value  - 6 < Misfire rate < 17% within 200 revolutions during 200 or 3*200 revolutions  Detecting Condition (II)  • DTC Strategy  - Calculation of engine roughness  • Enable Condition  - A/CON compressor is not switched in between ON and OFF  - Fuel cut-off not active  - No rough load  • Threshold Value  - Misfire rate > 2.3% during first 1,000 revolutions during 1,000 revolutions or  - Misfire rate > 2.3% after first 1,000 revolutions during 4*1,000 revolutions	Open or short in engine wire Connector connection Vacuum hose connection Ignition system Injector Fuel pressure Compression pressure Valve clearance and timing PCV hose PCV hose CKPS ECM


# **SPECIFICATION**

Tempe	erature	Ignition Coi	I Resistance
( )	( )	Primary Coil ( )	Secondary Coil (kΩ)
20	68	0.74±10%	13.3±15%kΩ

Item	Specification
Spark Plug Air Gap	1.0~1.1 mm (0.039~0.043 in)

FLB -159

#### **SCHEMATIC DIAGRAM**



# **FUEL SYSTEM (G6BA-GSL 2.7)**

#### FLB -160

#### **INSPECTION PROCEDURE**

#### 1. CHECK DTC RELATING TO INJECTOR/CKPS/MAFS/TPS

- 1. Connect a Hi-Scan (Pro) to the data link connector.
- 2. Turn ignition to ON position and monitor other DTCs.

Is any DTC relating to injectors, CKPS, MAFS or TPS set?

No

Yes

Do all repairs associated with those codes before proceeding with this procedure.

#### 2. CHECK INTAKE SYSTEM FOR VACUUM LEAK AND PCV VALVE

- 1. Check intake system for any split, disconnected, worn, or perforated vacuum hoses.
- 2. Check Positive Crankcase Ventilation (PCV) valve for proper operation and for leak.

Are vacuum hoses and PCV valve okay?

Yes

No

Replace faulty vacuum hoses or PCV valve.

#### 3. CHECK POWER TO IGNITION COIL

- Turn ignition switch to OFF position and disconnect ignition coil connector.
- 2. Turn ignition switch to ON position.

Is resistance within specification?

- 3. Measure voltage between terminal 3 of the ignition coil harness connector and chassis ground.
  - Specification: approximately B+

ON IG COIL

2
1
4
3
B+

ECM

Yes

No Repair open or short to chassis ground in harness.

EZOF603K

FLB -161


#### 4. CHECK IGNITION COILS AND SPARK PLUG WIRES


- 1. Turn ignition switch to OFF position and disconnect the ignition coil connector.
- 2. Measure resistance of the primary coils and the secondary iginition coils.

₩ NOTE

P0300: Ignition Coil No.1 through No.6

P0301: Ignition Coil No.1 P0302: Ignition Coil No.2 P0303: Ignition Coil No.3 P0304: Ignition Coil No.4 P0305 : Ignition Coil No.5





#### · Specification (Resistance):

Temperature		IgnitionCoil Resistance	
(°C)	(°F)	Primary Coil (Ω)	Secondary Coil (kΩ)
20	68	0.74 $\pm$ 10% $\Omega$	13.3 $\pm$ 15% k $\Omega$

3. Disconnect plug wires and check spark plug wires for cracks, corroded terminal, or carbon tracking.

Are ignition coils and spark plug wires okay?

Yes No Repair or replace it.

# 5. CHECK SPARK PLUG FOR PROPER OPERATION

- 1. Remove the spark plug.
- 2. Visually check the spark plug for carbon tracking, foreign materials (oil or fuel), damage, or cracking.
- 3. Measure the spark plug gap and check the spark plug for proper operation.
  - Specification (Air Gap): 1.0~1.1 mm (0.039~0.043 in)

Is spark plug okay?

Yes

Repair or replace it. No

#### 6. CHECK CKPS, TONE-WHEEL AND AIR GAP

- 1. Turn ignition switch to OFF position.
- 2. Disconnect the CKPS connector.
- 3. Visually check the tone-wheel for damaged teeth, foreign materials and improper installation and measure the air gap between the CKPS and the rotor.
  - Specification (Air Gap): 0.3~1.7 mm (0.012~0.067 in)

Are CKPS and tone-wheel okay?

EZOE6031

# **FUEL SYSTEM (G6BA-GSL 2.7)**

Yes

No

Repair or replace it.

#### 7. CHECK COMPRESSION

- 1. Do a compression test (no more than 10% between highest and lowest cylinder).
  - Refer to "EM" group.

Is compression okay?

Yes

No

Repair or replace it.

#### 8. CHECK FUEL LINE PRESSURE

- 1. Reconnect the ignition coils and spark plug connectors.
- 2. Release the fuel pressure and attach the fuel pressure gage to the delivery pipe.
  - To release the fuel presure, refer to "FUEL DELIVERY SYSTEM" section.
- 3. Start the engine and warm it up to normal operating temperature.
- 4. Check fuel line pressure at idle.
  - Specification (Fuel Pressure): 350 kpa (3.5 kg/cm², 49.8 psi)

Is fuel line pressure within specification?

Yes

No

Check fuel delivery system.

(Refer to "FUEL DELIVERY SYSTEM" section)

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.


EZOF6054

FLB -163

#### TROUBLESHOOTING FOR DTC EDB2DA27

DTC	P0325 P0330	Knock Sensor 1 Circuit Knock Sensor 2 Circuit
-----	----------------	---


#### **COMPONENT LOCATION**



FZOF505B

#### **DESCRIPTION**

Knocking is a phenomenon characterized by undesirable vibration and noise and can cause engine damage. The knock sensor (KS) is attached to the cylinder block and senses engine knocking. A knocking vibration from the cylinder block is applied as pressure to the piezoelectric element. The knock sensor (KS) detects vibration upon increase and decrease in engine RPM and generates a voltage based on this vibration. The ECM controls the ignition timing based on the amplitude and frequency of the knock sensor signal. For example, if engine knocking occurs, the ignition timing is retarded to suppress it. This DTC is set when the frequency goes outside a calibrated level.



BFGE505A

#### DTC DETECTING CONDITION

1. DTC Description


The ECM monitors the range of the analog input signal from knock sensor to check sensor failure that is short circuit or open circuit.

If the difference between knock signal and noise level is smaller than the threshold during defined time period, the DTC P0325 or P0330 are set. In case the noise level is higher than the uppper threshold or lower than the lower threshold, the DTC P0325 or P0330 are set too. If same error code is set in the next driving cycle, the ECM illuminates the MIL.

#### 2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause
P0325 P0330	Detecting Condition  • DTC Strategy  - Voltage range check  • Enable condition  - Engine speed > 1,800 rpm  - Knock control enabled	<ul> <li>Open or Short in knock sensor circuit</li> <li>Knock sensor</li> <li>ECM</li> </ul>
	<ul> <li>Threshold Value</li> <li>Mean Value of sensor signal &lt; 0.1V during 10*720°CA</li> </ul>	


#### SCHEMATIC DIAGRAM



EZOF402C

FLB -165

#### SIGNAL WAVE FORM



The knock sensor is installed at the cylinder block to sense a vibration successfully when engine operates. The waveform shown is the knock sensor signal's characteristic and indicates that the knocking doesn't take place. The knocking signal generally appears that a noise generates more than other sensors.

EFAE0228



شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



#### INSPECTION PROCEDURE

#### 1. CHECK KNOCK SENSOR AND ECM CONNECTORS

- 1. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
  - Refer to "CONNECTOR INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

#### Are all connectors good?



Yes


No Repair or replace it.

#### 2. CHECK FOR OPEN IN HARNESS

- Turn ignition switch to OFF position, and then disconnect KS and ECM connector.
- 2. Measure resistance between terminal 1 of the KS harness connector and 30(32) of the ECM harness connector (C133-3).
- 3. Measure resistance between terminal 2 of the KS harness connector and 29(31) of the ECM harness connector (C133-3).
  - Specification (Resistance): below 1Ω

Does each resistance indicate continuity?

No






Repair open in harness.

#### 3. CHECK FOR SHORT TO GROUND IN HARNESS

- Turn ignition switch to OFF position, and then disconnect KS and ECM connector.
- 2. Measure resistance between terminal 2 of the KS harness connector and chassis ground.
- 3. Measure resistance between terminal 1 and 2 of the KS harness connector.
  - · Specification (Resistance): infinite

Nο

Does each resistance indicate open?



Yes


Repair short or short to chassis ground in harness.

EZOF603N

FLB -167

#### 4. CHECK FOR SHORT TO POWER IN HARNESS

- 1. Turn ignition switch to OFF position, and then disconnect KS and ECM connectors.
- 2. Turn ignition switch to ON position.
- 3. Measure voltage between terminal 2 of the KS harness connector and chassis ground.
  - Specification (Voltage): below 0.5V



Is voltage within specification?



No

Repair short to power in harness.

#### 5. CHECK KNOCK SENSOR SIGNAL

- 1. Reconnect the ECM and KS connectors.
- 2. Connect a Hi-Scan (Pro) to the knock sensor.
- 3. Start the engine and monitor the KS signal at idle.
  - Refer to "SIGNAL WAVEFORM" for more information.

Is KS signal normal?




No

Replace KS.

## 6. CHECK KNOCK SENSOR

- 1. Turn ignition switch to OFF position and disconnect KS connectors.
- 2. Measure capacitance between terminal 1 and 2 of the KS connector.
  - Specification (capacitance): 0.8 ~ 1.6 nF (800 ~ 1,600 pF)



Is the measured capacitance within specification?



No

Replace KS.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.


EZOF603O

# **FUEL SYSTEM (G6BA-GSL 2.7)**

#### TROUBLESHOOTING FOR DTC EAFGEA2D

DTC
-----

#### COMPONENT LOCATION



EZOF505W

#### **DESCRIPTION**

The Crankshaft Position Sensor (CKPS) is a hall effect type sensor that generates voltage using a sensor and a target wheel mounted on the crankshaft; there are 58 slots in the target wheel where one is longer than the others. When the slot in the wheel aligns with the sensor, the sensor voltage outputs low. When the metal (tooth) in the wheel aligns with the sensor, the sensor voltage outputs high. During one crankshaft rotation there are 58 rectangular signals and one longer signal. The ECM calculates engine RPM by using the sensor's signal and controls the injection duration and the ignition timing. Using the signal differences caused by the longer slot, the ECM identifies which cylinder is at top dead center.

#### DTC DETECTING CONDITION

#### 1. DTC Description


The ECM sets DTC P0335 when the number of crankshaft teeth during one revolution is incorrect or crankshaft signal is missing while camshaft signal is detected. If same error code is set in the next driving cycle, the ECM illuminates the MIL.

FLB -169

#### 2. Conditions for Setting the DTC


DTC	Detecting Condition & Limp Home	Possible Cause
P0335	Detecting Condition & Limp Home  Detecting Condition (I)  Threshold Signal switching  Parallel Condition (I)  Detecting Condition (I)  Threshold Signal Switching  Threshold Value (I)  Detecting Condition (I)  Detecting Condition & Limp Home	Open or short to groumd or battery voltage line in CKPS Circuit     Poor connection of CKPS
	TDC cannot be detected with valid crankshaft teeth and camshaft signal during 4 revolutions  Detecting condition (II)	connector     Air gap out of specification     CKPS interfered with
	DTC Strategy     Check crankshaft signal switching	electrical noise at cranking CKPS ECM
	Engble Condition     After camshaft signal synchronization	
	Threshold Value     Number of crankshaft teeth is not correct during 5 revolutions	0


#### SCHEMATIC DIAGRAM



EZOF402E

#### SIGNAL WAVE FORM





The given data is the normal waveform of the Crankshaft Position Sensor(CKPS) and Camshaft Position Sensor(CMPS). The ECM controls the injection timing and the ignition timing by using these signals. The CKPS signal is used to detect the piston's position and the CMPS signal is used to detect the Top Dead Center of each cylinder.



اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



FLB -171

#### **INSPECTION PROCEDURE**

#### 1. CHECK CKPS AND ECM CONNECTORS

- 1. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
  - Refer to "CONNECTOR INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.


#### Are all connectors good?



No Repair or replace it.

#### 2. CHECK POWER TO CKPS

- 1. Turn ignition switch to OFF position, and then disconnect CKPS connector.
- 2. Turn ignition switch to ON position.
- Measure voltage between terminal 1 of the CKPS harness connector and chassis ground.
  - Specification (Voltage): approximately B+



Is voltage within specification?




No

Repair open or short to chassis ground in harness.

# 3. CHECK FOR OPEN IN HARNESS Lineary dilating judge

- Turn ignition switch to OFF position, and then disconnect CKPS and ECM connector.
- 2. Measure resistance between terminal 3 of the CKPS harness connector and 21 of the ECM harness connector (C133-3).
- 3. Measure resistance between terminal 2 of the CKPS harness connector and 8 of the ECM harness connector (C133-3).
  - Specification (Resistance): below  $1\Omega$

Does each resistance indicate continuity?





No Repair open in harness.

EZOF603P

## **FUEL SYSTEM (G6BA-GSL 2.7)**

#### FLB -172

#### 4. CHECK FOR SHORT TO GROUND IN HARNESS

- Turn ignition switch to OFF position, and then disconnect CKPS and ECM connector.
- Measure resistance between terminal 2 of the CKPS harness connector and chassis ground.
- 3. Measure resistance between terminal 3 and 2 of the CKPS harness connector.
  - Specification (Resistance): infinite

# $\begin{array}{c|c} \text{CKPS} \\ \hline \Omega & \stackrel{3}{3} & \stackrel{2}{2} & \stackrel{1}{1} \\ \hline \text{ECM} & \end{array}$

Does each resistance indicate open?




No

Repair short or short to chassis ground in harness.

#### 5. CHECK FOR SHORT TO POWER IN HARNESS

- 1. Turn ignition switch to OFF position, and then disconnect CKPS and ECM connectors.
- 2. Turn ignition switch to ON position.
- 3. Measure voltage between terminal 2 of the CKPS harness connector and chassis ground.
  - Specification (Voltage): below 0.5V



Is voltage within specification?



No

Repair short to power in harness.

# 6. CHECK CKPS SIGNAL

- 1. Reconnect the ECM and CKPS connectors.
- 2. Connect a Hi-Scan (Pro) to the CKPS.
- 3. Start the engine and monitor the CKPS signal at normal operating temperature.
  - Refer to "SIGNAL WAVEFORM" for more information.

# Is CKPS signal normal?



No


Replace CKPS.

EZOF603Q

FLB -173

#### 7. CHECK CKPS

- Turn ignition switch to OFF position and then disconnect CKPS connector.
- 2. Remove the CKPS from the engine.
- 3. Turn ignition switch to ON position.
- 4. Apply battery voltage to the terminal 1 and ground terminal 3 of CKPS as shown in the figure.
- 5. Install a LED between +5V power and CKPS terminal 2, and then set a steel wheel (or anything made of steel; hammer, wrench, bolt and nut etc.) at the CKPS's tip.
- Rotate the steel wheel slowly and check if the LED flashes light.
  - If the LED blinks, the CKPS works normally.



Does flash the LED when rotating the steel wheel?



No

Replace CKPS.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

EZOF603R


ولین سامانه دیجیتال تعمیرکاران خودرو در ایران

# **FUEL SYSTEM (G6BA-GSL 2.7)**

# TROUBLESHOOTING FOR DTC ESAAB9CB

	DTC	P0340	Camshaft Position Sensor Circuit Malfunction
--	-----	-------	--

#### **COMPONENT LOCATION**



EZOF505Y

#### **DESCRIPTION**

The Camshaft Position Sensor (CMPS) is a sensor that detects the compression TDC of the NO. 1 cylinder. The CMPS consists of a hall type sensor and a target on the end of the intake camshaft. When the target triggers the sensor, the sensor voltage is 5V. If not, the sensor voltage is 0V. These CMPS signal is sent to the ECM and the ECM uses the CMPS signal for synchronizing the firing of sequential fuel injectors.

#### DTC DETECTING CONDITION

1. DTC Description


The ECM monitors the camshaft sensor signal transition position which must change only once per crankshaft revolution. If no camshaft signal is detected while crankshaft signal is detected, the ECM sets DTC P0340. If same error code is set in the next driving cycle, the ECM illuminates the MIL.

#### 2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause	
	Detecting Condition  • DTC Strategy  - Check camshaft signal switching	<ul><li>Short to ground</li><li>Open or short to ground</li></ul>	
P0340	Enable condition     No failure on CKPS	or battery voltage line in CMPS circuit  • Poor connection of CMPS	
	<ul> <li>Threshold Value</li> <li>No camshaft signal switching detected or</li> <li>Rising and falling camshaft edge is not within defined window (-8~+8 teeth)during 80 revolutions</li> </ul>	connector • CMPS • ECM	


FLB -175

#### **SCHEMATIC DIAGRAM**



EZOF402G

#### SIGNAL WAVE FORM



The given data is the normal waveform of the Crankshaft Position Sensor (CKPS) and Camshaft Position Sensor (CMPS). The ECM controls the injection timing and the ignition timing by using these signals. The CKPS signal is used to detect the piston's position and the CMPS signal is used to detect the Top Dead Center of each cylinder.

LGGE402H

#### INSPECTION PROCEDURE

#### 1. PROBLEM VERIFICATION

- 1. Connect a Hi-Scan (Pro) to the data link connector.
- 2. Start the engine and monitor the CMPS signal at normal operating temperature without electrical loads.

Is signal continuously fluctuating between 0V and 5V?

No

Yes

Problem is intermittent or was repaired and ECM memory was not cleared. Refer to "INTERMITTENT PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

# 2. CHECK CMPS AND ECM CONNECTORS

- 1. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
  - Refer to "CONNECTOR INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

Are all connectors good?

Yes

No


Repair or replace it.

#### 3. CHECK POWER TO CMPS

- Turn ignition switch to OFF position, and then disconnect CMPS connector.
- 2. Turn ignition switch to ON position.

Is voltage within specification?

- Measure voltage between terminal 1 of the CMPS harness connector and chassis ground.
  - Specification (Voltage): approximately B+



Yes


Repair open or short to chassis ground in harness.

#### 4. CHECK FOR OPEN IN HARNESS

No

- Turn ignition switch to OFF position, and then disconnect CMPS and ECM connector.
- 2. Measure resistance between terminal 3 of the CMPS harness connector and 8 of the ECM harness connector (C133-4).
- Measure resistance between terminal 2 of the CMPS harness connector and 7 of the ECM harness connector (C133-4).
  - Specification (Resistance): below  $1\Omega$

Does each resistance indicate continuity?



EZOF603S


FLB -177



Repair open in harness. No

#### 5. CHECK FOR SHORT TO GROUND IN HARNESS

- 1. Turn ignition switch to OFF position, and then disconnect CMPS and ECM connector.
- 2. Measure resistance between terminal 2 of the CMPS harness connector and chassis ground.
- 3. Measure resistance between terminal 3 and 2 of the CMPS harness connector.
  - Specification (Resistance): infinite




Does each resistance indicate open?



Repair short or short to chassis ground in harness. No

#### 6. CHECK FOR SHORT TO POWER IN HARNESS

- 1. Turn ignition switch to OFF position, and then disconnect CMPS and ECM connectors.
- 2. Turn ignition switch to ON position.
- 3. Measure voltage between terminal 2 of the CMPS harness connector and chassis ground.
  - Specification (Voltage): below 0.5V



Is voltage within specification?



Repair short to power in harness. No


EZOF603T

# **FUEL SYSTEM (G6BA-GSL 2.7)**

#### FLB -178

#### 7. CHECK CMPS

- 1. Turn ignition switch to OFF position and then disconnect CMPS connector.
- 2. Remove the CMPS from the engine.
- 3. Turn ignition switch to ON position.
- 4. Apply battery voltage to the terminal 1 and ground terminal 3 of CMPS as shown in the figure.
- 5. Install a LED between +5V power and CMPS terminal 2, and then set a steel wheel (or anything made of steel; hammer, wrench, bolt and nut etc.) at the CMPS's tip.
- Rotate the steel wheel slowly and check if the LED flashes light.
  - If the LED blinks, the CMPS works normally.



Does flash the LED when rotating the steel wheel?



No

Replace CMPS.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

EZOF603U


ولین سامانه دیجیتال تعمیرکاران حودرو در ایران

FLB -179

#### TROUBLESHOOTING FOR DTC EFF82B4F

	P0350 P0351	Ignition Coil Primary/Secondary Circuit Ignition Coil 'A' Primary/Secondary Circuit
DTC	P0352 P0353	Ignition Coil 'B' Primary/Secondary Circuit Ignition Coil 'C' Primary/Secondary Circuit
	P0354 P0355	Ignition Coil 'D' Primary/Secondary Circuit Ignition Coil 'E' Primary/Secondary Circuit
	P0356	Ignition Coil 'F' Primary/Secondary Circuit

#### **COMPONENT LOCATION**



#### **DESCRIPTION**

With the ignition switch in the ON or START position, voltage is applied to the ignition coil. Each ignition coil consists of two coils. High tension leads go to each cylinder from the ignition coils. The ignition coils fire two spark plugs on every power stroke (the cylinder under compression and the cylinder on the exhaust stroke). The Engine Control Module (ECM) provides a switching circuit to ground for energizing the primary ignition coils. The ECM uses the crankshaft position sensor and camshaft position sensor signal to time the energizing of the coil. When a primary ignition coil is energized and de-energized, the secondary coil produces a high voltage spike to the attached spark plugs.

#### DTC DETECTING CONDITION

#### 1. DTC Description

The ECM monitors the peak voltage duration of the ignition primary circuit. If abnormal signal is detected on a cylinder (P0351 ot P0356) or more than three cylinders (P0350), the ECM sets above DTC.

# FUEL SYSTEM (G6BA-GSL 2.7)

# 2. Conditions for Setting the DTC

FLB -180

DTC	Detecting Condition & Limp Home	Possible Cause
P0350	Detecting Condition	
	- Failure on three or more cylinders	
P0351 P0352 P0353 P0354 P0355	Detecting Condition (I)  • DTC Strategy  - Monitoring ignition coil primary voltage  • Enable Condition  - Engine coolant temperature > 75 (167 )  - No cylinder shut-off active  - 5 subsequent working cycles after shut-off are passed  - No failure present on camshaft	<ul> <li>Open or short in ignition coil circuit</li> <li>Ignition system</li> <li>ECM</li> </ul>
P0356	<ul> <li>Threshold Value</li> <li>No ignition spark</li> <li>Ignition coil primary over voltage duration (depending on engine speed and mass air flow) too short</li> <li>Over voltage duration of each ignition output overlapping below 4,500 rpm</li> </ul>	0


# شرکت دیجیتال خودرو سامانه (مسئولی SPECIFICATION

Temperature		Ignition Coil	Resistance
ان خودرودی ایران	انه دیجیت(ل) تعمیرکا	Primary Coil ( )	Secondary Coi <mark>l (kΩ)</mark>
20	68	0.74±10%	13.3±15%kΩ


Item	Specification
Spark Plug Air Gap	1.0~1.1 mm (0.039~0.043 in)

FLB -181

#### **SCHEMATIC DIAGRAM**



#### SINGAL WAVEFORM



The ignition power transistor, controlled by the ECM, provides a switching circuit to ground for energizing the primary ignition coil. When the primary ignition coil is energized and de-energized, the secondary coil produces a high voltage through the attached spark plug.

EFAE0253

#### **INSPECTION PROCEDURE**

#### 1. CHECK DTC RELATING TO MISFIRE

- 1. Connect a Hi-Scan (Pro) to the data link connector.
- 2. Turn ignition to ON position and monitor other DTCs.

#### Is any DTC relating to misfire set?




Yes

Do all repairs associated with those codes before proceeding with this procedure.

#### 2. CHECK POWER TO IGNITION COIL

- 1. Turn ignition switch to OFF position and disconnect ignition coil connector.
- 2. Turn ignition switch to ON position.
- 3. Measure voltage between terminal 3 of the ignition coil harness connector and chassis ground.
  - · Specification: approximately B+



Is resistance within specification?



No

Repair open or short to chassis ground in harness.

#### 3. CHECK IGNITION COILS AND SPARK PLUG WIRES

- 1. Turn ignition switch to OFF position and disconnect the ignition coil connector.
- 2. Measure resistance of the primary coils and the secondary iginition coils.



P0350 : Ignition Coil No.1 through No.6

P0351: Ignition Coil No.1 P0352 : Ignition Coil No.2 P0353 : Ignition Coil No.3 P0354: Ignition Coil No.4 P0355 : Ignition Coil No.5 P0356: Ignition Coil No.6


Specification (Resistance):

terminal, or carbon tracking.

		,	
Temperature		IgnitionCoil Resistance	
(°C)	(°F)	Primary Coil (Ω)	Secondary Coil (kΩ)
20	68	0.74 $\pm$ 10% $\Omega$	13.3 $\pm$ 15% k $\Omega$

3. Disconnect plug wires and check spark plug wires for cracks, corroded

Are ignition coils and spark plug wires okay?



FZOF6057

FLB -183

#### 4. CHECK SPARK PLUG FOR PROPER OPERATION

- 1. Remove the spark plug.
- 2. Visually check the spark plug for carbon tracking, foreign materials (oil or fuel), damage, or cracking.
- 3. Measure the spark plug gap and check the spark plug for proper operation.
  - Specification (Air Gap): 1.0~1.1 mm (0.039~0.043 in)

#### Is spark plug okay?




No I

Repair or replace it.

#### 5. CHECK FOR OPEN IN HARNESS

- 1. Turn ignition switch to OFF and disconnect ECM connector.
- 2. [P0351 & P0354] Measure resistance between terminals 2 of ignition coil harness connector and 3 of ECM harness connector (C133-5).
- 3. [P0352 & P0355] Measure resistance between terminals 2 of ignition coil harness connector and 2 of ECM harness connector (C133-5).
- 4. [P0353 & P0356] Measure resistance between terminals 2 of ignition coil harness connector and 1 of ECM harness connector (C133-5).
  - Specification : below  $1\Omega$

Does each resistance indicate open?



no


Yes

Repair open in harness.

#### 6. CHECK FOR SHORT TO POWER HARNESS

- 1. Turn ignition switch to ON.
- [P0351 & P0354] Measure voltage between terminal 2 of ignition coil harness connector and chassis ground.
- 3. [P0352 & P0355] Measure voltage between terminal 1 of ignition coil harness connector and chassis ground.
- 4. [P0353 & P0356] Measure voltage between terminal 4 of ignition coil harness connector and chassis ground.
  - Specification: below 0.5V

#### Is voltage within specificaion?





No

Repair short to power in harness.


EZOF6058

#### FLB -184

#### 7. CHECK FOR SHORT TO GROUND IN HARNESS

- 1. Turn ignition switch to OFF.
- 2. [P0351 & P0354] Measure voltage between terminal 2 of ignition coil harness connector and chassis ground.
- 3. [P0352 & P0355] Measure voltage between terminal 1 of ignition coil harness connector and chassis ground.
- 4. [P0353 & P0356] Measure voltage between terminal 4 of ignition coil harness connector and chassis ground.
  - · Specification: infinite

Does each resistance indicate open?





No Repair short to chassis ground in harness.

#### 8. CHECK FIRST AND SECOND IGNITION SIGNAL PATTERNS

- 1. Reconnect ignition coil and ECM connectors.
- 2. Start engine and monitor ignition coil signal pattern.

Is signal pattern normal?



No Repair or replace it.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

ولین سامانه دیجیتال تعمیرکاران خودرو در ایران

EZOF6059

FLB -185

#### TROUBLESHOOTING FOR DTC E931E3FC

DTC	P0420	Catalyst System Efficiency Below Threshold (Bank 1)
DIC	P0430	Catalyst System Efficiency Below Threshold (Bank 2)

#### **DESCRIPTION**

The ECM uses dual oxygen sensors to monitor the efficiency of the manifold catalytic converter (warm-up catalytic converter). By monitoring the oxygen storage capacity of a catalyst, its efficiency can be indirectly calculated. The upstream (front) HO2S is used to detect the amount of oxygen in the exhaust gas before it enters the catalytic converter. A low voltage indicates high oxygen contents (lean air mixture). A high voltage indicates low oxygen contents (rich air mixture). When the catalyst efficiency drops, no chemical reaction takes place. This means the concentration of oxygen will be the same at the rear as it is at the front. The output voltage of the rear HO2S copies the voltage of the front HO2S. To monitor the system, the lean-to-rich switches of the front HO2S to the rear HO2S is counted. The ratio of rear switches to front switches is used to determine whether the catalyst is operating properly. An effective catalyst will have fewer rear switches than front switches, that is, a ratio closer to zero.

#### DTC DETECTING CONDITION

#### 1. DTC Description

The ECM calculates oscillation size of rear HO2S signal which respresents catalyst conversion properties. This oscillation size will determine if catalyst conversion is low due to aging or poisoning from leaded fuel or misfiring. The ECM sets P0420(Bank 1) or P0430(Bank 2) if the average of caculated oscillation size of rear HO2S signal during predetermined duration is higher than the predetermined threshold. If same error code is set in the next driving cycle, the ECM illuminates the MIL.

# 2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause
P0420 P0430	Detecting Condition  Detecting Condition  Based on oxgen storage capability  Enable condition  Catalyst temperature: 340~600 °C(644~1,112°F)  Engine coolant temperature > 70°C (158°F)  Engine speed: 800~2500 rpm  Air mass flow < 250mg/stroke  Lambda control within its limit  No misfire detected  Not transient condition  Threshoold Value  The signal ratio of front HO2S and rear HO2S in a load and speed range > 0.7 during 171 lambda controller cycles	Air leakage     HO2S     Fuel delivery system     Injector     Catalytic converter     ECM
	Limp-Home Function • None	

#### FLB -186

#### **INSPECTION PROCEDURE**

#### 1. CHECK DTC RELEAVANT TO HO2S/FUEL TRIM/MISFIRE

- 1. Connect Hi-Scan (Pro) to data link connector.
- 2. Turn ignition switch to ON and monitor any other DTCs relating to HO2S, fuel trim, or misfire.

Are any other DTCs also set?

No

Yes

Do all repairs associated with those codes before going to next step.

#### 2. CHECK AIR LEAKAGE

1. Check air leakage in exhaust system.

Is there any air leakage in exhasut system?

No

Yes

Repair or replace it.

#### 3. CHECK CATALYST CONVERTER AND HO2S FOR CONDITIONS

1. Thoroughly check catalyst and HO2S for contamination, deterioration or damage.

Is Catalyst converter or HO2S contaminated, deteriorated or damaged?

No

Yes

Repair or replace it.

#### 4. CHECK HO2S

- 1. Check front and rear HO2S for normal operation.
  - Refer to "DTC P0130 ~ P0160" for a detailed procedure.

Is front and rear HO2S normal?

Yes

No

Repair it.

#### 5. CHECK INJECTOR FOR NORMAL OPERATION

- 1. Start engine and check RPM decrease when disconnecting each injector connector in sequence.
- 2. Measure the decreasing engine RPM of all cylinders.

Is there any cylinder with no change in RPM or only a small RPM change?

EZOF0273

FLB -187

No

Yes

Repair or replace the injector of failed cylinder.

#### 6. CHECK FUEL LINE PRESSURE

- 1. Reconnect the ignition coils and spark plug connectors.
- 2. Release the fuel pressure and attach the fuel pressure gage to the delivery pipe.
  - To release the fuel presure, refer to "FUEL DELIVERY SYSTEM" section.
- 3. Start the engine and warm it up to normal operating temperature.
- 4. Check fuel line pressure at idle.
  - Specification (Fuel Pressure): 350 kpa (3.5 kg/cm², 49.8 psi)

Is fuel line pressure within specification?

Yes

No

Check fuel delivery system. (Refer to "FUEL DELIVERY SYSTEM" section)

#### 7. CHECK SIGNAL PATTERN OF FRONT AND REAR HO2S

- 1. Start engine and warm it up to normal operating temperature.
- 2. Using Hi-Scan (Pro), monitor both front HO2S and rear HO2S signals.

Do both signals of front and rear HO2S switch lean to rich or rich to lean similarly?

No

Yes

Replace manifold catalytic convertr.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.


EZOF0274

#### FLB -188

#### TROUBLESHOOTING FOR DTC EAR

DTC	P0444	Evap. Emission Control System-Purge Control Valve Circuit Open
-----	-------	--

#### **COMPINENT LOCATION**



#### EZOF505Z

#### **DESCRIPTION**

The evaporative emission control system prevents hydrocarbon (HC) vapors from the fuel tank from escaping into the atmosphere where they could form photochemical smog. Gasoline vapors are collected in the charcoal canister. The ECM controls the Purge Control Solenoid Valve (PCSV) to purge any collected vapors from the canister back to the engine for combustlon. This valve is actuated by the purge control signal from the ECM and controls fuel vapor from the canister to the intake manifold.

#### DTC DETECTING CONDITION

1. DTC Description

ECM sets DTC P0444 if the ECM detects that the PCSV control line is open.

2. Conditions for Setting the DTC


DTC	Detecting Condition & Limp Home	Possible Cause
P0444	Detecting Condition  • DTC Strategy  - Driver stage check  • Enable condition  - Battery voltage > 10V  • Threshold Value  - PCSV control line is open for 3 seconds	<ul><li>Open in PCSV circuit</li><li>PCSV</li><li>ECM</li></ul>

#### **SPECIFICATION**

PCSV Resistance : 24.5~27.5 at 20°C(68°F)

FLB -189

#### **SCHEMATIC DIAGRAM**



#### SIGNAL WAVE FROM

GENERAL SENSOR 10 V 2.0 mS
MIN:-552.0mV MAX: 55.3 V
80
40
40
HOLD ZOOM CURS MENU HELP

In normal operation, the PCSV opens and closes, depending on throttle angle and intake manifold vacuum. When it opens, fuel vapor is flushed from the canister and drawn into the intake manifold. To avoid a vacuum build-up in the canister, the canister close valve is normally held open to allow fresh air to replace the vapors drawn into the intake manifold. The given data is the signal waveform when PCSV operates normally. Note that the PCSV will not operate until the engine has reached normal operating temperature.

EZOF0293

#### **INSPECTION PROCEDURE**

#### 1. CHECK PCSV AND ECM CONNECTORS

- 1. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
  - Refer to "CONNECTOR INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

Are all connectors good?


Yes

No

Repair or replace it.

#### 2. CHECK PCSV RESISTANCE

- 1. Turn ignition switch to OFF and disconnect PCSV connector.
- 2. Measure resistance between the terminal 1 and 2 of PCSV connector.
  - Specification (PCSV resistance): 24.5 ~ 27.5  $\Omega$  at 20°C (68°F)



Is resistance within specification?




No

Replace PCSV.

#### 3. CHECK POWER TO PCSV

- 1. Turn ignition switch to OFF position and disconnect PCSV connector.
- 2. Turn ignition switch to ON position.
- 3. Measure voltage between terminal 1 of the PCSV harness connector and chassis ground.
  - Specification (Voltage): approximately B+



Is voltage within specification?

Yes

No


Repair open or short to chassis ground in harness.

EZOF603X

FLB -191

#### 4. CHECK FOR OPEN IN HARNESS

- 1. Turn ignition to OFF position, and then disconnect PCSV and ECM connector.
- 2. Measure resistance between terminal 2 of the PCSV harness connector and 42 of the ECM harness connector (C133-3).
  - Specification (Resistance): below  $1\Omega$



Does each resistance indicate continuity?



No Repair open in harness.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

EZOF603Y



شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



# **FUEL SYSTEM (G6BA-GSL 2.7)**

#### TROUBLESHOOTING FOR DTC ED2BD228

DTC	P0445	Evap. Emission Control System-Purge Control Valve Circuit Shorted
-----	-------	---

#### **DESCRIPTION**

Refer to DTC P0444

#### DTC DETECTING CONDITION

1. DTC Description

ECM sets DTC P0445 if the ECM detects that the PCSV control line is short to ground or short to battery line.

2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause
	Detecting Condition  • DTC Strategy  - Driver stage check	Short to ground or short to
P0445	<ul><li>Enable condition</li><li>Battery voltage &gt; 10V</li></ul>	<ul><li>battery line in PCSV circuit</li><li>PCSV</li></ul>
	- Battery voltage > 10 v	• ECM
	<ul> <li>Threshold Value</li> </ul>	0 \_
	PCSV control line is short to ground or battery line for 3 seconds	
(2025	شرخت دیجیتال حودر و سامانه (مستولیت ه	

#### **SPECIFICATION**

Refer to DTC P0444

SCHEMATIC DIAGRAM

Refer to DTC P0444

SIGNAL WAVE FORM

Refer to DTC P0444

FLB -193

#### **INSPECTION PROCEDURE**

#### 1. CHECK PCSV AND ECM CONNECTORS

- 1. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
  - Refer to "CONNECTOR INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

Are all connectors good?




No

Repair or replace it.

#### 2. CHECK PCSV RESISTANCE

- 1. Turn ignition switch to OFF and disconnect PCSV connector.
- 2. Measure resistance between the terminal 1 and 2 of PCSV connector.
  - Specification (PCSV resistance): 24.5 ~ 27.5  $\Omega$  at 20°C (68°F)



Is resistance within specification?




No

Replace PCSV.

#### 3. CHECK POWER TO PCSV

- 1. Turn ignition switch to OFF position and disconnect PCSV connector.
- 2. Turn ignition switch to ON position.
- Measure voltage between terminal 1 of the PCSV harness connector and chassis ground.
  - Specification (Voltage): approximately B+



Is voltage within specification?



No


Repair open or short to chassis ground in harness.

EZOF603X

#### **FUEL SYSTEM (G6BA-GSL 2.7)**

#### 4. CHECK FOR SHORT TO GROUND IN HARNESS

- Turn ignition switch to OFF position, and then disconnect PCSV and ECM connectors.
- 2. Measure resistance between terminal 2 of the PCSV harness connector and chassis ground.
  - Specification (Resistance): infinite



Does the resistance indicate open?




No

Repair short or short to chassis ground in harness.

#### 5. CHECK FOR SHORT TO POWER IN HARNESS

- Turn ignition switch to OFF position, and then disconnect PCSV and ECM connectors.
- 2. Turn ignition switch to ON position.
- 3. Measure voltage between terminal 2 of the PCSV harness connector and chassis ground.
  - Specification (Voltage): below 0.5V



Is voltage within specification?



No

Repair short to power in harness.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

EZOF603Z

FLB -195

#### TROUBLESHOOTING FOR DTC EFOED60D

DTC	P0501	Vehicle Speed Sensor A Range/ Performance [EURO-III/IV & JAPAN]	
-----	-------	---	--

#### **DESCRIPTION**

The Wheel Speed Sensor (WSS) generates a waveform with a frequency according to the speed of the vehicle. The signal generated by the WSS informs the ECM not only if the vehicle speed is low or high but also is stopped the vehicle or not. The ECM uses this signal to control the fuel injection, ignition timing, transmission/transaxle shift scheduling and torque converter clutch scheduling. Also the WSS signal is used to detect rough road driving condition.

#### DTC DETECTING CONDITION

#### 1. DTC Description


The ECM evaluates engine speed and mass air flow if there is no vehicle speed signal. This evaluation of both value will detect open circuit or short circuit error on wheel speed sensor. The ECM sets DTC P0501 if there is no vehicle speed signal from wheel speed sensor while both engine speed and mass air flow are higher than predetermined threshold during predetermined time. If the same error code is set in the next driving cycle, the ECM illuminates the MIL.

#### 2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause
(محدود) P0501	Detecting Condition  Detecting Condition  Detecting Condition  Check vehicle speed signal  Enable condition  Engine coolant temperature > 60 (140 )  Engine speed > 2,016 rpm  Mass air flow > 218 mg/stroke  No fuel cut-off  Threshoold Value  Vehick speed = 0 with high engine speed and high	Open or short in WSS circuit WSS ABS control module ECM
	load for 40 sec(M/T) or 60 sec(A/T)	


#### FLB -196

#### SCHEMATIC DIAGRAM (I) - WITH ABS



EZOF402N

#### SCHEMATIC DIAGRAM (II) - WITHOUT ABS



EZOF402M

FLB -197

#### INSPECTION PROCEDURE

#### 1. CHECK DTC RELATING TO FRONT RIGHT WSS OF ABS (OR WSS)

- 1. Connect a Hi-Scan (Pro) to the data link connector.
- 2. Turn the ignition switch ON and monitor any other DTCs relating to front right WSS of ABS (or WSS).

Is DTC relating to front right wheel speed sensor of ABS (or WSS)?

No

Yes

Do all repairs associated with those codes before proceeding with this procedure.

#### 2. CHECK ABS CONTROI MODULE (OR WSS) AND ECM CONNECTORS

- 1. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
  - Refer to "CONNECTOR INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

Are all connectors good?

Yes

No 🌑

Repair or replace it.

#### 3. CHECK FOR OPEN IN HARNESS

#### [WITH ABS]

- Turn ignition switch to OFF position, and then disconnect ABS control module and ECM connector.
- Measure resistance between terminal 3 of the ABS control module harness connector(E37) and 22 of the ECM harness connector (C133-4).
  - Specification (Resistance): below 1Ω

# ABS OFF ABS ECM

#### [WITHOUT ABS]

- Turn ignition switch to OFF position, and then disconnect WSS and ECM connector.
- 2. Measure resistance between terminal 1 of the WSS harness connector and 38 of the ECM harness connector (C133-4).
- 3. Measure resistance between terminal 2 of the WSS harness connector and 39 of the ECM harness connector (C133-4).
  - Specification (Resistance) : below  $1\Omega$

WSS

OFF

WSS

1 2
38 39

ECM

Does each resistance indicate continuity?

Yes

No

Repair open in harness.

EZOF604R

#### FLB -198

#### 4. CHECK FOR SHORT TO GROUND IN HARNESS

#### [WITH ABS]


- 1. Turn ignition switch to OFF position, and then disconnect ABS control module and ECM connector.
- 2. Measure resistance between terminal 3 of the ABS control module harness connector and chassis ground.
  - Specification (Resistance): infinite

# ABS Ω 3 22 ECM

#### [WITHOUT ABS]

- 1. Turn ignition switch to OFF position, and then disconnect WSS and ECM connector.
- 2. Measure resistance between terminal 1 of the WSS harness connector and chassis ground.
- 3. Measure resistance between terminal 2 of the WSS harness connector and chassis ground.
  - Specification (Resistance) : infinite

Does each resistance indicate open?



Yes

No

Repair short or short to chassis ground in harness.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

ولین سامانه دیجیتال تعمیرکاران خودرو در ایران

EZOF604S

FLB -199

#### TROUBLESHOOTING FOR DTC

DTC F	P0501	Vehicle Speed Sensor A Range/ Performance [EURO-II & LEAD]
-------	-------	--

#### **DESCRIPTION**

The vehicle Speed Sensor (VSS) generates a waveform with a frequency according to the speed of the vehicle. The signal generated by the VSS informs the ECM not only if the vehicle speed is low or high but also is stopped the vehicle or not. The ECM uses this signal to control the fuel injection, ignition timing, transmission/transaxle shift scheduling and torque converter clutch scheduling. Also the WSS signal is used to detect rough road driving condition.

#### DTC DETECTING CONDITION

1. DTC Description


The ECM evaluates engine speed and mass air flow if there is no vehicle speed signal. This evaluation of both value will detect open circuit or short circuit error on vehicle speed sensor. The ECM sets DTC P0501 if there is no vehicle speed signal from vehicle speed sensor while both engine speed and mass air flow are higher than predetermined threshold during predetermined time

#### 2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause
P0501	Detecting Condition  DTC Strategy Check vehicle speed signal  Enable condition Engine coolant temperature > 60 (140 ) Engine speed > 2,016 rpm Mass air flow > 218 mg/stroke No fuel cut-off  Threshoold Value Vehick speed = 0 with high engine speed and high load for 40 sec(M/T) or 60 sec(A/T)	<ul> <li>Open or short in VSS circuit</li> <li>VSS</li> <li>ABS control module</li> <li>ECM</li> </ul>

#### FLB -200

#### **SCHEMATIC DIAGRAM**



FLB -201

#### **INSPECTION PROCEDURE**

#### 1. CHECK VSS AND ECM CONNECTORS

- 1. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
  - Refer to "CONNECTOR INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.


#### Are all connectors good?



No Repair or replace it.

#### 2. CHECK POWER TO VSS

- 1. Turn ignition switch to OFF position, and then disconnect CMPS connector.
- 2. Turn ignition switch to ON position.
- 3. Measure voltage between terminal 1(2) of the VSS harness connector and chassis ground.
  - Specification (Voltage): approximately B+



Is voltage within specification?




No

Repair open or short to chassis ground in harness.

### 3. CHECK FOR OPEN IN HARNESS Lineary dilateral to the last of the

- Turn ignition switch to OFF position, and then disconnect VSS and ECM connector.
- 2. Measure resistance between terminal 3 of the VSS harness connector and 22 of the ECM harness connector (C133-4).
  - Specification (Resistance): below 1Ω



Does each resistance indicate continuity?



No

Repair open in harness.


EZOF001E

#### **FUEL SYSTEM (G6BA-GSL 2.7)**

#### 4. CHECK FOR SHORT TO GROUND IN HARNESS

- 1. Turn ignition switch to OFF position, and then disconnect VSS and ECM connector.
- 2. Measure resistance between terminal 3 of the VSS harness connector and chassis ground.
- 3. Measure resistance between terminal 3 and 2(1) of the VSS harness connector.
  - Specification (Resistance): infinite

Does each resistance indicate open?





No

Repair short or short to chassis ground in harness.

#### 5. CHECK FOR SHORT TO POWER IN HARNESS

- Turn ignition switch to OFF position, and then disconnect VSS and ECM connectors.
- 2. Turn ignition switch to ON position.
- 3. Measure voltage between terminal 3 of the VSS harness connector and chassis ground.
  - Specification (Voltage): below 0.5V

ON VSS

2(1) 3 1(2) B+ V

ECM

( ):5M/T

Is voltage within specification?



No

Repair short to power in harness.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.


EZOF001F

FLB -203

#### TROUBLESHOOTING FOR DTC EAFF213C

DT	С	P0506	Idle Air Control System - rpm Lower Than Expected
----	---	-------	---

#### **COMPONENT LOCATION**



EZOF505Y

#### **DESCRIPTION**

The Idle Speed Control Actuator (ISCA) is installed on the intake manifold and controls the intake airflow that is bypassed around the throttle plate to keep constant engine speed when the throttle valve is closed. The function of the ISCA is to maintain idle speed according to various engine loads and conditions, and also to provide additional air during starting. The ISCA consists of an opening coil, a closing coil, and a permanent magnet. Based on information from various sensors, the ECM controls both coils by grounding their control circuits. According to the control signals from the ECM, the valve rotor rotates to control the by pass airflow into the engine.

#### DTC DETECTING CONDITION

#### 1. DTC Description

The ECM monitors engine speed deviation from the target idle engine speed when the vehicle is stopped and the idle speed valve opening is stable.

The ECM sets DTC P0506 if the difference to the target idle engine speed is lower than the predetermined threshold. If the same error code is set in the next driving cycle, the ECM illuminates the MIL.

# FUEL SYSTEM (G6BA-GSL 2.7)

#### 2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause
P0506	Detecting Condition  DTC Strategy  Monitoring of unplausible idle speed  Enable condition  Minimum time after start = 15 seconds  Canister purge control < 50%  Throttle is fully closed (Idle state)  Vehicle speed: 0 kph  Engine coolant temperature > 75 (167 )  Engine load < 280 mg/stroke	<ul> <li>ISCA</li> <li>TPS</li> <li>Intake hose</li> <li>Carbon fouled throttle plate</li> <li>Accelerator cable adjusted improperly</li> <li>ECM</li> </ul>
	Threshold Value     Target idle speed-Engine speed > 100rpm (Engine speed too low) for 25 seconds	

#### **SPECIFICATION**

#### **TPS**


Throttle Position	Output Voltage
C.T (IDLE)	0.2 ~ 0.8 V
W.O.T	4.3 ~ 4.8 V
عیتال خودرو سامانه (مسئولیت محدود)	شرکت دیج

#### **ISCA**


Temperature		ISCA Coil #1 (OPEN)	ISCA Coil #2 (CLOSE)
( )	( )	Resistance( )	Resistance( )
20	68	14.9 ~ 16.1	17.0 ~ 18.2

FLB -205

#### **SCHEMATIC DIAGRAM**



#### SIGNAL WAVE FORM



The above waveforms are the voltage signals generated when ISCA operates. This ISCA type is duty type and the time ratio opened determines duty amount. The left side is the waveform of ISCA Opening coil at idle. The right side is the waveform of ISCA Closing coil at idle.

EFAE0352

#### FLB -206

#### **INSPECTION PROCEDURE**

- 1. CHECK DTC RELATING TO TPS, MAFS, INJECTOR, PCSV, OR ISCA
- 1. Connect a Hi-Scan (Pro) to the data link connector.
- 2. Turn ignition switch to ON position and monitor any other DTCs.

Are any other DTC relating to TPS, MAFS, injector, PCSV, or ISCA also set?

No

Yes

Do all repairs associated with those codes before proceeding with this procedure.

#### 2. CHECK FREE PLAY OF ACCELERATOR CABLE

- 1. Turn ignition switch to OFF position.
- 2. Check the free play of the accelerator cable.
  - Specifications: 1.0~2.0 mm (0.0039~0.0079 in)

Is free play within specification?

Yes

No

Adjust cable.

#### 3. CHECK TPS SIGNAL

- 1. Turn ignition switch to ON position.
- 2. Using the Hi-Scan (Pro), monitor the TPS signals while slowly opening the throttle.
  - Specification (Voltage):

0.2 ~ 0.8 V at C.T (IDLE)

4.3 ~ 4.8 V at W.O.T

Is signal within specification?

Yes

No

Replace the TPS.

#### 4. VISUALLY CHECK ISCA FOR CONNECTOR CONDITION

- 1. Turn ignition switch to OFF position and disconnect the ISCA connector.
- 2. Thoroughly check the ISCA for loose, bent, corroded, contaminated, deteriorated or damaged connectors.
  - Refer to "CONNECTOR INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

Is any problem present?

Yes

No

Repair or replace it.


BFGE604T

FLB -207

#### 5. CHECK ISCA RESISTANCE

- 1. Turn ignition switch to OFF position and then disconnect ISCA connector.
- 2. Measure resistance between terminals 2 and 3 of the ISCA closing coil.
- 3. Measure resistance between terminals 1 and 2 of the ISCA opening coil.
  - Specification (ISCA resistance):

Temperature		ISCA Coil #1 (OPEN)	ISCA Coil #2 (CLOSE)
(°C)	(°F)	Resistance (Ω)	Resistance (Ω)
20	68	14.9 ~ 16.1	17.0 ~ 18.2



Is each resistance within specification?




No Replace ISCA.

#### 6. CHECK ISCA FOR NORMAL OPERATION

- 1. Remove ISCA from throttle body and check for blockage and sticking.
- Connect terminal 2 of the ISCA connector to a 12V power supply.
   One at a time, momentarily ground terminal 1 of the opening coil and terminal 3 of the closing coil while verifying that the valve closes when the closing coil is grounded and that the valve opens when opening coil is grounded.
- Repeat several times to ensure reliability.



While ISCA is removed, inspect the throttle body for obstructions in the idle circuit ports. Repair or replace it.



Is ISCA working properly?



No Replace ISCA.

#### 7. CHECK INTAKE HOSE AND THROTTLE PLATE FOR BLOCKAGE

1. Visually check the intake hose and throttle plate for blockage or carbon deposits.

Is the passage of the intake hose or the throttle plate blocked?



No Clean or replace it.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

EZOF604U

#### **FUEL SYSTEM (G6BA-GSL 2.7)**

#### TROUBLESHOOTING FOR DTC E7027B5F

DTC	P0507	Idle Air Control System - rpm Higher Than Expected
-----	-------	--

#### **DESCRIPTION**

Refer to DTC P0506

#### DTC DETECTING CONDITION

1. DTC Description

The ECM monitors engine speed deviation from the target idle engine speed when the vehicle is stopped and the idle speed valve opening is stable.

The ECM sets DTC P0507 if the difference to the target idle engine speed is higher than the predetermined threshold. If same error code is set in the next driving cycle, the ECM illuminates the MIL.

#### 2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause
P0507	<ul> <li>Detecting Condition</li> <li>DTC Strategy <ul> <li>Monitoring of unplausible idle speed</li> </ul> </li> <li>Enable condition <ul> <li>Minimum time after start = 15 seconds</li> <li>Canister purge control &lt; 50%</li> <li>Throttle is fully closed (Idle state)</li> <li>Vehicle speed: 0 kph</li> <li>Engine coolant temperature &gt; 75 (167)</li> <li>Engine load &lt; 280 mg/stroke</li> </ul> </li> </ul>	<ul> <li>ISCA</li> <li>TPS</li> <li>Air leakage intake system</li> <li>Vacuum hose and PCV</li> <li>PCSV</li> <li>Accelerator cable adjusted improperly</li> <li>ECM</li> </ul>
	<ul> <li>Threshold Value</li> <li>Engine speed-Target idle speed &gt; 200rpm (Engine speed too high) for 25 seconds</li> </ul>	

#### **SPECIFICATION**

Refer to DTC P0506

**SCHEMATIC DIAGRAM** 

Refer to DTC P0506

SIGNAL WAVE FORM

Refer to DTC P0506

FLB -209

#### **INSPECTION PROCEDURE**

- 1. CHECK DTC RELATING TO TPS, MAFS, INJECTOR, PCSV, OR ISCA
- 1. Connect a Hi-Scan (Pro) to the data link connector.
- 2. Turn ignition switch to ON position and monitor any other DTCs.

Are any other DTC relating to TPS, MAFS, injector, PCSV, or ISCA also set?

No

Yes

Do all repairs associated with those codes before proceeding with this procedure.

#### 2. CHECK FREE PLAY OF ACCELERATOR CABLE

- 1. Turn ignition switch to OFF position.
- 2. Check the free play of the accelerator cable.
  - Specifications: 1.0~2.0 mm (0.0039~0.0079 in)

Is free play within specification?

Yes

No 🌑

Adjust cable.

#### 3. CHECK TPS SIGNAL

- Turn ignition switch to ON position.
- 2. Using the Hi-Scan (Pro), monitor the TPS signals while slowly opening the throttle.
  - Specification (Voltage):

0.2 ~ 0.8 V at C.T (IDLE)

4.3 ~ 4.8 V at W.O.T

Is signal within specification?

Yes

No

Replace the TPS.

#### 4. VISUALLY CHECK ISCA FOR CONNECTOR CONDITION

- 1. Turn ignition switch to OFF position and disconnect the ISCA connector.
- 2. Thoroughly check the ISCA for loose, bent, corroded, contaminated, deteriorated or damaged connectors.
  - Refer to "CONNECTOR INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

Is any problem present?

Yes

No

Repair or replace it.


BFGE604T

#### FLB -210

#### 5. CHECK ISCA RESISTANCE

- 1. Turn ignition switch to OFF position and then disconnect ISCA connector.
- 2. Measure resistance between terminals 2 and 3 of the ISCA closing coil.
- 3. Measure resistance between terminals 1 and 2 of the ISCA opening coil.
  - Specification (ISCA resistance):

Temperature		ISCA Coil #1 (OPEN)	ISCA Coil #2 (CLOSE)
(°C)	(°F)	Resistance (Ω)	Resistance (Ω)
20	68	14.9 ~ 16.1	17.0 ~ 18.2



Is each resistance within specification?



No Replace ISCA.


#### 6. CHECK ISCA FOR NORMAL OPERATION

- 1. Remove ISCA from throttle body and check for blockage and sticking.
- Connect terminal 2 of the ISCA connector to a 12V power supply.
   One at a time, momentarily ground terminal 3 of the opening coil and terminal 1 of the closing coil while verifying that the valve closes when the closing coil is grounded and that the valve opens when opening coil is grounded.
- 3. Repeat several times to ensure reliability.



While ISCA is removed, inspect the throttle body for obstructions in the idle circuit ports. Repair or replace it.

ولين سامانه ديجيتال تعميركا ?Is ISCA working properly





No Replace ISCA.

#### 7. CHECK VACUUM HOSE AND PCV

- 1. Visually check for any split, disconnected or perforated vacuum hose.
- 2. Also, check PCV valve for proper operation.

Are vacuum hose and PCV okay?

EZOF604W

FLB -211



No Repair or replace it.

#### 8. CHECK PCSV FOR NORMAL OPERATION

- 1. Turn ignition switch to OFF position and disconnect the hose leading from the PCSV to the intake manifold at PCSV.
- 2. Draw a vacuum at the nipple and verify that the PCSV holds vacuum.
- 3. Turn ignition switch to ON position and ground the PCSV connector terminal 2 (should hear a faint "click" from PCSV).
- 4. The Vacuum should bleed off.
- 5. Repeat this procedure 4 or 5 times to ensure PCSV reliability.

#### Is PCSV working properly?



No Repair or replace it.

#### 9. CHECK GASKETS, SEALS, AND VALVE FOR CRACKS OR LEAKS

- 1. Visually inspect the following items:
  - Gasket between the intake manifold and the surge tank
  - Gasket between the intake manifold and the cylinder head
  - Seals between the intake manifold and the fuel injectors
  - Seals between the surge tank and the PCV valves
  - Crankcase ventilation valve and/or system for leaks

#### Are the above items okay?



No

Repair or replace it.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

BFGE604X

#### **FUEL SYSTEM (G6BA-GSL 2.7)**

#### TROUBLESHOOTING FOR DTC

DTC	P0551	Power Steering Pressure Sensor/Switch Circuit Range/Performance
-----	-------	---


#### **DESCRIPTION**

The power steering system increases steering performance and improves steering feel and power-saving effectiveness. The power steering switch senses the power steering load into low/high voltage. Then the ECM controls the idle speed control motor by using this input signal.

#### **DTC DETECTING CONDITION**

DTC	Detecting Condition & Limp Home	Possible Cause
	Detecting Condition  • DTC Strategy  - Power steering switch check	
P0506	<ul> <li>Enable condition</li> <li>Engine coolant temperature &gt; 75°C (167°F)</li> <li>No vehicle speed error</li> <li>Power steering switch ON</li> </ul>	<ul> <li>Open or short in power steering switch circuit</li> <li>Power steering switch</li> <li>ECM</li> </ul>
QI	<ul> <li>Threshold Value</li> <li>Power steering is ON with high vehicle speed ( &gt; 100 km/h) for more than 25.5 secibds</li> </ul>	Q <sup>O</sup>

#### **SCHEMATIC DIAGRAM**



EZOF403I

FLB -213

#### **INSPECTION PROCEDURE**

#### 1. CHECK POWER STEERING SWITCH AND ECM CONNECTORS

- 1. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
  - Refer to "CONNECTOR INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.


Are all connectors good?



No Repair or replace it.

#### 2. CHECK FOR SHORT TO GROUND IN HARNESS

- 1. Turn ignition switch to OFF position, and then disconnect power steering switch and ECM connectors.
- 2. Measure resistance between terminal 1 of the power steering switch harness connector and chassis ground.
  - · Specification (Resistance): infinite



Does the resistance indicate open?


Yes

No

Repair short or short to chassis ground in harness.

#### 3. CHECK FOR SHORT TO POWER IN HARNESS

- 1. Turn ignition switch to OFF position, and then disconnect main relay and ECM connectors.
- 2. Turn ignition switch to ON position.
- 3. Measure voltage between terminal 1 of the power steering switch harness connector and chassis ground.
  - Specification (Voltage): below 0.5V



Is voltage within specification?



No


Repair short to power in harness.

EZOF604Y

#### **FUEL SYSTEM (G6BA-GSL 2.7)**

#### 4. CHECK FOR OPEN IN HARNESS

- 1. Turn ignition switch to OFF position, and then disconnect main relay and ECM connectors.
- 2. Measure resistance between terminal 1 of the power steering switch harness connector and terminal 26 of ECM harness connector (C133-3).
  - Specification (Resistance): below  $\Omega$



Does resistance indicate continuity?



No Repair open in harness.


Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

EZOF604Z



شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



FLB -215

#### TROUBLESHOOTING FOR DTC EC43E401

DTC	P0560	System Voltage
-----	-------	----------------

#### **DESCRIPTION**

The ECM provides ground to one side of the coil of the main relay and the other side is connected to the battery. The ECM monitors battery voltage and the voltage after the main relay.

#### DTC DETECTING CONDITION

#### 1. DTC Description


The ECM measures the voltage from ignition key and from main relay repectively and compares two voltages. This comparision will watch if the Main Relay has switched and remains on after ignition Key-On and if it has switched off after the ignition Key-Off. The ECM sets DTC P0560 if the voltage after Main Relay is lower than a predetermined threshold after ignition key-on or higer than a perdetermined threshold after ignition key-off.

#### 2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause
P0560	<ul> <li>Detecting Condition</li> <li>DTC Strategy</li> <li>Comparison battery voltage with voltage after main relay</li> <li>Enable condition</li> <li>Battery voltage &gt; 10V</li> <li>IG ON</li> </ul>	<ul> <li>Open or short in main relay circuit</li> <li>Main relay</li> <li>ECM</li> </ul>
ر ایران	<ul> <li>Threshold Value</li> <li>Voltage after main relay &lt; 6V for 1.5 seconds</li> </ul>	

# FLB -216

#### **SCHEMATIC DIAGRAM**



FLB -217

### **INSPECTION PROCEDURE**

#### 1. CHECK MAIN RELAY AND ECM CONNECTORS

- 1. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
  - Refer to "CONNECTOR INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

Are all connectors good?

Yes

No Repair or replace it.

### 2. CHECK MAIN RELAY

- 1. Remove the main relay.
- 2. Apply power to the main relay terminal 2 and ground terminal 4.
- 3. Check if the main relay works well when it is energized. (If the main relay works normally, a clicking sound can be heard.)

Does the main relay operate normally?

Yes

No Replace main relay.

### 3. CHECK POWER TO MAIN RELAY

- 1. Remove the main relay.
- 2. Turn ignition switch to ON position.
- 3. Measure the voltage between terminal 2 of the main relay harness connector and chassis ground.
- 4. Measure the voltage between terminal 5 of the main relay harness connector and chassis ground.
  - · Specification : approximately B+

Is voltage within specification?




No

Repair open or short to chassis ground in harness.

#### 4. CHECK FOR SHORT TO GROUND IN HARNESS

- 1. Turn ignition switch to OFF position, and then disconnect main relay and ECM connectors.
- 2. Measure resistance between terminal 4 of the main relay harness connector and chassis ground.
  - Specification (Resistance): infinite



RELAY

**ECM** 

Does the resistance indicate open?

EZOF6040

## WWW.DIGITALKHODRO.COM

## **FUEL SYSTEM (G6BA-GSL 2.7)**


Yes

No

Repair short or short to chassis ground in harness.

## 5. CHECK FOR SHORT TO POWER IN HARNESS

- 1. Turn ignition switch to OFF position, and then disconnect main relay and ECM connectors.
- 2. Turn ignition switch to ON position.
- 3. Measure voltage between terminal 4 of the main relay harness connector and chassis ground.
  - Specification (Voltage): below 0.5V



Is voltage within specification?




No

Repair short to power in harness.

## 6. CHECK FOR OPEN IN HARNESS

- Turn ignition switch to OFF position, and then disconnect main relay and ECM connectors.
- 2. Measure resistance between terminal 4 of the main relay harness connector and terminal 23 of ECM harness connector (C133-2).
  - Specification (Resistance): below Ω



Does resistance indicate continuity?

Yes

No

Repair open in harness.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

EZOF6041

FLB -219

## TROUBLESHOOTING FOR DTC EEC9A03E

DTC	P0605	Internal Control Module Read Only Memory (ROM) Error
-----	-------	--

#### **DESCRIPTION**

A malfunction is detected by using a checksum technique for verifying data. The digital data is composed of zeros and ones. A checksum is the total of all ones in a string of data. By comparing the checksum value with a stored value, a malfunction can be detected.

## DTC DETECTING CONDITION

1. DTC Description

The ECM monitors RAM areas and communication connections between microcontroller and output drivers and sets DTC P0605 if failure is detected.

If same error code is set in the next driving cycle, the ECM will illuminate the MIL.

2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause
91:	Detecting Condition  • DTC Strategy  - ECM ROM error	ECM internal fault
P0 <mark>605</mark>	Enable condition     IG ON	ECM hardware or software error
الداد	Threshold Value     Internal check (for 100 msec)	

#### **INSPECTION PROCEDURE**

## 1. CHECK ECM SOFTWARE VERSION

- 1. Connect a Hi-Scan (Pro) to the data link connector.
- 2. Turn ignition to ON position.
- 3. Check ECM software version.

#### Is the version newest one?



No Upgrade the ECM software.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

BFGE605B

## FLB -220 FUEL SYSTEM (G6BA-GSL 2.7)

### TROUBLESHOOTING FOR DTC

DTC	P0650	Malfunction Indicator Lamp (MIL) Control Circuit Malfunction
-----	-------	--

#### **DESCRIPTION**

The Malfunction Indicator Lamp (MIL), which is located in the instrument cluster, comes on to notify the driver that there may be a problem with the vehicle and that service is needed. Immediately after the ignition switch turns on, the malfunction indicator lamp is lit for 5 seconds to indicate that the MIL operates normally.

#### DTC DETECTING CONDITION


1. DTC Description

ECM sets DTC P0650 if the ECM detects that the MIL control line is open or short circuit to ground or battery line.

2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause
P0650	Detecting Condition  • DTC Strategy  - Driver stage check  • Enable condition  - Battery voltage > 10V  • Threshold Value	<ul> <li>Open circuit in MIL circuit</li> <li>Short to ground or battery line in MIL circuit</li> <li>MIL</li> <li>ECM</li> </ul>
ايران	- MIL control line is open or shor to ground or battery line for 20 seconds	

#### SCHEMATIC DIAGRAM



EZOF402R

FLB -221

### **INSPECTION PROCEDURE**

#### 1. PROBLEM VERIFICATION

- 1. Start the engine.
- 2. Check that the MIL illuminates for several seconds and then goes out.

Does the MIL illuminate for several seconds and then go out?



No Upgrade the ECM software.

#### 2. CHECK POWER TO MIL


1. Turn ignition switch to OFF position and disconnect MIL connector.



MIL connector is a part of instrument panel connector.

- 2. Turn ignition switch to ON position.
- 3. Measure voltage between terminal 2 of the MIL harness connector and chassis ground (M10-2).
  - Specification (Voltage): approximately B+





Yes


No

Repair open or short to chassis ground in harness.

## 3. CHECK FOR SHORT IN HARNESS TO GROUND

- 1. Turn ignition switch to OFF position, and then disconnect MIL and ECM connector.
- 2. Measure resistance between terminal 14 of MIL harness connector (M10-1) and chassis ground.
  - · Specifications: infinite

Does resistance indicate open?



Yes

No

Repair short to chassis ground in harness.

EZOF605C

## **FUEL SYSTEM (G6BA-GSL 2.7)**

#### 4. CHECK FOR OPEN IN HARNESS

- Turn ignition switch to OFF position, and then disconnect MIL and ECM connector.
- 2. Measure resistance between terminals 14 of MIL harness connector (M10-1) and 20 of ECM harness connector (C133-2).
  - Specifications: below 1Ω

MIL M10-1(14) M10-2(2) H20 ECM

Does resistance indicate continuity?




No Repair open in harness.

### 5. CHECK FOR SHORT TO POWER IN HARNESS

- Turn ignition switch to OFF position, and then disconnect MIL and ECM connector.
- 2. Turn ignition switch to ON position.
- 3. Measure voltage between terminal 14 of MIL harness connector (M10-1) and chassis ground.
- Specification: below 0.5V

Is voltage within specification?





No

Repair short to power in harness.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

EZOF605D

FLB -223

## TROUBLESHOOTING FOR DTC EB13E3AA

DTC	P1166	HO2S System-Lambda Controller at the Limit (Bank 1)
Dic	P1167	HO2S System-Lambda Controller at the Limit (Bank 2)

### **DESCRIPTION**

The Lambda closed-loop control system is included in the engine's control system. The control system regulates the lambda upstream with the HO2S signal. Rich mixtures generate the high concentrations of CO, H2, and HC. Lean mixtures generate the high concentrations of NOx, and free oxygen.

#### DTC DETECTING CONDITION

### 1. DTC Description

If the lambda controller reaches to the maximum or minimum threshold, then no more feedback control is possible and emission will be increased. The ECM sets DTC P1166(Bank 1) or P1167(Bank 2) if no proportional fuel adaptation occurs for a defined time after the lambda controller reached to minimum or maximum threshold. If the same error code is set in the next driving cycle, the ECM illuminates the MIL.

## 2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause
P1166 P1167	Detecting Condition  DTC Strategy  Monitoring deviation of lambda controller  Enable condition PCSV closed Engine coolant temperatue > 60°C(140°F)  Threshold Value Lambda controller on max. (+32%) or min. limit (-32%) for 2 minutes	<ul> <li>PCSV</li> <li>Air leakage</li> <li>Fuel pressure</li> <li>Injector</li> <li>Front HO2S</li> <li>ECM</li> </ul>

## **FUEL SYSTEM (G6BA-GSL 2.7)**

### FLB -224

## **INSPECTION PROCEDURE**

- 1. CHECK DTC RELATING TO HO2S, FUEL SYSTEM, EVAP. SYSTEM, OR IGNITION SYSTEM
- 1. Connect a Hi-Scan (Pro) to the data link connector.
- 2. Turn the ignition switch ON and monitor any other DTCs relating to CKPS.

Are DTC relating to HO2S, fuel system, EVAP. System, or ignition system set?

No

Yes

Do all repairs associated with those codes before proceeding with this procedure.

#### 2. CHECK AIR LEAKAGE AND CONNECTIONS TO DYNAMIC CHAMBER

- Check for air leakage and bad connections to the engine dynamic chamber (especially PCV, PCSV, ISCA, throttle body, intake manifold, brake booster, and oil filler cap).
  - · Refer to "EC" group.

## Are all connections okay?

Yes

No

Repair or replace it.

#### 3. CHECK PCSV

- 1. Disconnect the PCSV connector and the EVAP hose (PCSV side) between the PCSV and the canister.
- 2. Check vacuum at the PCSV.
  - Refer to "EC" group.

## Is PCSV normal?

Yes

No

Replace it.

#### 4. CHECK FUEL LINE PRESSURE

- 1. Release the fuel pressure and attach the fuel pressure gage to the delivery pipe.
  - To release the fuel presure, refer to "FUEL DELIVERY SYSTEM" section.
- 2. Start the engine and warm it up to normal operating temperature.
- 3. Check fuel line pressure at idle.
  - Specification (Fuel Pressure): 350 kpa (3.5 kg/cm², 49.8 psi)

Is fuel line pressure within specification?

Yes

No

Check fuel delivery system.

(Refer to "FUEL DELIVERY SYSTEM" section)

EZOF605E

FLB -225

#### 5. CHECK INJECTOR FOR NORMAL OPERATION

- 1. Start the engine and check the engine RPM decrease when disconnecting each injector connector in sequence.
- 2. Measure the decreasing engine RPM of all cylinders.

Is there any cylinder with no change in RPM or only a small RPM change?

No

Yes Repair or replace it.

## 6. CHECK FRONT HO2S

1. Temporarily install a good HO2S and check for proper operation.

Is problem corrected?

No

Yes Replace it.

## 7. CHECK ECM INPUT SIGNALS RELATING TO MAFS, TPS, AND ECTS

1. Check for ECM input signals from the MAFS, TPS, and ECTS.

Are input signals normal?

Yes

No

Replace all failed parts.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

BFGE605F


## **FUEL SYSTEM (G6BA-GSL 2.7)**

## FLB -226

### TROUBLESHOOTING FOR DTC E

DTC	P1372	Segment Time Acquisition Incorrect
-----	-------	------------------------------------

#### **COMPONENT LOCATION**



EZOF6025

#### **DESCRIPTION**

A misfire induces a decrease in the engine speed and causes a variation in the segment period. Therefore, misfiring detection is based on the observation of this variation of the segment period.

## DTC DETECTING CONDITION

## DTC Description

Because of the tolerance in mechanical machining and assembling process of the target wheel, the duration of each segment are not always same but differ from segment to segment on the same engine. And this irregular segment duration can disturb misfiring detection which is based on the difference of engine rotational speed between the firing and the misfiring cylinder. The ECM compares segment duration of 6 cylinders during fuel cut-off and deceleration period. With this comparison ECM perform segment adaptation to adapt the difference of each segment duration. The ECM sets DTC P1372 if any of segment adaptation value is on the limit.

## 2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause
P1372	Detecting Condition  • DTC Strategy  - Monitor segment time adaptation  • Threshold Value  - Segment adaptation value is at the limit (= 5/1000)	<ul><li>Installation of CKPS</li><li>Improperly installed target wheel</li><li>ECM</li></ul>

FLB -227

### **INSPECTION PROCEDURE**

#### 1. CHECK DTC RELATING TO CKPS

- 1. Connect Hi-Scan(Pro) to data link connector.
- 2. Turn ignition switch to ON and monitor DTCs relating to CKPS

## Are DTCs relating to CKPS also set?



Yes

Do all repairs associated with those codes before proceeding with this procedure.

#### 2. CHECK INSTALLATION OF CKPS AND SENSOR WHEEL

- 1. Turn ignition switch to OFF and disconnect CKPS connector.
- 2. Check sensor wheel for damaged teeth, crack, improper installation and measure the clearance between CKPS and sensor wheel with a depth gauge.
- 3. Check CKPS for loose, bent, corroded, contaminated, deteriorated or damaged connector.
  - Refer to "Engine Mechanical System".

### Are CKPS and sensor wheel okey?

Yes

No

Repair or replace it.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

ولین سامانه دیجیتال تعمیرکاران خودرو در ایران


EZOF6026

## **FUEL SYSTEM (G6BA-GSL 2.7)**

## TROUBLESHOOTING FOR DTC E

DTC P1505	Idle Charge Actuator Signal Low of Coil #1
-----------	--

#### **COMPONENT LOCATION**



EZOF505Y

#### **DESCRIPTION**

The Idle Speed Control Actuator (ISCA) is installed on the intake manifold and controls the intake airflow that is bypassed around the throttle plate to keep constant engine speed when the throttle valve is closed. The function of the ISCA is to maintain idle speed according to various engine loads and conditions, and also to provide additional air during starting. The ISCA consists of an opening coil, a closing coil, and a permanent magnet. Based on information from various sensors, the ECM controls both coils by grounding their control circuits. According to the control signals from the ECM, the valve rotor rotates to control the by pass airflow into the engine.

#### DTC DETECTING CONDITION

1. DTC Description

ECM sets DTC P1505 if the ECM detects that the ISCA (OPEN) control line is open or short to ground.

2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause
P1505	Detecting Condition  • DTC Strategy  - Criver stage check (Coil #1)  • Enable condition  - Battery voltage > 10V  • Threshold Value  - ISCA(Coil #1) control line is open or short to ground for 1second	<ul> <li>Open or short to ground in ISCA circuit</li> <li>ISCA</li> <li>ECM</li> </ul>

FLB -229

### **SPECIFICATION**


#### **TPS**

Throttle Position	Output Voltage
C.T (IDLE)	0.2 ~ 0.8 V
W.O.T	4.3 ~ 4.8 V

### **ISCA**


Tempe	erature	ISCA Coil #1 (OPEN)	ISCA Coil #2 (CLOSE)	
( )	( )	Resistance( )	Resistance( )	
20	68	14.9 ~ 16.1	17.0 ~ 18.2	


### **SCHEMATIC DIAGRAM**



EZOF402O

### SIGNAL WAVE FORM





The above waveforms are the voltage signals generated when ISCA operates. This ISCA type is duty type and the time ratio opened determines duty amount. The left side is the waveform of ISCA Opening coil at idle. The right side is the waveform of ISCA Closing coil at idle.

حيجيناك خورواو

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



FLB -231

### **INSPECTION PROCEDURE**

#### 1. CHECK ISCA AND ECM CONNECTORS

- 1. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
  - Refer to "CONNECTOR INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

#### Are all connectors good?



No Repair or replace it.

#### 2. CHECK ISCA RESISTANCE

- 1. Turn ignition switch to OFF position and then disconnect ISCA connector.
- 2. Measure resistance between terminals 2 and 1 of the ISCA opening coil.
  - Specification (ISCA resistance):

(°C) (°F) Resistance (Ω) Resistance (Ω) 20 68 14.9 ~ 16.1 17.0 ~ 18.2		Temperature (°C) (°F)		ISCA Coil #1 (OPEN)	ISCA Coil #2 (CLOSE)
20 68 14.9 ~ 16.1 17.0 ~ 18.2				Resistance (Ω)	Resistance (Ω)
		20	68	14.9 ~ 16.1	17.0 ~ 18.2

3. Inspect the signal waveform of the ISCA closing coil using a Hi-Scan (Pro).

Refer to "SIGNAL WAVEFORM" for more information.

## Is the resistance within specification?




No

Replace ISCA.

## 3. CHECK POWER TO ISCA

Is voltage within specification?

- 1. Turn ignition switch to OFF position and disconnect ISCA connector.
- 2. Turn ignition switch to ON position.
- 3. Measure the voltage between terminal 2 of the ISCA harness connector and chassis ground.
  - · Specification: approximately B+



**ISCA** 

-З

47

**ECM** 

46

OFF



No

Repair open or short to chassis ground in harness.


EZOF605K

## **FUEL SYSTEM (G6BA-GSL 2.7)**

## FLB -232

#### 4. CHECK FOR OPEN IN HARNESSS

- 1. Turn ignition to OFF position, and then disconnect ISCA and ECM connector.
- 2. Measure resistance between terminal 1 of the ISCA harness connector and 46 of the ECM harness connector (C133-3).
  - Specification (Resistance): below 1Ω




Does the resistance indicate continuity?

Yes

No Repair open in harness.

### 5. CHECK FOR SHORT TO GROUND IN HARNESS

- 1. Turn ignition switch to OFF position, and then disconnect ISCA and ECM connector.
- 2. Measure resistance between terminal 1 of the ISCA harness connector and chassis ground.
  - Specification (Resistance): infinite



Does the resistance indicate open?



Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

EZOF605L

FLB -233

## TROUBLESHOOTING FOR DTC E660EF86

DTC	P1506	Idle Charge Actuator Signal High of Coil #1
-----	-------	---

### **DESCRIPTION**

Refer to DTC P1505

#### DTC DETECTING CONDITION

1. DTC Description

ECM sets DTC P1506 if the ECM detects that the ISCA (OPEN) control line is short to battery line.

2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause
P1506	Detecting Condition  • DTC Strategy  - Driver stage check (Coil #1)  • Enable condition  - Battery voltage > 10V	<ul> <li>Short to battery line in ISCA circuit</li> <li>ISCA</li> <li>ECM</li> </ul>
91-	<ul> <li>Threshold Value</li> <li>ISCA (Coil #1) control line is short to battey line for 1 second</li> </ul>	

## شرکت دیجیتال خودرو سامانه (مسئول SPECIFICATION

Refer to DTC P1505

SCHEMATIC DIAGRAM

Refer to DTC P1505

SIGNAL WAVE FORM

Refer to DTC P1505

**ISCA** 

3

**ECM** 

46

OFF

## FLB -234

### **INSPECTION PROCEDURE**

#### 1. CHECK ISCA AND ECM CONNECTORS

- 1. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
  - Refer to "CONNECTOR INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

Are all connectors good?

Yes

No Repair or replace it.

#### 2. CHECK ISCA RESISTANCE

- 1. Turn ignition switch to OFF position and then disconnect ISCA connector.
- 2. Measure resistance between terminals 2 and 1 of the ISCA opening coil.
  - Specification (ISCA resistance):

	Temperature		ISCA Coil #1 (OPEN)	ISCA Coil #2 (CLOSE)
(°C) (°F)		(°F)	Resistance (Ω)	Resistance (Ω)
	20	68	14.9 ~ 16.1	17.0 ~ 18.2


- 3. Inspect the signal waveform of the ISCA closing coil using a Hi-Scan (Pro).
  - Refer to "SIGNAL WAVEFORM" for more information.

Is the resistance within specification?



## 3. CHECK POWER TO ISCA

- 1. Turn ignition switch to OFF position and disconnect ISCA connector.
- 2. Turn ignition switch to ON position.
- 3. Measure the voltage between terminal 2 of the ISCA harness connector and chassis ground.
  - Specification: approximately B+



Is voltage within specification?

Yes


No Repair open or short to chassis ground in harness.

EZOF605K

FLB -235

## 4. CHECK FOR SHORT TO POWER IN HARNESS

- 1. Turn ignition switch to OFF position and disconnect ISCA and ECM connectors.
- 2. Turn ignition switch to ON position.
- 3. Measure voltage between terminal 1 of the ISCA harness connector and chassis ground.
  - Specification (Voltage): below 0.5V



Is voltage within specification?



No

Repair short to power in harness.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

EZOF605M



سرحت دیجیت از حودرو سالمان با معتودیت تعدودی

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



## **FUEL SYSTEM (G6BA-GSL 2.7)**

## TROUBLESHOOTING FOR DTC E33FC549

DTC	P1507	Idle Charge Actuator Signal Low of Coil #2
-----	-------	--

#### **DESCRIPTION**

Refer to DTC P1505

#### DTC DETECTING CONDITION

1. DTC Description

ECM sets DTC P1507 if the ECM detects that the ISCA (CLOSE) control line is open or short to ground.

2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause
	Detecting Condition  • DTC Strategy  - Driver stage check (Coil #2)	Open or short to ground
P1507	Enable condition     Battery voltage > 10V	in ISCA circuit  ISCA  ECM
91	<ul> <li>Threshold Value</li> <li>ISCA (Coil #2) control line is open or short to ground for 1 second</li> </ul>	
(2025	شرخت دیجیتال حودر و سامانه (مسئولیت ه	

## **SPECIFICATION**

ولين سامانه ديجيتال تعميركاران خو Refer to DTC P1505

SCHEMATIC DIAGRAM

Refer to DTC P1505

SIGNAL WAVE FORM

Refer to DTC P1505

FLB -237

### **INSPECTION PROCEDURE**

### 1. CHECK ISCA AND ECM CONNECTORS

- 1. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
  - Refer to "CONNECTOR INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

Are all connectors good?



No Repair or replace it.

### 2. CHECK ISCA RESISTANCE

- ${\bf 1.} \ \ {\bf Turn\ ignition\ switch\ to\ OFF\ position\ and\ then\ disconnect\ ISCA\ connector.}$
- 2. Measure resistance between terminals 3 and 2 of the ISCA closing coil.
  - Specification (ISCA resistance):

Temperature		ISCA Coil #1 (OPEN)	ISCA Coil #2 (CLOSE)
(°C)	(°F)	Resistance (Ω)	Resistance (Ω)
20	68	14.9 ~ 16.1	17.0 ~ 18.2

3. Inspect the signal waveform of the ISCA closing coil using a Hi-Scan (Pro).

Refer to "SIGNAL WAVEFORM" for more information.

Is the resistance within specification?




No

Replace ISCA.

## 3. CHECK POWER TO ISCA

- 1. Turn ignition switch to OFF position and disconnect ISCA connector.
- 2. Turn ignition switch to ON position.
- 3. Measure the voltage between terminal 2 of the ISCA harness connector and chassis ground.
  - Specification: approximately B+



**ISCA** 

**ECM** 

OFF

## Is voltage within specification?



No

Repair open or short to chassis ground in harness.


EZOF605H

## **FUEL SYSTEM (G6BA-GSL 2.7)**

## FLB -238

### 4. CHECK FOR OPEN IN HARNESS

- Turn ignition to OFF position, and then disconnect ISCA and ECM connector.
- 2. Measure resistance between terminal 3 of the ISCA harness connector and 47 of the ECM harness connector (C133-3).
  - Specification (Resistance): below  $1\Omega$




Does the resistance indicate continuity?



No Repair open in harness.

## 5. CHECK FOR SHORT TO GROUND IN HARNESS

- 1. Turn ignition switch to OFF position, and then disconnect ISCA and ECM connector.
- 2. Measure resistance between terminal 3 of the ISCA harness connector and chassis ground.
  - Specification (Resistance): infinite



Does the resistance indicate open?



No

Repair short or short to chassis ground in harness.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

EZOF605I

FLB -239

## TROUBLESHOOTING FOR DTC E7CE7AB2

DTC	P1508	Idle Charge Actuator Signal High of Coil #2	
-----	-------	---	--

### **DESCRIPTION**

Refer to DTC P1505

#### DTC DETECTING CONDITION

1. DTC Description

ECM sets DTC P1508 if the ECM detects that the ISCA (CLOSE) control line is short to battery line.

2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause
P1508	Detecting Condition  • DTC Strategy  - Driver stage check  • Enable condition  - Battery voltage > 10V  • Threshold Value  - ISCA (Coil #2) control line is short to battery line for 1 second	<ul> <li>Short to battery line in ISCA circuit</li> <li>ISCA</li> <li>ECM</li> </ul>

# شركت ديجيتال خودرو سامانه (مسئول SPECIFICATION)

Refer to DTC P1505

SCHEMATIC DIAGRAM

Refer to DTC P1505

SIGNAL WAVE FORM

Refer to DTC P1505

**ISCA** 

3

**ECM** 

OFF

## FLB -240

### **INSPECTION PROCEDURE**

## 1. CHECK ISCA AND ECM CONNECTORS

- 1. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
  - Refer to "CONNECTOR INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

Are all connectors good?



No

Repair or replace it.

## 2. CHECK ISCA RESISTANCE

- 1. Turn ignition switch to OFF position and then disconnect ISCA connector.
- 2. Measure resistance between terminals 3 and 2 of the ISCA closing coil.
  - Specification (ISCA resistance):

Temperature		ISCA Coil #1 (OPEN)	ISCA Coil #2 (CLOSE)
(°C)	(°F)	Resistance (Ω)	Resistance (Ω)
20	68	14.9 ~ 16.1	17.0 ~ 18.2

- 3. Inspect the signal waveform of the ISCA closing coil using a Hi-Scan (Pro).
  - Refer to "SIGNAL WAVEFORM" for more information.

Is the resistance within specification?




No

Replace ISCA.

## 3. CHECK POWER TO ISCA

- 1. Turn ignition switch to OFF position and disconnect ISCA connector.
- 2. Turn ignition switch to ON position.
- 3. Measure the voltage between terminal 2 of the ISCA harness connector and chassis ground.
  - Specification: approximately B+



Is voltage within specification?

Yes

No


Repair open or short to chassis ground in harness.

EZOF605H

FLB -241

## 4. CHECK FOR SHORT TO POWER IN HARNESS

- 1. Turn ignition switch to OFF position and disconnect ISCA and ECM connectors.
- 2. Turn ignition switch to ON position.
- 3. Measure voltage between terminal 3 of the ISCA harness connector and chassis ground.
  - Specification (Voltage): below 0.5V



Is voltage within specification?



No Repair short to power in harness.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

EZOF605J



شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



## **FUEL SYSTEM (G6BA-GSL 2.7)**

## TROUBLESHOOTING FOR DTC E

DTC	P1529	TCM Request for MIL ON / Freeze frame to ECM via CAN
-----	-------	--

#### **DESCRIPTION**

A communication line exists between the Engine Control Module (ECM) and the Transaxle Control Module (TCM). The sole purpose of this communication line is for the TCM to notify the ECM to activate the Malfunction Indicator Lamp (MIL) when a serious transaxle failure has occurred.

### DTC DETECTING CONDITION

1. DTC Description

The ECM illuminates the MIL and sets DTC P1529 if TCM requests "MIL ON" via CAN. This error code determines diagnostic failure at TCM side.

2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause
Ol'	Detecting Condition  • DTC Strategy  - MIL ON request from TCM	0
P1529	<ul><li>Enable condition</li><li>None</li></ul>	Transaxle system
محدود)	Threshold Value     MIL is requested by TCM	

#### **INSPECTION PROCEDURE**

- This is only a request from the TCM to turn the MIL ON. The fault code is stored in the TCM. The
  freeze frame data is stored in the ECM under the P1529 request code. Be sure to retrieve the
  freeze frame data before clearing code P1529 from the ECM.
- · Check the transaxle system.

FLB -243

## TROUBLESHOOTING FOR DTC E347D9F1

DTC	P1602	CAN Communication BUS with TCM (Timeout)
-----	-------	--

#### **DESCRIPTION**

A communication line exists between the Engine Control Module(ECM) and the Transaxle Control Module(TCM). The communication is through a Control Area Network(CAN). Without CAN communication, an independent pin and wiring is needed to receive a sensor information from a ECM. The more information to be communicated, the more wirings is required. In case of CAN communication type, all the information need to be communicated among control modules such as ECM and TCM use CAN lines.

#### DTC DETECTING CONDITION


1. DTC Description

The ECM sets DTC P1602 if the message from the TCM is missed.

2. Conditions for Setting the DTC

DTC	Detecting Condition & Limp Home	Possible Cause	
P1602	Detecting Condition  DTC Strategy  Missing messages from TCM  Enable condition  Battery voltage > 10V  Engine speed > 256 rpm  Threshoold Value  Time(0.5 sec) exceeded without message for 1 second	Open or short in CAN communication line     ECM	

#### SCHEMATIC DIAGRAM



EZOF6027

### **INSPECTION PROCEDURE**

#### 1. CHECK TCM AND ECM CONNECTORS

- 1. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
  - Refer to ""CONNECTOR INSPECTION PROCEDURE"" in BASIC INSPECTION PROCEDURE."

### Are all connectors good?




No Replace TCM.

### 2. CHECK FOR OPEN IN HARNESS

- Turn ignition to OFF position, and then disconnect TCM and ECM connector.
- 2. Measure resistance between terminal 4 of the TCM harness connector (C136-3) and 37 of the ECM harness connector (C133-4).
- 3. Measure resistance between terminal 3 of the TCM harness connector (C136-3) and 36 of the ECM harness connector (C133-4).
  - Specification (Resistance): below 1Ω





Yes


No

Repair open in harness.

## 3. CHECK FOR SHORT TO GROUND IN HARNESS

- Turn ignition switch to OFF position, and then disconnect TCM and ECM connectors.
- 2. Measure resistance between terminal 4 of the TCM harness connector (C136-3) and chassis ground.
- 3. Measure resistance between terminal 3 of the TCM harness connector (C136-3) and chassis ground.
  - Specification (Resistance): infinite"

Does each resistance indicate open?



Yes

No

Repair short in harness or short to chassis ground.


EZOF6028

FLB -245

#### 4. CHECK FOR SHORT TO POWER IN HARNESS

- 1. Turn ignition switch to OFF position, and then disconnect TCM and ECM connectors.
- 2. Turn ignition switch to ON position.
- 3. Measure voltage between terminal 4 of the TCM harness connector (C136-3) and chassis ground.
- 4. Measure voltage between terminal 3 of the TCM harness connector (C136-3) and chassis ground.
  - Specification (Voltage): below 0.5V"

Is voltage within specification?





No

Repair short to power in harness.

Proceed with "ECM PROBLEM INSPECTION PROCEDURE" in BASIC INSPECTION PROCEDURE.

EZOF6029




شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



## **FUEL DELIVERY SYSTEM**

## COMPONENTS LOCATION ED65A2C7



- 1. Fuel Tank
- 2. Fuel Pump (Including Fuel Filter and Fuel Pressure Regulator)
- 3. Fuel Sender
- 4. Hose Suction
- 5. Hose Canister

EWOF008B


## **FUEL DELIVERY SYSTEM**

FLB -247

## FUEL PRESSURE TEST EECECC8E


#### 1. PREPARING


- 1. Remove the rear seat cushion (Refer to ""BD"" group in this SHOP MANUAL).
- 2. Open the service cover (A) under the rear seat cushion.



#### 2. RELEASE THE INTERNAL PRESSURE

- Disconnect the fuel pump connector.
- 2. Start the engine and wait until fuel in fuel line is exhausted.
- 3. After the engine stalls, turn the ignition switch to OFF position and diconnect the negative (-) terminal from the battery.






## 3. INSTALL THE SPECIAL SERVICE TOOL (SST) FOR MEASURING THE FUEL PRESSURE

1. Disconnect the fuel feed hose from the delivery pipe.



Cover the hose connection with a shop towel to prevent splashing of fuel caused by residual pressure in the fuel line.

- 2. Install the Fuel Pressure Gage Adapter (09353-38000) between the delivery pipe and the fuel feed hose.
- 3. Connect the Fuel Pressure Gage Connector (09353-24000) to the Fuel Pressure Gage Adapter (09353-38000).
- 4. Connect the Fuel Pressure Gage and Hose (09353-24100) to Fuel Pressure Gage Connector (09353-24000).
- 5. Connect the fuel feed hose to the Fuel Pressure Gage Adapter (09353-38000).



EZOF008I

## **FUEL SYSTEM (G6BA-GSL 2.7)**

## FLB -248

### 4. INSPECT FUEL LEAKAGE ON CONNECTION

- 1. Connect the battery negative (-) terminal.
- 2. Apply battery voltage to the fuel pump terminal and activate the fuel pump. With fuel pressure applied, check that there is no fuel leakage from the fuel pressure gauge or connection part.

### 5. FUEL PRESURE TEST

- 1. Diconnect the negative (-) terminal from the battery.
- 2. Connect the fuel pump connector.
- 3. Connect the battery negative (-) terminal.
- 4. Start the engine and measure the fuel pressure at idle.

Standard Value: 350 kpa (3.5 kg/cm², 49.8 psi)

If the measured fuel pressure differs from the standard value, perform the necessary repairs using the table below.

Condition	Probable Cause	Supected Area	
	Clogged fuel filter	Fuel filter	
	Fuel leak on the fuel-pressure regulator that is assembled on fuel pump because of poor seating of the fuel-pressure regulator.  Fuel leak on the fuel-pressure Fuel Pressure Regulator.		
Fuel Pressure too High	Sticking fuel pressure regulator	Fuel Pressure Regulator	

5.	Stop the engil	ne and check for	a change in the	fuel pressure	gauge reading.
----	----------------	------------------	-----------------	---------------	----------------

After engine stops, the gage reading should hold for about 5 minutes

 Observing the declination of the fuel pressure when the gage reading drops and perform the necessary repairs using the table below.

Condition	Probable Cause	Supected Area	
Fuel pressure drops slowly after engine is stopped	Injector leak	Injector	
Fuel pressure drops immediately after engine is stopped	The check valve within the fuel pump is open	Fuel Pump	

EWOF008Z

## **FUEL DELIVERY SYSTEM**


FLB -249

#### 6. RELEASE THE INTERNAL PRESSURE

- 1. Disconnect the fuel pump connector.
- 2. Start the engine and wait until fuel in fuel line is exhausted.
- 3. After the engine stalls, turn the ignition switch to OFF position and diconnect the negative (-) terminal from the battery.



Be sure to reduce the fuel pressure before disconnecting the fuel feed hose, otherwise fuel will spill out.



## 7. REMOVE THE SPECIAL SERVICE TOOL (SST) AND CONNECT THE FUEL LINE

- 1. Disconnect the Fuel Pressure Gage and Hose (09353-24100) from the Fuel Pressure Gage Connector (09353-24000).
- 2. Disconnect the Fuel Pressure Gage Connector (09353-24000) from the Fuel Pressure Gage Adapter (09353-38000).
- 3. Disconnect the fuel feed hose from the Fuel Pressure Gage Adapter (09353-38000).
- 4. Disconnect the Fuel Pressure Gage Adapter (09353-38000) from the delivery pipe.

CAUTION

Cover the hose connection with a shop towel to prevent splashing of fuel caused by residual pressure in the fuel line.

Conenct the fuel feed hose to the delivery pipe.

## 8. INSPECT FUEL LEAKAGE ON CONNECTION

- 1. Connect the battery negative (-) terminal.
- 2. Apply battery voltage to the fuel pump terminal and activate the fuel pump. With fuel pressure applied, check that there is no fuel leakage from the fuel pressure gauge or connection part.
- 3. If the vehicle is normal, connect the fuel pump connector.

EWOF008K


## **FUEL SYSTEM (G6BA-GSL 2.7)**

## FLB -250

## **FUEL INJECTOR**

## INSPECTION E6C3CF1D

1. Measure resistance between the terminal 1 and 2 of the injector.



BFGE502Q

Specification (Resistance): 13.8 ~ 15.2 at 20°C (68°F)

2. If the resistance is not within specification, replace the injector.

ولین سامانه دیجیتال تعمیرکاران خودرو در ایران




## **FUEL DELIVERY SYSTEM**

## FLB -251

## **FUEL PUMP (FP)**

## REMOVAL (INCLUDING FUEL FILTER AND FUEL PRESSURE REGULATOR) E2AC6DE7

- Remove the rear seat cushion (Refer to "BD" group in this SHOP MANUAL).
- Open the service cover (A) under the rear seat cush-







## ∴ CAUTION

Cover the hose connection with a shop towel to prevent splashing of fuel caused by residual pressure in the fuel line

- Unfasten the fuel pump cap (D) counterclockwise.
- Remove the fuel pump assembly.








EWOF008E

- 3. Release the internal pressure of the fuel lines and hoses as following:
  - Disconnect the fuel pump assembly harness connector (A).
  - Start the engine and wait until fuel in fuel line is exhausted. After the engine stalls, turn the ignition switch to OFF position.
  - Disconnect the negative (-) terminal from the battery.




EWOF008D


## **FUEL TANK**

#### REMOVAL E8956AD8

- Remove the rear seat cushion (Refer to "BD" group in this SHOP MANUAL).
- 2. Open the service cover (A) under the rear seat cushion.



- Release the internal pressure of the fuel lines and hoses as following:
  - Disconnect the fuel pump assembly harness connector (A).
  - Start the engine and wait until fuel in fuel line is exhausted. After the engine stalls, turn the ignition switch to OFF position.
  - Disconnect the negative (-) terminal from the battery.



EWOF008F


Disconnect the fuel feed line (B).




## ∴ CAUTION

Cover the hose connection with a shop towel to prevent splashing of fuel caused by residual pressure in the fuel line

- Lift the vehicle.
- Remove the muffler (A) (Refer to "EM" group in this SHOP MANUAL).



EWOF008H



EWOF008J

Disconnect the leveling hose (D), the fuel filler hose (E) and the vaccum hoses (F,G)



## NOTE

When disconnecting the vaccum hose (D), also release the connection point in front of the fuel tank.

- Support the fuel tank with lifter.
- Remove the fuel tank band (B) and remove the fuel tank (C).