

Audio System -RPS-MP3 RDDIO PT CD.Remote Display

item code	description	information
1032	null	electrical supplies protection and management unit
7215	null	/ multifunction screen
8404	null	aerial
8409	null	heated rear screen/aerials / assembly
8410	null	/ audio system
8430	null	rear left speaker
8435	null	rear right speaker
8440	null	front left tweeter speaker
8444	null	front left woofer speaker
8445	null	front right tweeter
8449	null	front right woofer speaker
8482	null	audio-navigation microphone / audio-telephone microphone
8499	null	external audio input block
84A1	null	USB socket on front centre console
84B3	null	matrix display on the instrument panel
84C5	null	digital tuner aerial
84C6	null	multifunction control panel
84D1	null	digital aerial adaptor
84D2	null	AM-FM aerial adaptor 1
84D3	null	AM-FM aerial adaptor 2
AE00	null	electric steering lock
BB00	null	ancillaries battery
BSI1	null	built-in systems interface
CA00	null	ignition switch
CV00	null	control under the steering wheel
E841A	null	crimp one information (or equipotential 841A) wire
E841B	null	crimp one information (or equipotential 841B) wire
E843A	null	crimp one information (or equipotential 843A) wire
E843B	null	crimp one information (or equipotential 843B) wire
E917	null	crimp one information (or equipotential 917) wire
E917A	null	crimp one information (or equipotential 917A) wire
E918	null	crimp one information (or equipotential 918) wire
E918A	null	crimp one information (or equipotential 918A) wire
E934	null	crimp one information (or equipotential 934) wire
E935	null	crimp one information (or equipotential 935) wire
E953	null	crimp one information (or equipotential 953) wire
ECV0	null	steering wheel integrated controls assembly
EM40A	null	crimp earth (earth point number 40A)
EM51B	null	crimp earth (earth point number 51B)
EM53	null	crimp earth (earth point number 53)
MC10	null	body earth point number 10
MC40A	null	body earth point number 40
MC40B	null	body earth point number 40
MC51B	null	body earth point number 51
MC53B	null	body earth point number 53B
MM01	null	engine earth point number 01
PSF1	null	engine compartment connection board-fuse box