


12. MANUAL AIR CONDITIONING SYSTEM


1) CONDENSER FAN MOTOR, A/C COMPRESSOR, TRIPLE PRESSURE SWITCH, A/C TEMPERATURE SWITCH



a. CONNECTOR INFORMATION


CONNECTOR NUMBER	WIRING HARNESS	GROUND POSITION
G101	Engine Room	Behind Left Head Lamp
G103	Engine Room	Behind Right Head Lamp

b. CONNECTOR IDENTIFICATION SYMBOL & PIN NUMBER POSITION




C. POSITION OF CONNECTORS AND GROUNDS


- W/H ENGINE ROOM



- W/H MAIN : FRONT




2) ACTUATOR (MIX, MODE, INTAKE), BLOWER (MOTOR, RESISTOR, SWITCH)



a. CONNECTOR INFORMATION


CONNECTOR NUMBER	WIRING HARNESS	GROUND POSITION
G201	Main	Above Driver Seat Leg Room

b. CONNECTOR IDENTIFICATION SYMBOL & PIN NUMBER POSITION




C. POSITION OF CONNECTORS AND GROUNDS


• W/H MAIN : FRONT




MODE ACTUATOR




MIX ACTUATOR




INTAKE ACTUATOR



BLOWER MOTOR




STICS




C209

• W/H FLOOR : TRUNK

• W/H FLOOR : CO-DRIVER SEAT



C214



C405

