


AIRBAG 1



wire harness junctor	description	page
M84	SRS ECU wire harness junctor	33
M82	clock spring wire harness junctor	33
M83	auxiliary safety air bag wire harness junctor	33
M85	left airbag wire harness junctor	33
M87	right airbag wire harness junctor	33
M89	left seat belt pretensioner wire harness junctor	33
M92	right seat belt pretensioner wire harness junctor	33
M99	connecting with right curtain airbag wire harness junctor	33
M101	connecting with left curtain airbag wire harness junctor	33


دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



AIRBAG 2



wire harness junctor	description	page
M84	SRS ECU wire harness junctor	33
M88	left collision sensor wire harness junctor	33
M91	right collision sensor wire harness junctor	33
PMB	IP.BOX B wire harness junctor	33
PMF	IP.BOX F wire harness junctor	25
M86	landing	63

connection point	remark	page
M84-46	to BCM B M02-37	205

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

