



Central lock 1



Harness connector	Name	Page
M01	BCM A harness connector	25
M02	BCM B harness connector	25
D09	Left door lock motor harness connector	49
D34	Door lock motor harness connector	49
D29	Right door lock motor harness connector	53
D40	Left rear door lock motor harness connector	53
MF1	Main harness to frame harness connector 1	26
FM1	Frame harness to main harness 1	43
FD1	Body harness to left front door harness connector 1	43
DF1	Left front door harness to main harness harness connector 1	49
FD2	Body harness to left front door harness connector 2	43
DF2	Left front door to body harness connector 2	49
FD3	Body harness to right front door harness connector 1	43
DF3	Right front door to body harness connector 1	53
FD4	Body harness to right rear door harness connector 1	45
DF4	Right rear door to body harness connector 1	53
F04	Ground	64

Central lock 2



Harness connector	Name	Page
M02	BCM B Harness connector	25
M03	BCM C Harness connector	26
D10	Glass switch (Low equiped) Harness connector	49
D13	Glass switch (High equiped) Harness connector	49
TG05	Rear gate unlock Harness connector	54
TG11	Rear gate switch Harness connector	54
MF1	Main harness to frame harness connector 1	26
FM1	Frame harness to main harness 1	43
MF2	Main harness to frame harness connector 2	26
FM2	Frame harness to main harness 2	43
FD1	Body harness to left front door harness connector 1	43
DF1	Left front door harness to main harness harness connector 1	49
FT2	Body harness to rear gate harness	45
TF2	Rear gate harness to body harness	54
F04	Ground	64
F45	Ground	64