


Electric Mirrors



دیجیتال خودرو
 شرکت دیجیتال خودرو سامانه (مسئولیت محدود)
 اولین سامانه دیجیتال تعمیرکار

Electric Mirrors

item code	description	information
1032	null	electrical supplies protection and management unit
6036	null	driver's door electric windows and exterior mirrors control pad
6404	null	passenger 's rear view mirror memorisation and lighting control unit
6410	null	left-hand electric and heated exterior mirror
6415	null	right-hand electric and heated exterior mirror
AE00	null	electric steering lock
BB00	null	ancillaries battery
BFH3	null	cabin relay fusebox 1
BSI1	null	built-in systems interface
CA00	null	ignition switch
E301	null	crimp one information (or equipotential 301) wire
E700	null	crimp one information (or equipotential 700) wire
E904	null	crimp one information (or equipotential 904) wire
E904C	null	crimp one information (or equipotential 904C) wire
E904D	null	crimp one information (or equipotential 904D) wire
E904E	null	crimp one information (or equipotential 904E) wire
E905A	null	crimp one information (or equipotential 905A) wire
E917	null	crimp one information (or equipotential 917) wire
E917A	null	crimp one information (or equipotential 917A) wire
E918	null	crimp one information (or equipotential 918) wire
E918A	null	crimp one information (or equipotential 918A) wire
E953	null	crimp one information (or equipotential 953) wire
EM30A	null	crimp earth (earth point number 30A)
EM40C	null	crimp earth (earth point number 40C)
EM53	null	crimp earth (earth point number 53)
EM70	null	crimp earth (earth point number 70)
EM71	null	crimp earth (earth point number 71)
MC10	null	body earth point number 10
MC30B	null	body earth point number 30B
MC40C	null	body earth point 40C
MC53B	null	body earth point number 53B
MM01	null	engine earth point number 01
PSF1	null	engine compartment connection board-fuse box