



Pre-Crash Safety System




Pre-Crash Safety System




Pre-Crash Safety System

F8(B)
Power Management Control ECU




Pre-Crash Safety System

F8(B)
Power Management Control ECU



Pre-Crash Safety System




The diagram illustrates the wiring for a digital car alarm system. The central component is a blue rectangular alarm unit with 18 pins. The connections are as follows:











- Pin 1:** Connected to the GR (Ground) wire.
- Pin 2:** Connected to the L (Left) wire.
- Pin 3:** Connected to the R (Right) wire.
- Pin 4:** Connected to the P (Park) wire.
- Pin 5:** Connected to the BE (LHD) wire.
- Pin 6:** Connected to the R (RHD) wire.
- Pin 7:** Connected to the V (Voltage) wire.
- Pin 8:** Connected to the R (RHD) wire.
- Pin 9:** Connected to the P (LHD) wire.
- Pin 10:** Connected to the R (LHD) wire.
- Pin 11:** Connected to the BE (LHD) wire.
- Pin 12:** Connected to the R (LHD) wire.
- Pin 13:** Connected to the L (Left) wire.
- Pin 14:** Connected to the R (RHD) wire.
- Pin 15:** Connected to the P (Park) wire.
- Pin 16:** Connected to the BE (RHD) wire.
- Pin 17:** Connected to the R (RHD) wire.
- Pin 18:** Connected to the B (Battery) wire.

The diagram also shows the connections for the F43 Steering Sensor and the F71 Junction Connector. The F43 Steering Sensor has two pins: CANL and CANH. The F71 Junction Connector has two pins: 3 and 4. The F43 Steering Sensor is connected to the F71 Junction Connector, which is then connected to the alarm unit.













Pre-Crash Safety System











Pre-Crash Safety System

A 44
BlackA 47
GreenA 48
BlackA 51
BlueA 52
BlackA 56
BlackA 61
BlackA 62
BlackA 63
WhiteA 67
GrayA 79
WhiteB 1
BlackC 1
WhiteF 8
Black















Pre-Crash Safety System

F 13
BlackF 15
BlackF 16
BlackF 17
WhiteF 19
WhiteF 28
BlackF 29
YellowF 42
WhiteF 43
BlueF 56
WhiteF 57
WhiteF 65
White


Pre-Crash Safety System

F 66
WhiteF 67
BlackF 68
BlackF 70
BlueF 71
BlueF 81
WhiteF 92
WhiteF 93
White


Pre-Crash Safety System




Pre-Crash Safety System




Pre-Crash Safety System



Pre-Crash Safety System



Pre-Crash Safety System



دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

