



d3ap532pi

allocation of PSF1 fuses

fuse	A	supply	matching
F1 (MFRM)	5A	-	controlled air intake module
F5 (MFRM)	5A	-	ABS steering angle sensor
F8 (MFRM)	-	-	-
F9 (MFRM)	-	-	-
F10 (MFRM)	5A	-	automatic gearbox control assembly - automatic gearbox grille position
F11 (MFRM)	5A	-	shift-lock relay
F12 (MFRM)	15A	-	AM6/AT6 gearbox ECU - electrovalve piloted manual gearbox ECU
F13 (MFRM)	20A	-	boiler (cabin coolant heater)
F14 (MFRM)	-	-	-
F15 (MFRM)	-	-	-
F16 (MFRM)	-	-	-
F17 (MFRM)	-	-	-
F18 (MFRM)	5A	-	secondary dual-function stoplamp switch
F19 (MFRM)	-	-	-
F6 (MFRM)	40A	-	RH and LH windscreen wiper motors
F1	15A	-	BPGA Principal Relay safety - Engine ECU
F16	20A	-	pompe rte
F25	30A	-	-
F26	10A	-	air conditioning compressor
F2	5A	-	engine cooling
F3	5A	-	engine management ECU
F4	5A	-	centralised voltage maintaining system
F5	15A	-	engine management ECU
F6	20A	-	engine management ECU - fuel gauge sender unit
F7	10A	-	engine management ECU - active damper ECU
F8	10A	-	fuel additive pump - engine management ECU
F10	5A	-	-
F11	15A	-	active damper ECU - headlamps - dynamic headlamp correction control unit
F12	5A	-	ABS ECU - stolen vehicle location control unit - aircon compressor control relay
F13	-	-	-
F18	-	-	-
F20	15A	-	windscreen wash pump
F21	20A	-	Headlamp washer pump
F22	15A	-	horn
F23	15A	-	RH headlamps
F24	15A	-	LH headlamps
F27	5A	-	LH headlamps
F28	5A	-	RH headlamps
F30	30A	-	engine management ECU
F15	5A	-	power steering electropump - cabin air heating element
F9	10A	-	electric steering lock
F17	10A	-	built-in systems interface (BSI)
F29	30A	-	starter motor
F14	25A	-	screen washer pump earth